



RAZER WIRELESS CHARGING GAMING MOUSE MAT&PUCK

RZ02-0493 & HFX01


IMPORTANT PRODUCT INFORMATION GUIDE

WHAT'S INSIDE

- Razer Wireless Charging Gaming Mouse Mat




- A. Status indicator
- B. Continuous charging mat
- C. Anti-slip rubber base
- D. USB Type C connector
- E. USB Type C to USB Type A adapter
- F. Wireless Charging Puck




- Important Product Information Guide

WHAT'S NEEDED




Compatible Razer wireless charging enabled-mouse*



**Sold separately. For an updated list of compatible mice, visit support.razer.com*

LET'S GET YOU COVERED



*Your product's serial
number can be found here.*




Register your product and score exclusive benefits

razerid.razer.com/warranty


GETTING STARTED

SETTING UP


1




2




3



4




5



i

Install Razer Synapse when prompted or download the installer at razer.com/synapse. Use the Razer Synapse app to customize your mouse's charge limit, pair a keyboard, change pairing behavior, and more.

CHARGING



Mouse Battery Status

Mat Status Indicator

Mouse Battery Status	Mat Status Indicator
Not available	Disabled
Charged	Static Green
~75%	Breathing Green
~50%	Breathing Yellow
~25%	Breathing Red
~5%	Blinking Red

Find out more about your gaming-grade mouse mat at support.razer.com

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer Wireless Charging Mouse Mat, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for assistance.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

The mouse mat requires a USB connection that can supply sufficient power to charge a Razer wireless charging-compatible mouse. The charging process may be affected when connecting to a non-powered USB hub or non-powered USB, mostly found on keyboards and peripherals.

Don't use or place the device near water, moisture, or other wet surfaces.

Don't use or place the device near any heat, naked flame, or other hot surfaces such as radiators, stoves, fireplaces, and candles.

The product should only be used with compatible Razer wireless charging-enabled mice. Please check if your device is compatible with the mouse dock before charging. Razer shall not be responsible for any damages incurred to any device when using the mouse dock.

Don't place (or drag) heavy, sharp, or rough items on top of the mouse mat, as this may scratch or damage its surface.

Don't strike the mouse mat using hard or pointed objects and don't place very hot or cold items on the mouse mat.

MAINTENANCE AND USE

The product requires minimum maintenance to keep it in optimum condition. Once a month we recommend you unplug the device from the computer and clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

CAUTION: DO NOT FOLD or BEND the mouse mat, as doing so may damage or deform the product and void the warranty.

BATTERY WARNING

The charging puck contains a lithium-ion rechargeable battery. In general, the life expectancy of such battery is dependent upon usage. If you suspect that the lithium-ion rechargeable battery may be drained (has a low charge), try recharging it. If the battery does not recharge after several attempts, it may be non-operational.

Do not open, mutilate, or expose the battery to conducting materials (metal), moisture, liquid, fire, or heat. Doing so may cause the battery to leak or explode, resulting in personal injury. Do not use or charge the battery if leaking, discolored, or deformed. Do not leave the rechargeable battery discharged or unused for extended periods. When not using the battery for more than 30 days, be sure to store it in a fully charged state. Do not tamper with the battery. Dispose of the used battery according to local regulations.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, “For Gamers. By Gamers.”, and “Razer Chroma” logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. Actual product may differ from pictures. All other trademarks are the property of their respective owners. Warranty not valid outside of product’s intended region.

Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent, or other intellectual property right. The Razer Wireless Charging System(the “Product”) may differ from pictures, whether on the packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages arising in any way out of distribution of, sale of, resale of, use of, or inability to use the product. In no event shall Razer’s liability exceed the retail purchase price of the product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

FCC Statement

15.105

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

WPT:

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 5 mm from all persons and must not be co-located or

operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

15.19

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 / KDB784748 D01 v08 (P4)

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Declaration of Conformity

Hereby, **Razer Inc.** declares that the radio equipment type Wireless Charging Gaming Mouse Mat and Wireless Charging Puck is in compliance with Directive 2014/53/EU as well as UK Radio Equipment Regulations SI 2017 No.1206. The full text of the EU/UK declaration of conformity is available at the following internet address: [razer.com/legal/compliance](https://www.razer.com/legal/compliance)

2.4G equipment

- Operating frequency range: 2402-2480MHz
- Maximum out power(E.I.R.P): 9.04dBm (8.02 mW), 2.4G SRD

Wireless charging

- Operating frequency range: 6,765kHz to 6,795kHz
- Maximum out power: 7.5W