




RAZER RZ03-0544 WIRELESS KEYBOARD

IMPORTANT PRODUCT INFORMATION GUIDE

WHAT'S INSIDE

■ Razer RZ03-0544




**Function may vary per operating system.*


***Mapped to Backspace by default.*

- A. Razer Command Dial
- B. Command Dial mode indicator LED
- C. Dedicated Macro keys
- D. Screen brightness keys
- E. Task View / Mission Control key*
- F. Search key
- G. Dictation key
- H. Emoji / Character Viewer key*
- I. USB Type C port
- J. Mode switch
- K. Context Menu key
- L. Launch Calculator key
- M. Mute / Unmute microphone key
- N. Screen lock key
- O. Backlight control keys
- P. Razer HyperSpeed mode key (2.4 GHz)
- Q. Bluetooth profile keys
- R. Sleep mode key
- S. Multi-function media button
- T. AI Prompt Master button
- U. Battery life / status button
- V. Multi-function roller
- W. Middle key**
- X. Integrated wrist rest
- Y. Kickstand

- Razer HyperSpeed Wireless Dongle + USB dongle adapter




- USB Type A to Type C cable



- Important Product Information Guide

WHAT'S NEEDED



LET'S GET YOU COVERED




Register your product and score exclusive benefits
razerid.razer.com/warranty

*Your product's serial
number can be found*

GETTING STARTED

CHARGING YOUR KEYBOARD




i For best results, fully charge your keyboard before using it for the first time. You may continue using the keyboard while plugged in.

CONNECTING TO YOUR KEYBOARD


A. Via Razer HyperSpeed Wireless mode (2.4 GHz)

1.





2.

WIRELESS



Switch to Razer HyperSpeed Wireless mode




For initial set up only.

Your keyboard is now ready to use in Razer HyperSpeed Wireless mode (2.4 GHz).


B. Via Bluetooth mode

1.

WIRELESS




2. Switch to Bluetooth mode / Select a Bluetooth profile




i The Bluetooth profile button will briefly show the selected Bluetooth profile. Your keyboard can pair up to 3 devices using its Bluetooth profiles.

- 3.




C. Via Wired mode

1.



2.




i Install Razer Synapse when prompted, or download the installer from razer.com/synapse

Your keyboard is now ready to use in wired mode.


USING YOUR RAZER RZ03-0544

SWITCHING BETWEEN WIRELESS MODES



COMMAND DIAL*

Switching Between Razer Command Dial Modes




Command Dial Modes	Command Dial Mode indicator LED	Scroll up / Down
Lighting Brightness (Default)	Green	( / ) Adjust the keyboard's brightness
Zoom	Red	( / ) Zoom in / out
Switch Apps	Blue	( / ) Switch between apps (alt + tab / alt + shift + tab)
Track Jogging	Yellow	Fast forward or rewind media


**Out-of-the-box settings only.*

 Other Razer Command Dial modes can be enabled and customized via the Razer Synapse app.



MULTI-FUNCTION ROLLER*



Volume up



Volume down



Mute / Unmute
volume



Press

AI PROMPT MASTER


Invoke AI
Prompt Master



Press

i Requires Razer Synapse.

LOW BATTERY NOTIFICATION



 10%
LOW BATTERY
(Blinking red)

i This notification will repeat until the battery is drained or the keyboard is charged.

BATTERY LIFE / STATUS BUTTON

Activating / Deactivating Power Saving Mode




Press and hold for 3s

i In Power Saving Mode, the keyboard conserves battery by reducing its polling rate, turning off

the keyboard lighting, and pausing Synapse connectivity.

Checking the battery level




KEYBOARD FUNCTIONS *

Key	Function
F1 / F2 ( / )	Decrease or increase the screen brightness.
F3 ()	Open Task View (Windows) or Mission Control (macOS) to manage all open windows and desktops.
F4 ()	Search for apps, files, documents, and settings.
F5 ()	Open Dictation to convert spoken words into text.
F6 ()	Open the Emoji panel (Windows) or Character Viewer (macOS) to insert emojis, GIFs, and symbols into your text.
F7 ()	Display the context menu of a selected item.
F8 ()	Launch the Calculator app.
F9 ()	Mute or unmute the microphone.
F10 ()	Disable the Windows key, alt + tab, and alt + F4 functions (customizable via Razer Synapse).
F11 / F12 ( / )	Adjust the keyboard's brightness.
fn + pause ()	Suspend all operating system activities and conserve power.


**Out-of-the-box settings only.*

*** Function may vary per operating system.*

CHROMA EFFECTS



Hotkey	Chroma effect
fn + ctrl + 1	 Off
fn + ctrl + 2	 Static*
fn + ctrl + 3	 Breathing*
fn + ctrl + 4	 Spectrum cycling
fn + ctrl + 5	 Wave**

Hotkey	Chroma effect
fn + ctrl + 6	 Reactive*
fn + ctrl + 7	 Starlight*
fn + ctrl + 8	 Ripple*
fn + ctrl + 9	 Wheel**
fn + ctrl + 0	 Fire

**Press again to change color.*

***Press again to change direction.*



Use the Razer Synapse app to customize your keyboard's lighting effects and access other advanced features available on your keyboard.

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Razer RZ03-0544, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for support.

Keep the keyboard and all its parts and accessories out of the reach of small children to avoid accidents and/or injuries.

Don't take apart the device, and do not attempt to operate it under abnormal current loads. Doing so will void your warranty.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device to let the temperature stabilize to an optimal level.

COMFORT

Research has shown that long periods of repetitive motion, improper positioning of your computer peripherals, incorrect body position, and poor habits may be associated with physical discomfort and injury to nerves, tendons, and muscles. Below are some guidelines to avoid injury and ensure optimum comfort while using your Razer RZ03-0544.

1. Position your keyboard and monitor directly in front of you with your mouse next to it. Place your elbows next to your side, not too far away, and your keyboard within easy reach.
2. Adjust the height of your chair and table so that the keyboard and mouse are at or below elbow height.
3. Keep your feet well supported, posture straight, and your shoulders relaxed.
4. During gameplay, relax your wrist and keep it straight. If you do the same tasks with your hands repeatedly, try not to bend, extend or twist your hands for long periods.
5. Don't rest your wrists on hard surfaces for long periods.

6. Customize the keys on your keyboard to suit your gaming style and minimize repetitive or awkward motions.
7. Don't sit in the same position all day. Get up, step away from your desk, and do exercises to stretch your arms, shoulders, neck, and legs.

If you should experience any physical discomfort while using your keyboard, such as pain, numbness, or tingling in your hands, wrists, elbows, shoulders, neck or back, please consult a qualified medical doctor immediately.

MAINTENANCE AND USE

The Razer RZ03-0544 requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you unplug and switch off the device from the computer and clean it using a soft cloth or cotton swab to prevent dirt buildup. Don't use soap or harsh cleaning agents.

BATTERY WARNING

The Razer RZ03-0544 contains a Li-ion rechargeable battery. In general, the life expectancy of such batteries is dependent upon usage. If you suspect that the Li-ion rechargeable battery inside the Razer RZ03-0544 may be drained (has a low charge), try charging it.

Caution: Don't open, mutilate, or expose to conducting materials (metal), moisture, liquid, fire, or heat. Doing so may cause batteries to leak or explode, resulting in personal injury. Battery life varies with usage.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners.

Windows and the Windows logo are trademarks of the Microsoft group of companies.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Razer is under license.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer RZ03-0544 (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://www.razer.com/warranty).

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

FCC Statement

15.105

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

15.19

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada Statement

RSS-Gen(P23):

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1) L'appareil ne doit pas produire de brouillage;

2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

Hereby, Razer Inc. 9 Pasteur. Irvine. CA 92618, USA declares that the radio equipment type Wireless Keyboard RZ03-0544 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: razer.com/legal/compliance.

2.4G equipment

- Operating frequency range: 2402-2480MHz
- Maximum out power(E.I.R.P): 5.27 dBm (3.37 mW), 2.4G SRD
- Maximum out power(E.I.R.P): 5.41 dBm (3.48 mW), 1Mbps, BLE
5.36 dBm (3.44 mW), 2Mbps, BLE