



GAMING HEADSET


RAZER RZ04-0542

WIRELESS DONGLE (RC30-0542)

IMPORTANT PRODUCT INFORMATION GUIDE


WHAT'S INSIDE

- Razer RZ04-0542




- A. Adjustable padded headband
- B. Hybrid fabric and leatherette memory foam cushions
- C. Mic mute toggle
- D. Volume control
- E. Razer SmartSwitch / Power button
 - 2.4GHz Mode
 - Bluetooth® Mode
- F. USB Type C connector
- G. Microphone port
- H. Status indicator
- I. Mic sidetone control


- USB Type C Razer™ HyperSpeed Wireless Dongle




- Detachable Razer™ HyperClear Cardioid 9.9mm Mic



- USB Type A to Type C cable



- Type A to Type C adapter cable



- Important Product Information Guide

WHAT'S NEEDED

PRODUCT REQUIREMENTS

- Devices with Bluetooth audio capability or USB Type C/Type A port


RAZER SYNAPSE REQUIREMENTS

- Windows 10 64-bit (or higher)
- Internet connection for app installation

RAZER AUDIO APP REQUIREMENTS

- iOS 12 / Android 8.1 Oreo (or higher)
- Internet connection for app installation

LET'S GET YOU COVERED





*Your product's serial
number can be found here.*



Register your product and score exclusive benefits
[razerid.razer.com/warranty](https://www.razerid.razer.com/warranty)

GETTING STARTED


CHARGE YOUR HEADSET



Charging Status	Status Indicator
Full	Static Green
High	Blinking Green
Mid	Blinking Yellow
Low	Blinking Red


i For best results, connect your Razer BlackShark V3 X HyperSpeed directly to your computer's USB port using the provided cable. A depleted battery will be fully charged in approximately 4 hours.

POWER YOUR HEADSET ON/OFF



CONNECT TO YOUR DEVICE


WIRED MODE





i Install Razer Synapse when prompted or download the installer from [razer.com/synapse](https://www.razer.com/synapse).


2.4GHz MODE

①



②







Set Up For PC

Make sure to set the Razer BlackShark V3 X HyperSpeed as your PC's default input and output device.

Wired Mode



2.4GHz Mode



Personalize your PC experience

Use the Razer Synapse app to customize your headset's EQ, enable audio enhancements, and fine-tune other advanced features. Install Razer Synapse when prompted, or download the installer from [razer.com/synapse](https://www.razer.com/synapse)

Activate 7.1 Surround Sound*


Experience accurate positional sound that's specifically designed for games, movies, and music.

1. Download the 7.1 Surround Sound software from [razer.com/7.1-surround-sound](https://www.razer.com/7.1-surround-sound)
2. Register your product at razerid.razer.com/products to get your activation code sent to your email.


**Only available on Windows 10 64-bit (or higher)*

BLUETOOTH® MODE


1



2




3



Search for the headset on your Bluetooth device


4




i If pairing times out, follow the next procedure to reinitiate pairing.

Reactivating Bluetooth Pairing Mode



①



②




3



Search for the headset on your Bluetooth device

4



Set Up For Mobile


Download the Razer Audio App to customize your headset's EQ settings, auto shutoff feature, gaming mode, and much more — anytime, anywhere.



Razer Audio



OR




RZR.TO/AUDAPP
(For China only)


1. Download the mobile app on your mobile device.
2. Launch the app and follow the onscreen instructions.

i When using the Razer Audio app, ensure the headset is connected to your mobile device via Bluetooth.

PAIRED TO BOTH WIRELESS MODES



SWITCH BETWEEN WIRELESS MODES




i To use the SmartSwitch function, the headset must be connected to both wireless modes.


USING YOUR RAZER BLACKSHARK V3 X HYPERSPEED

RAZER HYPERCLEAR CARDIOID MIC


PLUG IN THE MIC




PROPER MIC PLACEMENT




SET THE MIC TO MUTE/UNMUTE




CHANGE THE MICROPHONE SIDETONE LEVEL



CHANGE THE VOLUME




BLUETOOTH CALL FUNCTION REFERENCE



Action	Call Status	Effect
Single press	Incoming call	Accept an incoming call
	Active call	End the current call
	Active primary call and incoming secondary call	Put a call on hold and accept an incoming call
	Active primary call and	End call and swap to on-hold call

	secondary call on hold	
	Incoming call	Reject incoming call
Double press	Active primary call and incoming secondary call	Reject incoming secondary call
	Active primary call and secondary call on hold	Switch between calls

ADJUST FOR COMFORT



i Gently stretch the headbands before wearing the headset but do not overstretch it to avoid permanent damage.

Find out more about your gaming-grade headset at support.razer.com

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer BlackShark V3 X HyperSpeed, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for assistance.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

We recommend stretching the headset gently apart before placing them over your head to minimize headband stress. However, please avoid overstretching the headset beyond its technical limits.

The device isolates external ambient sounds even at low volumes, resulting in lowered awareness of your external surroundings. Please remove the device when engaging in any activities that requires active awareness of your surroundings.

Listening to excessively loud volumes over extended periods of time can damage your hearing. Furthermore, legislation of certain countries permits a maximum sound level of 86dB to affect your hearing for 8 hours a day. We therefore recommend that you reduce the volume to a comfortable level when listening for prolonged periods of time. Please, take good care of your hearing.

MAINTENANCE AND USE

The Razer BlackShark V3 X HyperSpeed requires minimum maintenance to keep it in optimum condition. Once a month we recommend you clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. or affiliated companies in the United States and other countries. All other trademarks are the property of their respective owners.

Android, Google, Google Logo, Google Play, and the Google Play logo are trademarks of Google LLC.

Apple, the Apple logo, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Copyright © 2003-2023 by Bluetooth SIG, Inc. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent, or other intellectual property right. The Razer BlackShark V3 X HyperSpeed (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://www.razer.com/warranty).

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

RF exposure (SAR): The SAR limit of Europe is 2.0 W/kg. The device can safely be used with a distance of 0 mm to the human body. The maximum SAR test value for this device is 0.02 W/kg.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device has been tested to comply with FCC Specific Absorption Rate (SAR) compliance. The highest reported SAR level for usage near the head (0mm) is 0.011 W/kg.

This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes :

- 1) L' appareil ne doit pas produire de brouillage;
- 2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

"This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of **0mm** between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de **0mm** entre le radiateur et votre corps."

Declaration of Conformity


Hereby, Razer Inc. 9 Pasteur. Irvine. CA 92618, USA declares that the radio equipment type g Gaming Headset RZ04-0542/ WIRELESS DONGLE (RC30-0542) is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: [razer.com/legal/compliance](https://www.razer.com/legal/compliance)

Gaming Headset:

- Radio Frequency: 2.4 GHz SRD/Bluetooth
- Operating frequency: 2402-2480MHz
- Max Output power: $\leq 17\text{dBm}$

Wireless Dongle:

- Radio Frequency: 2.4 GHz SRD
- Operating frequency: 2402-2480MHz
- Max Output power: $\leq 15\text{dBm}$



ENGLISH

The power delivered by the charger shall be between min 2.5 Watts required by the radio equipment, and max 15 Watts in order to achieve the maximum charging speed.

FRANÇAIS

La puissance fournie par le chargeur doit être entre, au minimum, 2.5 Watts requis par l'équipement radioélectrique et, au maximum, 15 Watts pour atteindre la vitesse de chargement maximale

DEUTSCH

Die Leistung des Ladegeräts muss von einer von der Funkanlage benötigten Mindestleistung von 2.5 Watt bis zu einer zum Erreichen der maximalen Ladegeschwindigkeit benötigten Höchstleistung von 15 Watt reichen.

ESPAÑOL

La potencia suministrada por el cargador debe ser de entre un mínimo de 2.5 vatios requeridos por el equipo radioeléctrico y un máximo de 15 vatios a fin de alcanzar la máxima velocidad de carga

PORTUGUÊS

A potência fornecida pelo carregador tem de se situar entre um mínimo de 2.5 Watts exigidos pelo equipamento de rádio e um máximo de 15 Watts para que a velocidade de carregamento máxima seja atingida

POLSKI

Moc dostarczana przez ładowarkę musi wynosić między minimalnie 2.5 W wymaganych przez urządzenie radiowe a maksymalnie 15 W, aby osiągnąć maksymalną prędkość ładowania