



RAZER GAMING SPEAKERS

SYSTEM MODEL:RZ05-0474

GAMING SPEAKERS MODEL:RZ05-0474

SUBWOOFER MODEL:RC30-474W


REMOTE CONTROL MODEL:RC30-474C

USER MANUAL

20-SEP-2022


WHAT'S INSIDE

- Razer RZ05-0474




- A. Rear-facing lighting powered by Razer Chroma™ RGB
- B. USB Type C port
- C. Power port
- D. Left speaker port
- E. Left speaker connector

- Subwoofer




- F. Rear-facing bass port
- G. Power port
- H. Subwoofer pairing button
- I. Subwoofer status indicator

- Razer Wireless Control Pod




- J. Power button / Media control knob
- K. Source button
- L. Speaker status indicator
- M. Bottom cover
- N. Battery compartment
- O. Bluetooth pairing button

- USB Type A to USB Type C cable




- Regional power cords*



**May vary for specific regions.*

- 2 x AAA batteries
- Important Product Information Guide

WHAT'S NEEDED




**Required for the Razer Wireless Control Pod.*

LET'S GET YOU COVERED



Register your product and score exclusive benefits


razerid.razer.com/warranty




Your product's serial number can be found here.

SETTING UP YOUR RAZER RZ05-0474


1.




2.



3.



4.




Caution: The included AAA batteries are non-rechargeable. Dispose of batteries in accordance with your local environmental laws. For your safety, use only lithium or alkaline batteries.

CONNECTING TO YOUR GAMING SPEAKERS

A. VIA PC MODE

1.




2.

**PRESS AND
HOLD**


3s



**POWER ON
(Solid white)**




**PC MODE
(Solid green)**



**CONNECTED TO
SPEAKERS
(Solid green)**


3.




When using the gaming speakers with compatible devices, make sure to set the Razer RZ05-0474 as its default output device (if applicable).

B. VIA BLUETOOTH MODE

1.



2.




! *Instructions are for first-time pairing only. When connecting to your gaming speakers, remember to keep them within 1 meter of your mobile device. Once paired, your gaming speakers will automatically reconnect to your mobile device whenever you switch to Bluetooth mode.*

USING YOUR GAMING SPEAKERS


POWER ON/OFF



SWITCHING BETWEEN AUDIO SOURCES



REACTIVATING BLUETOOTH PAIRING MODE (FOR NEW DEVICES)



i Alternatively, you can reactivate Bluetooth pairing mode within 20 seconds of powering on the gaming speakers by pressing and holding the Bluetooth pairing button for 4 seconds.

2.



PERSONALIZE YOUR EXPERIENCE

RAZER SYNAPSE (PC)

Use the Razer Synapse app to switch between audio sources, customize your speakers' lighting, personalize an EQ preset, and adjust other advanced features for a truly immersive listening experience.

i Only available on Windows® 10 64-bit (or higher). Install Razer Synapse when prompted or download the installer from razer.com/synapse.

Find out more about your brand-new PC gaming speakers at support.razer.com

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Razer RZ05-0474, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for assistance.

Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.

Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device to let the temperature stabilize to an optimal level.

Listening to excessively loud volumes over extended periods can damage your hearing. Furthermore, legislation of certain countries permits a maximum sound level of 86db to affect your hearing for 8 hours a day. We, therefore, recommend that you reduce the volume to a comfortable level when listening for prolonged periods. Please, take good care of your hearing.

MAINTENANCE AND USE

The Razer RZ05-0474 requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you clean each speaker and the subwoofer using a soft cloth or cotton swab to prevent dirt buildup. Don't use soap or harsh cleaning agents.

REGULATORY

FCC COMPLIANCE STATEMENTS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

SUPPLIER'S DECLARATION OF CONFORMITY

Unique Identifier

Trade Name: RAZER

Model No.: RZ05-0474 / RC30-474W / RC30-474C

Responsible Party – U.S. Contact Information

US Company Name: Razer Inc.

Address: 9 Pasteur, Suite 100 Irvine California 92618 United States

Telephone number or internet contact information: www.razer.com

ISED COMPLIANCE STATEMENTS

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur et votre corps.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2022 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. or affiliated companies in the United States and other countries. All other trademarks are the property of their respective owners.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Razer is under license.

Windows and the Windows logo are trademarks of the Microsoft group of companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer RZ05-0474 (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.