





GAMING CONTROLLER RZ06-0558

WIRELESS DONGLE RC30-0558

IMPORTANT PRODUCT INFORMATION GUIDE

WHAT'S INSIDE

- Gaming Controller & Wireless Dongle




- A. Type C port
- B. Touchpad (touchpad button)
- C. Create button
- D. Razer Mecha-Tactile PBT 8-way floating D-pad
- E. Status indicator
- F. Options button
- G. Razer Mecha-Tactile PBT action buttons
- H. TMR analog thumbsticks with replaceable caps
- I. PS button
- J. Function button

- K. Mic mute button
- L. 3.5 mm headset jack
- M. Razer Pro HyperTriggers (L2/R2)
- N. Bumpers (L1/R1)
- O. Multi-function claw grip bumpers (M1/M2)
- P. Trigger stop switches
- Q. PC/PS mode switch
- R. Wireless/wired mode switch
- S. Back button rubber plugs
- T. Removable multi-function mouse click back buttons (M3/M4/M5/M6)


- Razer HyperSpeed Wireless 2.4GHz USB Type A dongle




- USB Type A to USB Type C cable




- 2 Replacement thumbstick caps (tall concave/short convex)



- 4 Back button rubber inserts



- Screwdriver



- Carrying Case



- Important Product Information Guide

WHAT'S NEEDED

PRODUCT REQUIREMENTS


- PlayStation®5 or PC*
- USB Type A port

RAZER SYNAPSE REQUIREMENTS

- Windows® 11 64-bit (or higher)
- Internet connection for app installation

**Razer has validated the operation between this controller and the PlayStation®5 console. PC compatibility not tested nor endorsed by Sony Interactive Entertainment.*

LET'S GET YOU COVERED



Your product's serial number can be found here.




Register your product and score exclusive benefits
razerid.razer.com/warranty

Got a question? Ask the Razer Support Team at support.razer.com


GETTING STARTED

CHARGE YOUR CONTROLLER



i Only use the included USB Type A to USB Type C cable to charge the Gaming Controller & Wireless Dongle. For best results, please fully charge the controller before using it for the first time. A depleted battery will be fully charged in approximately 3 hours.

POWER YOUR CONTROLLER ON/OFF




CONNECT TO YOUR DEVICE


2.4GHz MODE

For PS5


1



2




3




For PC


1



2




3




WIRED MODE

For PS5


1



2




3




On
(Static White)

For PC


1



2



3




On
(Static White)

i


Install Razer Synapse when prompted, or download the installer from razer.com/synapse

USING THE CONTROLLER

UTILIZING THE TRIGGER STOP SWITCHES




Locked



Unlocked

CHANGING THE REPLACEABLE THUMBSTICK CAPS



USING THE FUNCTION BUTTON COMMANDS


Input	Function
 +  Hold Press	Volume Up
 +  Hold Press	Volume Down
 +  Hold Press	Switch to Profile 
 +  Hold Press	Switch to Profile 

 +  Hold Press	Switch to Profile 
 +  Hold Press	Switch to Profile 


REASSIGNING THE MULTI-FUNCTION (M1-M6) MAPPING

By default, the M1-M6 bumpers and buttons are unmapped. Use the steps below or Razer Synapse to remap them.

1. Hold down the Function button and the Multi-Function bumper/button you want to remap.




2. Press the button you want to assign to it.



USING THE SENSITIVITY CLUTCH FUNCTION


Holding down the assigned button will lower the chosen analog stick's sensitivity by up to 50%.




 The sensitivity clutch function can be assigned and customized through Razer Synapse.

REMOVING THE MULTI-FUNCTION BACK BUTTON


1




2




3




4



5



6



Find out more about your gaming-grade controller at support.razer.com

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using the Gaming Controller & Wireless Dongle, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for support. Do not attempt to service or fix the device yourself at any time.

Do not take apart the device, and do not attempt to operate it under abnormal current loads. Doing so will void your warranty.

Keep the controller and all its parts and accessories out of the reach of small children to avoid accidents and/or injuries.

Keep the device and its components away from liquid, humidity or moisture. Operate the device and its components only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and switch off the device in order to let the temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Gaming Controller & Wireless Dongle requires minimum maintenance to keep it in optimum condition. Once a month, we recommend that you unplug the device and clean it using a soft cloth or cotton to prevent dirt buildup. Do not use soap or harsh cleaning agents.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers." and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries.

Windows and the Windows logo are trademarks of the Microsoft group of companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Gaming Controller & Wireless Dongle (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device has been tested to comply with FCC Specific Absorption Rate (SAR) compliance. The highest reported SAR level for usage near the head (0mm) is 0.011 W/kg.

This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes :

- 1) L' appareil ne doit pas produire de brouillage;
- 2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

"This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 0mm between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 0mm entre le radiateur et votre corps."

RF exposure (SAR): The SAR limit of Europe is 2.0 W/kg. The device can safely be used with a distance of 0 mm to the human body. The maximum SAR test value for this device is 0.02 W/kg.

CE Statement of Compliance with EU directive

ENGLISH

STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Hereby, Razer (Europe) GmbH, declares that this Gaming Controller Model: RZ06-0558 and Wireless Dongle Model: RC30-0558 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and 2015/863/EU.

The full Declaration of Conformity is accessible via the following:

Internet address: razer.com/legal/compliance



Li-ion

This equipment is for home use, and has acquired electromagnetic conformity registration, so it can be used not only in residential areas, but also other areas.

BATTERY INFO


Risk of fire or explosion or defeat the safeguard of equipment if the battery is replaced by an incorrect type. Replace only with the same or equivalent type. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion. High or low extreme temperatures or low air pressure at high altitude that the battery can be subjected to during use, storage or transportation. Leaving the battery in an extremely high temperature and/or low air pressure surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.



EU PRODUCT AND BATTERY DISPOSAL INFORMATION

BATTERY WARNING

The Gaming Controller contains a Li-ion rechargeable battery. In general, the life expectancy of such batteries is dependent upon usage. If you suspect that the Li-ion rechargeable battery inside the Gaming Controller may be drained (has a low charge), try charging it.



ENGLISH

The power delivered by the charger must be between min 4.5 Watts required by the radio equipment, and max 15 Watts in order to achieve the maximum charging speed.

Gaming Controller:

Radio Frequency: 2.4 GHz SRD

Operating Frequency: 2402-2480 MHz

Max Output power: $\leq 12\text{dBm}$

SW version: V1.00.00.00

Radio Frequency: Bluetooth LE

Operating Frequency: 2402-2480MHz

Max Output power: $\leq 9\text{dBm}$

SW version: V1.00.00.00

Wireless Dongle:

Radio Frequency: 2.4 GHz SRD

Operating Frequency: 2402-2480 MHz

Max Output power: $\leq 14\text{dBm}$

SW version: V1.00.00.00