

Figure 7
Inside of the EUT



Figure 8
Inside of the EUT



Figure 9
Inside of the EUT



Figure 10
Frontside of the LCD Panel



Figure 11
Component side of the PCB



Figure 12
Component side of the PCB




Figure 13
Frontside of the Control Board



Figure 14
Backside of the Control Board




Figure 15
Component side of the PCB




Figure 16
Component side of the PCB




Figure 17
Wifi Card of the EUT



Figure 18
Wifi Card of the EUT



Figure 19
Wifi Card of the EUT



Figure 20
HDD of the EUT



Figure 21
HDD of the EUT




Figure 22
CPU of the EUT




Figure 23
Speaker of the EUT




Figure 24
Speaker of the EUT



Figure 25
Battery of the EUT



Figure 26
Battery of the EUT



Figure 27
Battery of the EUT



Figure 28
RC30-0099, Power Adapter



Figure 29
RC30-0099, Power Adapter



Figure 30
RC30-0083, Power Adapter



Figure 31
RC30-0083, Power Adapter

