


tomtom
GO
Quick Start Guide





TomTom **GO** Quick Start Guide

Content

Installation	4
Unpacking	4
Your TomTom GO	5
Assembly	6
Switching on for the first time	7
Starting up	7
Using TomTom GO	7
How to plan your first route	8
Helping with your trip	10
What's on the screen?	11
Finding alternative routes	12
Advanced planning	13
Preferences	14
Use night colors	14
Manage POI	15
Hide POI	15
Change Home location	15
More information	16
TomTom PLUS	16
General information	16
Safety and Regulatory Information	17

Installation

Unpacking

Unpack your TomTom GO box and identify the contents. The model number of your TomTom GO can be found on the bottom of the device itself. You should have:

- **(1) TomTom GO.** Its main features are a touch-sensitive LCD screen, a power (On/Off) button, a release button (for removing TomTom GO from its cradle) and a Secure Digital (SD) memory card slot.
- A **(2) pre-installed SD card.**
- **The component parts of a suction-mount (3/4)** cradle, for attaching to your windshield.
- A **(5) DC power lead**, with 12V cigarette lighter adapter. This is the main power source for the TomTom GO when it's in your vehicle.
- An **(6) installation diagram**, showing how to assemble the cradle, how to fix it to your windshield and how to insert TomTom GO.

- A **(7) carry case**, for storing TomTom GO when it's not in your vehicle.
- A **(8) USB data cable** for connecting TomTom GO to a Windows PC or Mac.
- A **(9) PC and Mac compatible CD** containing documentation and optional extras.
- A **(10) Product Code Card** for support, future map upgrades and more.
- This **(11) Quick Start Guide.**
- An **(12) AC adaptor**, included for you to charge and work with TomTom GO even when it's not in your vehicle. Note that this comes with several international pin adaptors, for use anywhere in the world. When you use this adaptor, please make sure it is cooled by placing it in a ventilated area.



1



2



3



4



5



6



7



8



9



10




11



12

Installation



Your TomTom GO

1. Touchscreen
2. SD card slot
3. Release button
4. On/Off button
5. Charging LED
6. Speaker
7. AC-connector
8. USB-connector
9. Docking connector

NOTE: Do not expose TomTom GO to high or low temperatures. We recommend that you do not leave TomTom GO in direct sunlight for long periods or in an unattended car on sunny days. High or low temperatures can cause permanent damage. Do not attempt to service TomTom GO yourself! Do not open, puncture or disassemble it. Doing so may be dangerous and will invalidate your warranty. Do not leave your TomTom GO in your glove box when driving.

Installation

Assembly

1. Assemble the suction-mount cradle as shown in the installation poster.
2. Plug the small plug end of the DC power lead into the socket on the back of the cradle. Plug the other end into your vehicle's 12V (cigarette lighter) socket.
3. Ease TomTom GO onto its cradle by locating its front edge first and then pushing back firmly until you hear a click. You'll feel TomTom GO lock into place. The green LED on TomTom GO's front panel will light up if the cradle is also connected to your vehicle's 12V socket.
4. Clean the inside of your windshield (or side window), to remove any dust and grease. Place the cradle in a suitable location on your windshield and push the black plastic lever to the right, fixing the cradle in position.

NOTE: Some newer vehicles may have a heat reflective shield embedded in the windshield. In some cases this can prevent proper GPS signal reception. If this turns out to be a problem in your vehicle, you will need to purchase and install the TomTom External Antenna Kit (available as an accessory).

Tip: You don't have to use the cradle if you don't want to. If necessary, TomTom GO can be positioned on its own anywhere that's convenient, provided that it's safely secured.

Under normal travelling conditions, the suction mount is sufficient to hold the cradle

in position. Note that suction may be lost if left overnight, due to condensation and low temperature. For this reason, and for security, we recommend removing both the suction mount cradle and TomTom GO when leaving your vehicle overnight. To remove the cradle, pull the suction mount lever to the left. If the cradle still doesn't detach from your windshield, tug gently on the clear plastic tab at the edge of the suction mount, to break the vacuum seal.

Tip: To activate your 12V socket, you may need to set your ignition key in an 'Accessories' position. Please consult your vehicle handbook. Also, TomTom GO contains a rechargeable battery which can be used for up to 4 hours without charging. For short trips it may be possible to do without the DC power lead for simpler and neater operation.

To adjust the angle of TomTom GO, loosen the adjustable knobs on the cradle and then turn it gently. In addition to tilting the cradle up and down and from side to side, you can also rotate TomTom GO in the cradle, from left to right, $\pm 45^\circ$. When you're happy, tighten up the knobs again.

Tip: After using TomTom GO, remove it from the cradle by pressing the release button while tipping the unit forward gently. Put it in the supplied bag. If you want to clean it, use a soft, dry cloth. Do not use water or a solvent.

Switching on for the first time


Starting up

1. Refer to your installation diagram for setup instructions.
2. Follow the on-screen instructions, using your finger on the touchscreen to select your preferences.

Using TomTom GO


Note: Your TomTom GO does not transmit your location, so others cannot use it to track you while driving.

TomTom GO starts by displaying the navigation view. The screen will appear in black and white until your TomTom GO locates your current position. Once this is done, the navigation view is shown in full color. In future, your position will be found much faster, normally within a few seconds. Everything on TomTom GO can be accomplished easily using just your finger on the touchscreen. Note: you can bring up the main options menu by tapping your finger somewhere in the middle of the screen.



As with many of the menus in TomTom GO, there are more options than can be shown on one screen. Try tapping on ► a few times, to cycle through all the different things you can do.

How to plan your first route



Tip: Don't worry if some of the icons are 'greyed out', this just indicates that these menu options aren't available yet. E.g. as you haven't yet planned a route then 'Find alternative...', 'View route' and 'Clear route' are all greyed out

How to plan your first route

1. Move outside, if you haven't already done so, so that the GPS hardware can locate your position. This may take some time, and will happen more quickly if you remain in one place. The screen displays your current position on its map, represented in a '3D' navigation view, from a driver's perspective. When you start moving, the navigation view will match the streets outside as you would see them through your windshield

Your position (and direction) is indicated by the  icon.

2. Bring up the main menu as explained previously. Use  a few times to browse through all the different things you can do, then choose '**Navigate to...**'  to start planning your first route.

Remember that  always means that there's more to see on the next page, in this case extra ways of choosing a destination.

3. Choose '**Address**' . You'll see a standard keyboard, used for entering place names (e.g. towns, streets and favorite locations). Above the keyboard is a small browser window in which your TomTom GO will present locations from its database.

How to plan your first route

- The best way to see how your TomTom GO works is to use it for real, so think of the address that you want to visit and **enter the first few letters** of the city, town or village. Be as specific as possible. As you type, the letters are compared to the built-in list of possible names and any matches appear in the browser window.

Quick-matching a town name. Use  and  to scroll through other possible matches. If you make a mistake, use  to delete the last letter entered.



- When you see the name of the place you want, select it by tapping on the name. A new browser window is now shown, this time with the prompt '**Street:**' at the top. Again, start entering the road name of your destination, selecting it when the full name is shown among the matches

Quick-matching a street name. In cases where there is more than one road of the same name, additional information is displayed to help you choose the correct location





- A third and final keyboard and browser are shown, this time for you to select a house number. For some roads (such as those that don't have house numbers), you'll be asked to select a particular 'Crossing:' (i.e. an intersection). Select a crossing, or enter the house number and then choose '**Done**'.

If you'd rather pick a crossing than a house number, just select the 'Crossing' button.



How to plan your first route



7. The fastest route from your current position to your destination is then calculated. This should only take a few seconds and its progress is shown on the screen. When done, a summary is shown, on a suitably scaled map.

*Studying this summary can be useful for you to get a feel for your trip's scope and to check if the route includes roads that you'd rather avoid (in which case, see '**Finding alternative routes**', below).*

8. Select '**Done**' and you'll find yourself back at the main navigation view, but with the route now clearly colored in for you.

White arrowheads show the direction you need to move along the current road and a specially-shaped green arrow shows what to do at the next turn or intersection

Helping with your trip

That's the planning all done, so simply buckle your seat belt and drive. As you approach a specific turn in the calculated route, your chosen voice will tell you what to do. For example, "In 100 yards, turn left", followed by "Turn left", without you having to take your eyes off the road. As you travel, following the voice instructions, you'll notice that the navigation view is updated constantly, always showing coming roads and intersections and presenting the best route to you.

Don't worry if you miss a turn or drive down the wrong road. A new fastest route will be calculated automatically, based on your new position and direction of travel. Wherever you go, it will always give you instructions that will take you to your chosen destination.

What's on the screen?


Much of the information on the main navigation view is configurable (see the **'Preferences'** chapter for details). By default, you'll see something like the illustration at the right.

If you miss a voice instruction, tap on the turn instruction in the bottom left hand corner to generate a new one. And if you'd like to view the route summary again, tap anywhere in the trip information panel in the bottom right hand corner.

Most of the time, the voice and turn instructions are all you need to navigate successfully, which means never having to take your eyes off the road. At complicated intersections, where simple instructions aren't adequate, the navigation view comes into its own. A quick comparison between the screen and the world in front of you should be all you need.

Tip: No instruction is shown or spoken at intersections which require no action. In towns and cities especially, don't be concerned that you are passing side-roads and driving over crossroads without any instruction

What's on the screen?



- 1 Your next turn instruction.
- 2 The name of the next street to turn onto.
- 3 Configurable trip information including arrival time, time to destination and distance to destination.
- 4 Your current GPS position.
- 5 'Zoom out' and 'Zoom in' buttons.
- 6 'Next highway' indicator, if applicable. See 'Name preferences' in the manual on CD, if you want to turn this off.
- 7 A 'phone-style' signal indicator to give an idea of how good or bad the GPS reception is in your current location. The more bars, the better.

Finding alternative routes



Finding alternative routes

Maybe a route has been planned that you're not happy with? Perhaps you have been routed through a busy area? Have you spotted roadwork up ahead? Or perhaps you really wanted to go 'via' one particular location? In each of these cases, **'Find alternative...'**  can help you. Again, you'll see it on the main menu, right next to **'Navigate to...'**

Which **'Find alternative'** option you go for depends on why you're dissatisfied with the first route.

Choose **'Travel via...'**  if you want to make sure the planned route goes past one particular location, perhaps to pick up or drop someone off. If you spot signs of trouble, choose **'Avoid roadblock'** . Or if you want to avoid a particular busy road intersection, perhaps because it's a known traffic black spot, choose **'Avoid part of route'** . Finally, if you want an alternative route because you simply don't like the original, choose **'Calculate alternative'** .

***Tip:** If you want to include more than a single 'via' location in your trip, use the comprehensive 'Itineraries' feature instead, described in the manual on CD.*

Advanced planning


Advanced planning

Although navigating from your current position is the function that you'll use most often, there may be times when you want to plan ahead. Choosing **'Advanced planning'**  on the main menu lets you look at the best route and trip time between any two given locations or get directions that will help someone else get to your current position.


Tip: You may need to use  in order to see the **'Advanced planning'** icon.

If you'd like this choice every time you navigate, or if you'd like to change the default setting, see **'Planning preferences'** in the **'Change preferences'** menu.

Rather than use your GPS position, with **'Advanced planning'** you choose your departure location using either an address, a Point Of Interest, a favorite location, for example. You then pick a destination in the same way and finally choose a planning option (fastest, shortest, walking, etc.)



Preferences



The default night colors, designed not to affect your night vision.

Preferences

You can personalize much of the look and feel of your TomTom system by using the main menu option **'Change preferences'** . Use  to cycle through the different pages of preferences. Here are some of the most important ones (you'll find the full set in the manual on CD).

Tip: The icons shown for some preferences will change, depending on the setting the preference is currently on. For example, choosing **'Turn off sound'**  disables the voice instructions. Once disabled, the option and icon change to **'Turn on sound'** , reflecting the action to take when it is next selected.

Use night colors

Bright colors are normally used in the maps so that you can see them clearly even in sunlight. When it is dark outside, you may want to use the preference **'Use night colors'** , to show the map in (by default) dark and subdued colors that will not interfere with your night vision. You can use the preference **'Use day colors'**  to revert to the original color scheme.

Preferences

Manage POI

POI is an abbreviation you'll see a lot, standing for 'Point Of Interest'. Dozens of categories of POIs are built-in, from airports to gas stations, from restaurants to theaters. Most importantly, POIs can be used as destinations, can be shown on the map and can even warn you of their proximity (for example, looking for a parking garage or gas station while driving in a strange city).

You can choose which Points Of Interest categories you're interested in by selecting the option **'Enable/Disable POI'** , or set up a warning (you can have as many as you like) with the option **'Warn when near POI'** .



*A typical selection of POIs from the categories selected in the **'Manage POI'** preference.*

Hide POI

Once you've spent time carefully browsing through the categories in **'Manage POI'** and have chosen the ones you need, you can hide all of them from the main navigation view in one stroke with **'Hide POI'** , and then show your preferred set again with **'Show POI'** .

Change Home location

You can set or change your 'Home' location at any time by using **'Change home location'** . You will then be able to select this quickly later as a departure or destination point.

More information

TomTom PLUS

In addition to voice-guided satellite navigation, our optional TomTom PLUS service can give you real time information on traffic congestion, helping you plan around it. In addition, there is current weather information for any location on your map, plus special downloads, including detailed city maps, extra voice files and extra POI databases. Full details of the TomTom PLUS service can be found on the CD.

*Note: To use TomTom PLUS, you need a **GPRS-ready mobile phone** with Bluetooth. If you already pick up email or browse the Internet on your phone, then it's probably already GPRS-ready; if you're not sure, ask your network provider*

More information

All the features of your TomTom GO are fully explained in the manual included on the CD.

The manual is available in UK and US English, Dutch, German, French, Italian, Spanish, Portuguese, Danish, Swedish, Finnish, Norwegian, Polish, Czech, Hungarian and Turkish.

For technical support information please visit our website at **www.tomtom.com**

Our “**Frequently Asked Questions**” (FAQs) section contains answers to all the most frequent requests from our customers, providing a quick and easy way to get the information you need. You can also access the support section of our website to find product documentation and contact details for our customer support department. We primarily supply support via email, as this allows us to explain solutions in the most effective way.

Safety and Regulatory Information

Important Safety Notices and Warnings

1. Global Positioning System

The Global Positioning System (GPS) is a satellite-based system that provides location and timing information around the globe. GPS is operated and controlled under the sole responsibility of the Government of the United States of America, who are responsible for its availability and accuracy. Any changes in GPS availability and accuracy, or in environmental conditions, may impact the operation of your TomTom GO. TomTom B.V. cannot accept any liability for the availability and accuracy of GPS.

2. Use with Care

Use of TomTom GO for navigation still means that you need to drive with due care and attention.

3. Aircraft and Hospitals

Use of devices with an antenna is prohibited on most aircraft, in many hospitals and in many other locations. TomTom GO must not be used in these environments.

4. Battery

This product uses a Lithium-Ion battery. Do not use it in a humid, wet and/or corrosive environment. Do not put, store or leave your product in or near a heat source, in a high temperature location, in strong direct sunlight, in a microwave oven or in a pressurized container, and do not expose it to temperatures over 60°C (140°F). Failure to follow these guidelines may cause the Lithium-Ion battery to leak acid, become hot, explode or ignite and cause injury

and/or damage. Do not pierce, open or disassemble the battery. If the battery leaks and you come into contact with the leaked fluids, rinse thoroughly with water and seek medical attention immediately. For safety reasons, and to prolong the lifetime of the battery, charging will not occur at low (below 0°C/32°F) or high (over 45°C/110°F) temperatures.

Temperatures: Standard operation: -10 °C to + 55 °C (GO300 and GO500), 0 °C to + 55 °C (GO700); short period storage: -20 °C to + 60 °C; long period storage: -20 °C to + 25 °C.



THE LITHIUM-ION BATTERY CONTAINED IN THE PRODUCT MUST BE RECYCLED OR DISPOSED OF PROPERLY. USE TOMTOM GO ONLY WITH THE SUPPLIED DC POWER LEAD AND AC ADAPTER FOR BATTERY CHARGING.

To recycle your TomTom GO unit, please see your local approved TomTom service centre.

FCC Information for the User

Radio and Television Interference

This equipment radiates radio frequency energy and if not used properly - that is, in strict accordance with the instructions in this manual - may cause interference to radio communications and television reception.

It has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These are designed to provide reasonable protection against harmful interference in a residential

Safety and Regulatory Information

installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation distance between the equipment and the receiver.
- If you are using the equipment with a mains adapter, plug it into an outlet which is on a different circuit from that to which the receiver is connected.
- Consult an experienced radio/TV technician for help.

Important

This equipment was tested for FCC compliance under conditions that included the use of shielded cables and connectors between it and the peripherals. It is important that you use shielded cable and connectors to reduce the possibility of causing radio and television interference. Shielded cables, suitable for the product range, can be obtained from an authorised dealer. If the user modifies the equipment or its peripherals in any way, and these modifications are not approved by TomTom, the FCC may withdraw the user's right to operate the equipment.

For customers in the USA, the following booklet prepared by the Federal Communications Commission may be of help: "How to Identify and Resolve Radio-TV Interference Problems". This booklet is available from the US Government Printing Office, Washington, DC 20402 Stock No 004-000-00345-4.

FCC Declaration of Conformity

Tested to Comply with FCC Standards for Home or Office Use.

TomTom GO has been tested to – and complies with – part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Responsible party in North America:

TomTom, Inc.

150 Baker Ave

Concord, MA 01742

Tel: 978 287 9555 option 1

Fax: 978 287 9522

Toll Free: 866 4 TOMTOM (866 4 866 866)

(The Toll Free number does not work outside of the US)

Emissions information for Canada

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

CE Marking

This equipment complies with the requirements for CE marking when used in a residential, commercial or light industrial environment.

FCC Information for the User

FCC Information for the User

The device used for this transmitter must not be co-located simultaneously operating in conjunction with any other transmitter.

Exposure to Radio Frequency Radiation

To comply with RF exposure requirements please maintain a separation distance of at least 20 cm from any part of the product.

Safety and Regulatory Information

R&TTE Directive

This equipment complies with the essential requirements of EU Directive 99/5/EC (declaration available at **www.tomtom.com**).

Diese Ausrüstung erfüllt die wesentlichen Anforderungen der EU-Richtlinie 99/5/EC (Erklärung verfügbar unter **www.tomtom.com**).

Cet équipement remplit les conditions édictées dans la Directive EC/99/5 (document disponible sur **www.tomtom.com**).

Deze apparatuur is conform de eisen van de EU-richtlijnen 99/5/EC (verklaring beschikbaar op **www.tomtom.com**).

Questa apparecchiatura soddisfa le condizioni essenziali della Direttiva Europea 99/5/EC (dichiarazione disponibile su **www.tomtom.com**).

Este equipo cumple con los requisitos esenciales de la Directiva 99/5/EC de la EU (declaración disponible en **www.tomtom.com**).

Dette udstyr overholder de grundlæggende krav i EU-direktiv 99/5/EC (erklæring herom kan findes på **www.tomtom.com**).

Denna utrustning rättar sig efter de nödvändiga krav från EU direktiv 99/5/EC (deklaration finns på **www.tomtom.com**).

This Document

Great care was taken in preparing this manual. Constant product development may mean that some information is not entirely up-to-date. The information in this document is subject to change without notice.

TomTom BV shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the performance or use of this material. This document contains information protected by copyright. No part of this document may be photocopied or reproduced in any form without prior written consent from TomTom B.V.

© 2005 TomTom BV, The Netherlands. Patents pending. All rights reserved. TomTom and the TomTom logo are registered trademarks of TomTom B.V. The Netherlands. All other trademarks are the property of their respective owners. The use of TomTom products is governed by a license agreement which is included in this package and/or the products. This license contains a limited warranty and limitation of liability. You can review the license conditions at **www.tomtom.com**

Data Source © 1984-2004 Tele Atlas North America, Inc. All rights reserved.

Canadian Data © DMTI Spatial. Portions of Canadian map data are reproduced under license from Her Majesty the Queen in Right of Canada with permission from Natural Resource Canada. Point of interest data by Info USA. Copyright 2004.



Part.no. 5D00.112

traj/3.6959



www.tomtom.com

