


1 Label Location in GXRM Module

1.1 Label diagram:



1.2 Label Location:



The Label is pasted on the backside of the board.

*****END OF APPENDIX*****