


INSTRUCTIONS

R/C SUPER POWER

1 CONTENTS/FEATURES

(Shown in fully extended mode)

- 1 Battery door
- 2 Battery door latch(2)
- 3 Battery switch
- 4 Axle lock(2)




SMART CIRCUITRY

If your vehicle gets stuck or stalled during play, a special circuit will cut power to protect it. just release the transmitter controls (reposition your vehicle if necessary), wait a few seconds, and you're ready to go again.

Transmitter

- 1 Driving controls
- 2 Antenna


NOTE: Your transmitter is equipped with a special automatic ON battery-saving feature. just turn your vehicle ON. Then push either transmitter control and you will be able to run and control your vehicle.




2 QUICK START

Please read this Owner's Manual thoroughly.

1. Start with a full charge.
2. Turn vehicle switch ON. Activate transmitter to run and control your vehicle.
3. When you're done driving, turn vehicle switch OFF. Remove all batteries for storage.



3 BASIC DRIVING



① Forward

② Reverse



③ Left Turn/Eddy

④ Right Turn/Eddy


4 COOL STUNTS

Your vehicle can do all kinds of amazing stunts...here are a few ideas to get you started. Once you start driving your vehicle, you'll realize it can perform lots of other your exciting stunts! So drive your vehicle, use your imagination, and come up with your own awesome stunts!

- ① **Wind It!** Start out with your vehicle in fully-extended mode. Push both transmitter buttons down to drive in reverse. Your vehicle will rewind into compact mode as it travels.




- ② **Tumble!** Start out push both transmitter buttons up to drive high speed forward. And then, you must push both transmitter buttons down at once. Your vehicle will have peculiar tumble action.



② Vehicle (3803-2)

1. First insert the plug of pile into the charger faucet, and then charge up the pile fully, charging it for six hours. (as illustrated).

Please use the charger and battery included for this product.



2. Unscrew the fixing screws on the cover of the battery to open it.



3. Insert the battery pack into the battery compartment and slide it into place as shown.



4. Replace the cover of the battery, and then screw down the fixing screws.



If your vehicle hits an object, the impact may cause the lock mechanism to disengage. This feature is designed to protect the vehicle components.



Be sure to turn the vehicle switch OFF before locking or unlocking the vehicle.



Don't aim your vehicle at people, animals or fragile objects.

③ Transmitter

1. Slide battery door open



2. Install one 6LR61(9V) battery with polarity (+/-) as shown inside battery compartment.



3. Replace battery door.



BATTERY SAFETY INFORMATION

- Batteries may leak fluids that can cause a chemical burn injury or ruin your toy(product). To avoid battery leakage:
- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the toy(product). Dispose of batteries safely. Do not dispose of batteries in a fire. The batteries may explode or leak.
- Never short-circuit the battery terminals.
- Use only batteries of the same or equivalent type, as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy(product) before charging.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.

Battery performance Note:

For best performance use alkaline batteries (where disposable batteries are called for). If your vehicle is supplied with standard (carbon-zinc) batteries for initial use and/or demonstration purposes, we recommend replacing them with alkaline batteries when necessary. Battery life may vary depending on battery brand.

8

SAFETY INFORMATION

Adults, this toy is recommended for children 6 years of age and older, to ensure that the child's play is both safe and fun. Please read and understand these general safety rules with the child.

- NEVER drive your vehicle on streets! They're for real cars!
- DO NOT pick up vehicle while in motion.
- Keep fingers, hair and loose clothing away from the tires and the wheel hubs while the vehicle is switched ON.
- Adult supervision is recommended when this vehicle is being operated.
- To avoid accidental operation, remove all batteries when not in use.




WARNING:

CHOKING HAZARD- Small parts
Not for children under 6 years

Do not use this toy if the batteries are not working properly. Do not use this toy if the batteries are not working properly.

Keep these instructions for future reference: they contain important information.

- 3 Wild 360 Spins an Tumble!** push one transmitter button up and the other one down. Your vehicle will do a super-cool; 360 high speed spin! And then, you must push both transmitter buttons down at once, Your vehicle will have peculiar tumble action.



- 4 Roll & Transform!** When the car is in the compact mode, push up one of the operating knobs on the controller and push down the other one. Now the car can roll at high speed in the same place. And then push any knobs on the controller to the opposite direction at once, this time the car can spring up and turn into the spread mode.



When power supply energy, you can drive your vehicle, use your imagination, and come up with your own awesome stunts!

• Flashing Function

- 1 The acrobatic car can flash automatically as per the operating direction of the remote control.
- 2 The flashing function of the intelligence flashlight can be closed automatically without receiving the direction from the remote control in order to save the power supply.

5 QUICK TIPS

- 1 When your Vehicle starts to lose power, it may lose functions or performance. It's time for a recharge. Your vehicle's running time may change depending on Your driving style.
- 2 Radio interference can make your vehicle run badly. Interference can be caused by other R/C vehicles running on the same frequency; electrical wires; large buildings; or CB radios. Try to stay away from these!
- 3 Point your transmitter antenna up -not down to ward your vehicle. If your vehicle gets too far away, it won't work properly.


- 4 Don't drive your vehicle in sand or through water or snow. If your vehicle does get wet, wipe with a towel and allow to dry completely.
- 5 Don't store your vehicle near heat or in direct sunlight. Always turn switches OFF and remove all batteries for storage.

6 BATTERY INSTALLATION

1 Vehicle (3803-4)

1. First insert the plug of pile into the charger faucet, and then charge up the pile fully, charging it for six hours. (as illustrated).

Please use the charger and battery included for this product.



2. Rotate the Battery door latch to unlocked position and open the battery door.



3. Insert the battery pack into the battery compartment and slide it into place as shown.



4. Close the battery door and rotate the battery door latches to locked position.



NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.