

User's Manual

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- (3) This device can automatically deactivate the transmitter within not more than 5 seconds of being released.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The Device Data:


1. Model designation: CY-01
2. Power: 12V battery
3. Frequency: 315 MHz

Operation instruction:

Step:

1. Switch on the call unit by on/off volume control.
2. Put the call unit away from the remote unit up to 150 feet
3. Push the button on the remote unit as the illustration on the panel one by one, accordingly the call unit will sound as Buck Grunt, snort, tending grunt, Rattling antler, Doe bleat. No sound will be a cured if two of more buttons were pushed at the same time.
4. The call unit will sound as your need once the button on the remote unit was pushed. When the button released the sound will not stop until the sound cycle end
5. When stop to use the remote deer call, don't forget to switch off the call unit.

- Remote up to 150 feet
- Weather resistant sturdy construction
- Weather-guard rubber molded seams
- Water-resistant speaker cover
- On/Off volume control
- 5 digital call sounds
- Non-slip push button pads on remote unit
- Velcro closure strap for remote unit attachment
- Heavy duty nylon carry/tree strap.



While you are calling in that big buck, you will no longer have to worry about giving away your tree stand or ground blind location. The light weight calling unit can be placed up to 150 feet away from your tree stand or ground blind and operated by remote control. This keeps the deer's attention on where the call sounds are coming from, and not on you.

If you are a serious deer hunter, photographer, or nature lover, this remote calling system will have you calling like a pro every time.

REMOTE DEER CALL

BUCK GRUNT - Sound that a buck makes when mating and/or communicating with a doe he is trailing. This call means "come here".

SNORT - An aggressive sound usually made by the dominant buck in anticipation of fighting another buck. This call is also used by a buck to merely intimidate another buck in order to avoid a fight.

TENDING GRUNT - As the rut intensifies, the buck will use this call as he is trailing a doe trying to mate her. It is the buck's way of asking the doe to stop so he can breed her.

RATTLING ANTLER - Rattling antlers signals a fight between two bucks. This often times lures a third buck who is curious, or who is interested in stealing the doe while the fighting bucks spar.

DOE BLEAT - The sound a doe makes to signal that her breeding time is near, which attracts bucks to the area.