
封面

90mm

135mm

Vertical Mouse




M618MINI GX

Thank you for choosing this special wireless vertical mouse. Please read the user manual carefully when using this product.

➢Contents:

- Wireless vertical mouse ------X1
- User manual ------X1
- USB nano receiver ------X1
- CD driver for optional ------X1

➢Button Function:



①	Left click
②	Scroll wheel
③	Right click
④	DPI cycle
⑤	Backward
⑥	Forward
⑦	ON/OFF button

➢Features

- Vertical mouse, worm bionic shape design

➢Installation

Plug the USB connector for wired mouse (or USB Nano receiver for wireless version) to the USB port in the computer, after detecting successfully it will work normally.

➢Specification

DPI	800 /1200 /1600
Polling rate	125Hz
Working Voltage	1.5V
Working Current	< 20mA

➢Receiver Connection

Equipping the mouse with battery, insert the Nano receiver to the USB port of your computer, pushing the ON button on the bottom of the mouse, and the receiver will detect the device automatically, plug and play.

The red light will flash once if you shift the DPI to the first gear, will flash twice when you shift the DPI to the second gear, etc. Also it will flash when the voltage is low.


➢Driver Instruction


1. Installation

Download the driver from *www.deluxworld.com* or the CD in the package, install the driver.
Note: Please make sure this mouse is already connected to computer when setting the functions in the driver.

2.Setting

These functions can be customized as below





3.Macro setting:

Click "Assign Macro" to enter into Macro settings, click NEW and name the macro, and click "Left click" on any blank space below MACRO SELECT to confirm the name. Then Start Record, after finishing the record, please click "STOP RECORD", and click "OK" to save the macro. After choosing certain macro, the background of this macro will turn green, you can edit the macro.

4.Other functions:

Basic: Cut, Copy, Paste, etc. 8 functions are available
Advanced: Switch window, close window, etc. 6 functions are available
Media: Previous track, next track, stop, etc. 7 functions are available
You can also adjust the speed of tracking , double-click and scrolling

After setting the functions please click "Apply", if you need default functions just click "Restore Defaults"

➢Building Up the Connection Between Mouse and Receiver

If your mouse cannot work normally, you can try to build up the connection again between mouse and receiver, as following steps:

1. Take out the Nano receiver from computer and insert again, it will detect automatically for about 15 seconds.
2. Keep the mouse in ON mode and with battery in correct direction.
3. Keep the effective distance within 10 CM between the mouse and receiver.
4. Press the middle button (scroll wheel) and right button at the same time for about 1~3 seconds, then release it. The connection is being built for about 10 seconds.
5. If cannot build up the connection in 10 seconds, please repeat the above steps.

➢Debugging Tips

- Check the receiver if is connected to the USB port.
- Check the ON/OFF button if in ON mode.
- Check the effective distance between mouse the receiver and shorten it.
- Rebuild up the connection between the mouse and receiver.

FC CE

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

设计说明：

1、尺寸：135x90mm(公差+/-1mm)

2、材质：100g书写纸

3、颜色：单色双面印刷

4、装订方式：风琴折页

DELUX

深圳市多彩实业有限公司
SHENZHEN DELUX INDUSTRY CO., LTD.

名 称	M618mini GX海外说明书		
料 号			
分 发	□研发部 □产品部 □资材部 □品保部 □生产部 □工程部 □海外营销部 □国内营销部 □文控中心	批 准	
审 核	[signature]	设 计	梁莹/19.02.20