

1

2

3

4

5

6

7

8

A

B

C

D

70mm

100mm

封面

3. Notes:


- The indicator light will flash once after shifting the DPI to the first grade, will flash twice after shifting the DPI to second grade, etc. 5 grades in total.
- Press the scroll wheel + backward button at the same time to switch among 5 lighting effect: Streaming, Neon, Breathing, Flicker, Led off.
- When using the mouse, the corresponding mode indicator light flashes constantly to indicate that the battery is low, please charge it with a suitable device in time.

➤ Debugging Tips

- Make sure the receiver is plugged in the USB port.
- Make sure the distance between mouse and device in 10m.
- Make sure the ON/OFF button are slide to "ON" position

3.

Vertical Mouse



User Manual

Thank you for choosing our wireless vertical mouse. Please read the user manual carefully when using this product.

➤ Contents:

- Wireless vertical mouse —X1
- User manual —X1
- USB Nano receiver (stored in the battery compartment) -----X1
- 1.6m Type-C charging cable -----X1

➤ Button Function:

①

②

③

④

⑤

⑥

⑦

⑧

⑨

⑩

① Forward

② DPI cycle

③ Backward

④ Scroll wheel

⑤ Left click

⑥ Right click

⑦ Charging indicator

⑧ ON/OFF button

⑨ Mode Switch Key

⑩ Pairing Key

⑪ USB receiver

1.

➤ Features

- Ergonomic vertical left-handed design
- Tri-mode connection
- 1000mAh built-in Li-ion battery

➤ Specification

Connection	Wired+2.4G
DPI	800/1200/1600/2400/4000
Polling rate	125Hz

➤ Connection

1. Mode Switching

When slide the Mode Switch Key to 2.4G mode, the indicator will flash green color. When slide the Mode Switch Key to BT mode, the indicator will flash blue color. When plug the Type-C cable into the computer, the mouse will enter wired mode and charge the battery at the same time. When charging, the indicator will light up with red color, and light off when fully charged.

2. Match Way

(1) 2.4G Mode: Slide the Mode Switch Key to 2.4G mode, press the Pairing Key for 3s, the indicator will flash green color, then plug the USB receiver within 1 minute and the mouse will program automatically.

2.

设计说明:

1、尺寸: 100x70mm(公差+/-1mm)

2、材质: 70g书写纸

3、颜色: 单色双面印刷

4、装订方式: 风琴折页

分 发

☐研发部

☐产品部

☒资材部

☒品保部

☒生产部

☒工程部

☒海外营销部


☐国内营销部

☒文控中心

批 准

审 核

DELUX



深圳市多彩实业有限公司

SHENZHEN DELUX INDUSTRY CO., LTD.

名 称

M618ZD海外中性说明书
(台展方案)

料 号

R3.4.M618Z06011A

设 计

王欣宇/22.03.31

1

2

3

4

5

6

7

8

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.