







Remote Control Rocket Fusée télécommandée



Requires 1 X 9V batteries
Fonctionne avec 1 piles 9V



Requires 3 X "AAA" batteries
Fonctionne avec 3 piles "AAA"

Do not mix old and new batteries.
Do not mix alkaline, standard(carbon-zinc), or
rechargeable(nickel-cadmium) batteries.

Ne pas mélanger les piles neuves et les piles usées.
Ne pas mélanger les piles alcalines, standard (carbone-zinc)
ou rechargeables (nickel-cadmium).

Remove batteries when not in use or discharged
Enlever la batterie quand n'en opération ou décharger pas

For best results use on a smooth surface or short pile carpet.
Pour un meilleur résultat, utiliser sur une surface lisse ou un
tapis aiguilleté.

Requires 1 X 9V, 3 X "AAA" batteries (Not included)
Fonctionne avec 1 piles 9V, 3 piles "AAA"(Non compris)

This device complies with Part 15 of the FCC rules. Operation is
subject to the following two conditions: (1) This device may not
cause harmful interference, and (2) This device must accept any
interference received, including interference that may cause
undesired operation..

Changes or modification not expressly approved by the party responsible for compliance could void the user's
authority to operate the equipment