

size:195x100mm



HEUIXINT
合汇鑫通

Bluetooth Speaker

User Manual



Model:M15




HEUIXINT
合汇鑫通

SHENZHEN HEUI XINT TECHNOLOGY CO.,LTD
Address: 6/F, Building 2,Hengchangrong High Tech Industrial Park,
No.128 East Road,Shangnan,Shajing Street,Baoan District,
Shenzhen,China
Tel : 0755-29784553 Fax : 0755-29784376
Service hotline : 400-6166-315
Http://www.heuixint.com

What's included

1. Speaker
2. Micro USB Cable
3. User Manual



What you'll see

1. Aluminum appearance
2. Micro USB Slot
3. On/Off
4. Volume Button (+)
5. Volume Button (-)
6. Pause/Play
7. Silicone pad

1. Bluetooth

Turn on the speaker will enter the Bluetooth mode, make sure your mobile phone has its Bluetooth turned on and search for devices , wait your mobile phone finds " M15 " your devices would be connected to your mobile phone.



2. USB Charge

Micro usb cable connect PC usb jack for charging.

Remark: The device will be "OFF" while not working at connected bluetooth after 20 minutes.

Product Parameters

Power	3.7V 2200mAh Lithium Battery
Effective Power	≤5Wx2
Speaker	1.57 inch
Frequency Response	60Hz-20KHz
Impedance	4Ω
SNR	80dB
Distortion	THD < 1%
Charging Interface	Micro USB 5V
Bluetooth Technology	Action V4.0 10M Transmission Distance
Dimension	L 198 x W 84.5 x H 64.5 mm

Indicator status introduction

CHARGE	Working Status
blinking blue	bluetooth mode
red indicator	USB sound card mode
red indicator	charging
—	finish charging

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.