


<Photographs of EUT>



Intertek Testing Services Shenzhen Ltd. Longhua Branch


Address: 1F/2F, Building B, QiaoAn Scientific Technology Park, Shangkeng Community, Guanhu Subdistrict, Longhua District, Shenzhen, P.R. China
Tel: 86-755-8601 6288 Fax: 86-755-8601 6751 www.intertek.com.cn



Intertek Testing Services Shenzhen Ltd. Longhua Branch

Address: 1F/2F, Building B, QiaoAn Scientific Technology Park, Shangkeng Community, Guanhu Subdistrict, Longhua District, Shenzhen, P.R. China
Tel: 86-755-8601 6288 Fax: 86-755-8601 6751 www.intertek.com.cn


<Antenna Location>



The separation distance for antenna to edge:

Antenna	To Front Face (mm)	To Rear Face (mm)	To Left Side (mm)	To Right Side (mm)	To Top Side (mm)	To Bottom Side (mm)
WLAN / BT	5	29	43	16	29	31

<Photographs of SAR Setup>




Front Face of EUT with 0 cm Gap



Rear Side of EUT with 0 cm Gap



Right Side of EUT with 0 cm Gap



Top Side of EUT with 0 cm Gap

Intertek Testing Services Shenzhen Ltd. Longhua Branch

Address: 1F/2F, Building B, QiaoAn Scientific Technology Park, Shangkeng Community, Guanhu Subdistrict, Longhua District, Shenzhen, P.R. China
Tel: 86-755-8601 6288 Fax: 86-755-8601 6751 www.intertek.com.cn