

SURE·SHOT HD

Complete Video Game System

LEGAL NOTICE

PHOTOSENSITIVITY/EPILEPSY WARNING

Please read before using this game or allowing your children to use it. A very small percentage of people are susceptible to epileptic seizures or loss of consciousness when exposed to certain flashing lights or light patterns in everyday life. Such people may have a seizure while watching television images or playing certain video games. This may happen even if the person has no medical history of epilepsy or has never had any epileptic seizures. If you or anyone in your family has ever had symptoms related to epilepsy (seizures of loss of consciousness) when exposed to flashing lights, consult your doctor prior to playing.

We advise that parents should monitor the use of video games by their children. **DISCONTINUE USE IMMEDIATELY** and consult your doctor if you or your child experience:

- dizziness
- blurred vision
- eye or muscle twitches
- loss of consciousness
- disorientation
- any involuntary movement or convulsion

WARNING - BATTERY INFORMATION

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert item correctly by matching the + and – polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short circuit the supply terminals.
6. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging.
7. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.

WARNING - REPETITIVE MOTION INJURIES

Playing video games can make your muscles, joints or skin hurt. Follow these instructions to avoid problems such as tendinitis, carpal tunnel syndrome or skin irritation:

- Avoid excessive play. Parents should monitor their children for appropriate play.
- Take a 10 to 15 minute break every hour, even if you don't think you need it.
- If your hands, wrists or arms become tired or sore while playing, or if you feel symptoms such as tingling, numbness, burning or stiffness, stop and rest for several hours before playing again.
- If you continue to have any of the above symptoms or other discomfort during or after play, stop playing and see a doctor.

WARNING - RADIO FREQUENCY INTERFERENCE

The Sure Shot HD system can emit radio waves that can affect the operation of nearby electronics, including cardiac pacemakers.

- Do not operate the Sure Shot HD system within 9 inches of a pacemaker while using the wireless feature.
- If you have a pacemaker or other implanted medical device, do not use the wireless feature of the Sure Shot HD system without first consulting your doctor or the manufacturer of your medical device.
- Observe and follow all regulations and rules regarding use of wireless devices in locations such as hospitals, airports, and on board aircraft. Operation in those locations may interfere with or cause malfunctions of equipment, with resulting injuries to persons or damage to property.

END OF PRODUCT RECYCLING

The Sure Shot HD system is made of many materials that may be recycled. Follow local regulations when disposing of the system.

WARRANTY INFORMATION

If you're unable to resolve the issue through our website or through Customer Support, verify on your original receipt if the product is eligible for replacement.

HARDWARE WARRANTY: Super Happy Fun Fun, Inc. warrants to the original purchaser that the hardware product shall be free from defects in material and workmanship for thirty (30) days from the date of purchase.

If a defect covered by this warranty occurs during this warranty period, Super Happy Fun Fun will repair or replace the defective hardware product or component, free of charge. The original purchaser is entitled to this warranty only if the date of purchase is registered at point of sale or the consumer can demonstrate, to Super Happy Fun Fun's satisfaction, that the product was purchased within the last 30 days.

SERVICE AFTER EXPIRATION OF WARRANTY: Please visit our website at www.sureshotd.com/support for troubleshooting information and repair or replacement options. In some instances, it may be necessary for you to ship the complete product, **FREIGHT PREPAID AND INSURED FOR LOSS OR DAMAGE**, to Super Happy Fun Fun. Please do not send any products to Super Happy Fun Fun without contacting us first.

WARRANTY LIMITATIONS THIS WARRANTY SHALL NOT APPLY IF THIS PRODUCT: (a) IS USED WITH PRODUCTS NOT SOLD OR LICENSED BY SUPER HAPPY FUN FUN (INCLUDING, BUT NOT LIMITED TO, NON-LICENSED GAME ENHANCEMENT AND COPIER DEVICES, ADAPTERS, SOFTWARE, AND POWER SUPPLIES); (b) IS USED FOR COMMERCIAL PURPOSES (INCLUDING RENTAL); (c) IS MODIFIED OR TAMPERED WITH; (d) IS DAMAGED BY NEGLIGENCE, ACCIDENT, UNREASONABLE USE, OR BY OTHER CAUSES UNRELATED TO DEFECTIVE MATERIALS OR WORKMANSHIP; OR (e) HAS HAD THE SERIAL NUMBER ALTERED, DEFACED OR REMOVED. ANY APPLICABLE IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED IN DURATION TO THE WARRANTY PERIODS DESCRIBED ABOVE (3 MONTHS, AS APPLICABLE). IN NO EVENT SHALL SUPER HAPPY FUN FUN BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM THE BREACH OF ANY IMPLIED OR EXPRESS WARRANTIES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR EXCLUSION OF CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state or province to province. Super Happy Fun Fun's address is: Super Happy Fun Fun, Inc. 11044 Research Blvd. Suite C-220, Austin, TX 78759

This warranty is only valid in the United States and Canada.

COPYRIGHT AND TRADEMARKS

Copyright 2017 Super Happy Fun Fun, Inc. All Rights Reserved.
Big Buck Hunter Pro Copyright © 2006 Play Mechanix, Inc. All Rights Reserved
Big Buck Hunter Pro Open Season Copyright © 2009 Play Mechanix, Inc. All Rights Reserved
©2012 Play Mechanix, Inc. All Rights Reserved

FCC AND IC NOTICE

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

The wireless controller complies with FCC/IC radiation exposure limits set forth for uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules.

This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption rate (SAR).

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded cables must be used with this unit to ensure compliance with Class B FCC limits.

You are cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. If you have questions about this product, visit www.sureshotd.com.

You can also write to: Super Happy Fun Fun, Inc., Customer Support, 11044 Research Blvd., Suite C-220, Austin, TX 78759 U.S.A.

Declaration of Conformity

Trade Name:	SureShot HD
No.:	2017-888-ST002A / 2017-888-GC002A
Responsible Party:	Super Happy Fun Fun, Inc.
Address:	11044 Research Blvd. Suite C-220 Austin, TX 78759 U.S.A.
Telephone Number:	(512) 349-7885