

1XKT9062Y

1 color Black



MAGIC SNOWMAN VILLAGE
QUICK START GUIDE


This Quick Start Guide will provide you with general information to enable you to enjoy your Magic Snowman Village figurines right out of the box. We encourage you to retain your original packaging for safe storage.

SYNCING YOUR SET

If you have more than one Magic Snowman Village tabletop décor piece, the pieces will play synchronized songs and light shows across all connected pieces. The Christmas Tree unlocks the most synchronized content across the village pieces.

Slide the switch of each piece to either Channel 1, 2, or 3. Ensure all pieces are on the same channel.

Requires 3 AA batteries (included and replaceable) or the Keepsake Power Cord (sold separately). For best results, we recommend keeping power sources consistent across your village pieces.



ACTIVATING YOUR SET

Depending on the power source, your tabletop set has 2 different modes of operation:

- BATTERY-POWERED**
Press the button on your village piece to see a song and light show. After the song and light show, your village piece enters a 3-minute light-only mode. After 3-minute light mode, the village piece will turn off. Press button to toggle through sound and light, light only, and off.
- POWER CORD**
Press the button on your village to see a song and light show. After the song and light show, your village piece enters a constant light-only mode. Press button to toggle between sound and light and light only. To turn off, slide switch to “OFF” position.

NOTE: If you have multiple village pieces that are synchronized, pressing the button on any piece will cause all pieces to activate and toggle through modes.

TROUBLESHOOTING:

In the event that one or more of the village pieces stops working in sync with the others, resync by moving the slider switch on the bottom of all figurines to the “OFF” position and then turn them back to different channel position than previously used.

You will find helpful FAQs and troubleshooting tips at care.hallmark.com



Scan here for more product information.

IMPORTANT SAFETY PRECAUTIONS:

- For indoor use only.
- To reduce the risk of fire or electric shock, do not expose this device to moisture.

IMPORTANTES MESURES DE SÉCURITÉ :

- Pour usage intérieur seulement.
- Pour éviter tout risque d'incendie ou de décharge électrique, conserver cet appareil à l'abri de l'humidité.

Please recycle or dispose of batteries properly. Remove batteries before storing.

CAUTION: Do not mix old and new or different battery types.

ATTENTION : Ne pas mélanger des piles usagées et neuves ou de types différents.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that of the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B)/NMB-3 (B)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent mécanisme respecte l'article 15 des règlements de la FCC. Son utilisation est sujette aux deux conditions suivantes :

- Ce mécanisme ne doit pas causer d'interférence nuisible
- Ce mécanisme doit accepter toute interférence extérieure, y compris celle pouvant entraîner un mauvais fonctionnement.

ATTENTION : Tout changement ou modification non approuvés expressément par le manufacturier pourraient annuler le droit de l'utilisateur d'utiliser le présent mécanisme.

REMARQUE : Le présent équipement a été testé et satisfait aux limites des mécanismes numériques de catégorie B, suivant l'article 15 des règlements de la FCC. Ces limites sont conçues pour offrir une protection raisonnable contre des interférences nuisibles dans des installations résidentielles. Le présent équipement génère, utilise et peut irradier l'énergie des fréquences radio et, s'il n'est pas installé ni utilisé conformément aux instructions, il peut causer une interférence nuisible aux communications radio. Cependant, il n'est pas garanti qu'une telle interférence ne puisse se produire dans une installation particulière. Si le présent équipement cause une interférence nuisible à la réception d'un signal radio ou télévisé, ce qui peut être déterminé en éteignant et en rallumant l'équipement, il est recommandé à l'utilisateur de corriger la situation en prenant une ou plusieurs des mesures suivantes :

- En réorientant ou en relocalisant l'antenne de réception.
- En augmentant l'espace entre l'équipement et le récepteur.
- En branchant l'équipement dans une prise d'un circuit autre que celui où est branché le récepteur.
- En consultant un détaillant ou un technicien radio/télévision d'expérience.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- L'appareil ne doit pas produire de brouillage;
- L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Not a toy. For decorative use only.
Ce produit n'est pas un jouet. Pour usage décoratif seulement.