

Functions:

-  To learn the numbers on the characters.
-  To learn the different colours.
-  Six different sounds.
-  To learn how to count total quantities of characters.
-  To learn six different characters.
-  Follow the instructions to put the character on the meadow.

Suggestions:

- After removing a character from the farm, wait until you hear the sentence from the farm before replacing it.
- If the farm fails to recognise the characters, or recognises them incorrectly, insert new batteries.
- Use and store the Magic Farm in room temperature environment.

Important:

- Remove rechargeable batteries from the toy before recharging.
- Recharge rechargeable batteries only under adult supervision.
- Non rechargeable batteries are not to be recharged.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short circuited.
- Remove all the batteries when the toy is not in use for a long time.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Disposal Instructions:

- Please only place discharged batteries into the collection boxes at the store of the municipal disposal site.

Product identification :

Nature : Toy
Type : Inductive Toy
Commercial reference : 8088
Designation : Magic Farm

Kuky Limited declares under its entire responsibility that the product described above is conformed to the applicable fundamental requirements and in particular the ones of the following 1995/5/CE directive :

Article 3.1 a : health protection and user's security .
According to norms EN 71-1 (1998)-2-3 and EN 50088.

Article 3.1 b : protection requirements regarding the electro-magnetic compatibility . According to norms EN301489-1 : V 1.4.4 : 2002-04.

Article 3.2 : Good use of the radioelectrical spectrum in order to avoid harmful interferences.
According to norms EN 300330-2 : V 1.1.1 : 2001-06

To that effect, declares that all the series of radio testings have been made.

Date : 31/05/2005



Ref:8088-E

magic farm

