




Picture 8: Left Hand Touch Cheek Position




Picture 9: Left Hand Tilt 15 Degree Position



Picture 10: Right Hand Touch Cheek Position



Picture 11: Right Hand Tilt 15 Degree Position




Picture 12: Back Side, the distance from handset to the bottom of the Phantom is 10mm




Picture 13: Front Side, the distance from handset to the bottom of the Phantom is 10mm




Picture 14: Left Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 15: Right Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 16: Top Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 17: Bottom Side, the distance from handset to the bottom of the Phantom is 10mm