

Meet your phone.




Para la versión en español, visite verizonwireless.com/Support



About your phone

Front camera Indicator light
Earpiece Volume button



Back key Power/
Lock button
Home key
Microphone
Recent apps key

Flash Back camera



Speaker Headset jack
micro-USB/
Charger port


NOTE: Devices and software are constantly evolving.
The images you see here are for reference only.

Setting up your phone

Your phone already has a SIM card installed.


Step 1. Remove the back cover

Place your fingernail in the cutout at the bottom left of the back cover, and pop the cover off the phone.




Optional: Insert the microSDXC card
If you have a microSDXC card, slide the card into the microSDXC card slot with the gold contacts facing down.

NOTE: The microSDXC card is sold separately.





Step 2. Insert the battery

Insert the battery, making sure the gold contacts line up. Press down gently to secure.



Step 3. Replace the back cover
Replace the cover over the back of the phone, and then press down along the edges to secure. Make sure there are no gaps.




Setting up your phone

Step 4. Charge your phone

Before turning on your phone, charge it fully.

Insert the small end of the USB cable into the phone. Insert the larger end into the charger and plug it into an outlet.



WARNING: Only use approved chargers with your device. Incompatible chargers or tampering with the charger port could damage your device and void the warranty.

Using your phone

Turning your phone on/off

To turn your phone on, press and hold the **Power/Lock** button.

To turn your phone off, press and hold the **Power/Lock** button again and tap **Power off**.

Locking/unlocking the screen

To turn on your screen, press the **Power/Lock** button. Then swipe up on the screen to unlock it.

To turn off your screen and prevent accidental key presses, press the **Power/Lock** button.

Touch screen tips

Use touch gestures to move around the screen, open menus, select items, zoom in and out of web pages and more.

There are several touch gestures recognized by your phone:

- **Tap**—Tap the screen with your finger to select items or press buttons on the screen.
- **Touch and hold**—Touch and hold an item on the screen (such as a link in a web page) to open available options.
- **Swipe**—Swipe by quickly sliding your finger in any direction.
- **Drag**—Drag by touching an item and moving it to a new position.
- **Double tap**—Double tap to zoom in/out on a web page or picture.
- **Multi-touch**—Pinch or spread your thumb and index finger to zoom in or out.
- **Two-finger swipe**—Swipe down from the status bar using two fingers to access Quick Settings.

Copying content from your old phone

For help transferring contacts, photos and other content from your old phone, visit verizonwireless.com/Cloud.

Learning more



From your computer, visit verizonwireless.com/Support.



Download a User Guide from verizonwireless.com/Support or call **800.922.0204** to order a copy.

Managing your account



My Verizon Mobile app

Manage your account, track your usage, edit account information, pay your bill and more.



International travel

For features and rates when outside the US, visit: verizonwireless.com/International.



Customer service

Call **800.922.0204**
Twitter @VZWSupport

Additional information

Your wireless device and third-party services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms, conditions and policies prior to using this wireless device and any associated application, product or service.

Hearing aid compatibility information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer technologies that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Ask your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, ask your service provider or phone retailer.



ZTE, BLADE, and the ZTE logos are trademarks of ZTE Corporation. Android is a trademark of Google LLC. The *Bluetooth*® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by ZTE Corporation is under license. microSDXC Logo is a trademark of SD-3C, LLC. Qualcomm® Snapdragon™ processors are products of Qualcomm Technologies, Inc. Qualcomm and Snapdragon are trademarks of Qualcomm Incorporated, registered in the United States and other countries. Used with permission. Other trademarks and trade names are the property of their respective owners.

© 2018 Verizon Wireless. All Rights Reserved.