

DJI ROMO

Quick Start Guide

V0.1




Disclaimer

By using this product, you signify that you have read, understand, and accept the terms and conditions of this guideline and all instructions at <https://www.dji.com/romo>. EXCEPT AS EXPRESSLY PROVIDED IN AFTER-SALES SERVICE POLICIES AVAILABLE AT [HTTPS://WWW.DJI.COM/SERVICE/POLICY](https://www.dji.com/service/policy), THE PRODUCT AND ALL MATERIALS AND CONTENT AVAILABLE THROUGH THE PRODUCT ARE PROVIDED "AS IS" AND ON "AS AVAILABLE BASIS" WITHOUT WARRANTY OR CONDITION OF ANY KIND. This product is not intended for children.

Using for the First Time

- (1) **Make sure to remove** the foam strip from the robot. Gently turn the robot upside down, make sure that the mops, side brushes and soft rubber roller brushes are mounted in place after they are firmly secured.



- (2) **Make sure to remove** the foam sheet from the base station washboard. Lift the base station to the planned placement area. Make sure the surface of the floor is level and flat, and there is enough space to operate the product. Connect the power port on the back of the base station to a power outlet using the AC power cable.



- (3) Mount the base plate onto the base station. Make sure there is a strong Wi-Fi signal, and that

there are no obstacles within 5 cm on the either side and 1 m in front of the base station.




- (4) Open the front cover of the base station. Make sure that the disposable dust bag is mounted properly. Align the cleaning solution bottle mouth with the slot on the base station, and push the bottle to the end of the slot. The "click" sound indicates that it is firmly secured in place. Close the front cover of the base station.



- (5) When inserting the robot into the base station, make sure that the wheels on both sides of the robot are placed onto the track of the base station. Push the robot until it is fully inserted in the

base station. Once properly inserted, the indicator on the robot will turn on and the robot will automatically power on.



- (6) Take out the clean water tank, and fill it with tap water. Fill with tap water only. DO NOT add other products, such as cleaning solution or disinfectant. Note that when opening the water tank cover, a small amount of force is needed to loosen the buckle. Make sure to slowly open the water tank cover. When closing the cover, make sure to close it until it is firmly secured. When adding water, make sure that the water volume does not exceed the MAX mark on the tank.



- (7) Download and install the DJI Home app, and follow the prompts in the app to build a map of the surrounding area and perform cleaning tasks.



Buttons/Indicator



1. Start Button

Press once to start/pause/resume the task.
Press and hold for 5 seconds to power on/off.

2. Return-to-Home Button

Press once to stop the task and return the robot to the base station.



Start Button/Indicator

Start Button

Press once to start/pause/resume the task.

Indicator

Displays White: Device is available.

Displays Orange: Task failed. Follow the prompts in the app to resolve the issue.

Displays Red: Invalid device. Contact DJI Support.

FCC Compliance Notice

Supplier's Declaration of Conformity

Product name: Vacuum Cleaner / Base Station

Model Number: CR8E/CR8F/CS8E/CS8F

Responsible Party: PixelPro Imaging LLC

Responsible Party Address: 217 S VICTORY BLVD,BURBANK,CA 91502-2349

Website: www.dji.com

We, PixelPro Imaging LLC, being the responsible party, declares that the above mentioned model was tested to demonstrate complying with all applicable FCC rules and regulations.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm during normal operation. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.