



Wireless PIR-Camera

User's Manual



Foreword

General

This manual introduces the installation, functions and operations of the wireless PIR-Camera (hereinafter referred to as the "PIR-Camera"). Read carefully before using the device, and keep the manual safe for future reference.

Model

DHI-ARD1731-W2; DHI-ARD1731-W2 (868)

Safety Instructions

The following signal words might appear in the manual.

Signal Words	Meaning
 DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, reductions in performance, or unpredictable results.
 TIPS	Provides methods to help you solve a problem or save time.
 NOTE	Provides additional information as a supplement to the text.

Revision History

Version	Revision Content	Release Time
V1.0.0	First release.	June 2022

Privacy Protection Notice

As the device user or data controller, you might collect the personal data of others such as their face, fingerprints, and license plate number. You need to be in compliance with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures which include but are not limited: Providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

About the Manual

- The manual is for reference only. Slight differences might be found between the manual and the product.
- We are not liable for losses incurred due to operating the product in ways that are not in compliance with the manual.
- The manual will be updated according to the latest laws and regulations of related jurisdictions. For detailed information, see the paper user's manual, use our CD-ROM, scan the QR code or visit our official website. The manual is for reference only. Slight differences might be found between the electronic version and the paper version.
- All designs and software are subject to change without prior written notice. Product updates might result in some differences appearing between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There might be errors in the print or deviations in the description of the functions, operations and technical data. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and company names in the manual are properties of their respective owners.
- Please visit our website, contact the supplier or customer service if any problems occur while using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Important Safeguards and Warnings

This section introduces content covering the proper handling of the device, hazard protection, and protection of property damage. Read carefully before using the device, and comply with the guidelines when using it.

Operation Requirements



- Make sure that the power supply of the device works properly before use.
- Do not pull out the power cable of the device while it is powered on.
- Only use the device within the rated power range.
- Transport, use and store the device under allowed humidity and temperature conditions.
- Prevent liquids from splashing or dripping on the device. Make sure that there are no objects filled with liquid on top of the device to avoid liquids flowing into it.
- Do not disassemble the device.

Installation Requirements



WARNING

- Connect the device to the adapter before power on.
- Strictly abide by local electrical safety standards, and make sure that the voltage in the area is steady and conforms to the power requirements of the device.
- Do not connect the device to more than one power supply. Otherwise, the device might become damaged.



- Observe all safety procedures and wear required protective equipment provided for your use while working at heights.
- Do not expose the device to direct sunlight or heat sources.
- Do not install the device in humid, dusty or smoky places.
- Install the device in a well-ventilated place, and do not block the ventilator of the device.
- Use the power adapter or case power supply provided by the device manufacturer.
- The power supply must conform to the requirements of ES1 in IEC 62368-1 standard and be no higher than PS2. Note that the power supply requirements are subject to the device label.
- Connect class I electrical appliances to a power socket with protective earthing.

Table of Contents

Foreword	I
Important Safeguards and Warnings	III
1 Introduction	1
1.1 Overview	1
1.2 Technical Specifications	1
2 Checklist	4
3 Design	5
3.1 Appearance	5
3.2 Dimensions	6
4 Power On	7
5 Adding the PIR-Camera to the Hub	9
6 Installation	10
6.1 Field of View	10
6.2 Installing the PIR-Camera	10
7 Configuration	12
7.1 Viewing Status	12
7.2 Configuring the PIR-Camera	13
Appendix 1 Cybersecurity Recommendations	16

1 Introduction

1.1 Overview

With its built-in 2-MP HD camera and CMOS image sensor, wireless PIR-Camera detects intrusions and captures high-definition snapshots. It is a wireless passive infrared detector that sends snapshots through the Wi-Fi and Ethernet connection to your phone and ARC (alarm center), for the causes of intrusions to be effectively identified.

The camera is also uniquely designed to only take snapshots when an intrusion occurs, eliminating the need to install cameras to constantly monitor scenes. Built to keep your family and business safe, the entire data transmission process is encrypted and the camera does not actively obtain your private information.

1.2 Technical Specifications

This section contains technical specifications of the PIR-Camera. Please refer to the ones that correspond with your model.

Table 1-1 Technical specifications

Type	Parameter	Description
Video	Field of View	88° (H); 68° (V)
	Image Type	JPEG
	Resolution	1600 × 1200; 1280 × 960; 640 × 480; 320 × 240
	Detection Speed	0.3 m/s-3 m/s (0.98 ft/s-9.84 ft/s)
	Frame Rate	2
	Illumination Mode	Infrared Light
	Illumination Range	12 m (39.37 ft)
	Day/Night Switch	Color/Black & White
Function	Indicator Light	1 × green alarm indicator
	Button	1 × power switch
	Remote Update	Cloud update
	Low Battery Detection	Yes
	Battery Level Display	Yes
	Tamper	Tamper alarm

Type	Parameter	Description	
	Signal Strength	RF Signal test RF-HD signal test	
	Carrier Frequency	DHI-ARD1731-W2(868): 868.0 MHz-868.6 MHz	DHI-ARD1731-W2: 433.35 MHz-434.6 MHz
	Communication Distance	DHI-ARD1731-W2(868): RF: Up to 1,600 m (5,249.34 ft) in an open space RF-HD: Up to 300 m (984.25 ft) in an open space	DHI-ARD1731-W2: RF: Up to 1,200 m (3,937.01 ft) in an open space RF-HD: Up to 300 m (984.25 ft) in an open space
	Communication Mechanism	Two-way	
	Frequency Hopping	Yes	
	Encryption Mode	AES128	
General	Power Supply	CR123A*3	
	Battery Life	4 years (if triggered twice a week with a battery efficiency of 70%)	
	Operating Temperature	-10 °C to +55 °C (+14 °F to +131 °F) (indoor)	
	Operating Humidity	10%-90% (RH)	
	Product Dimensions	127.6 mm× 71.0 mm× 53.2 mm (5.02" × 2.80" × 2.09")	
	Packaging Dimensions	121.0 mm× 65.0 mm× 170.0 mm (4.76" × 2.56" × 6.69")	
	Net Weight	202 g (0.45 lb)	
	Gross Weight	333 g (0.73 lb)	
	Installation	Wall mount	
	Casing	PC + ABS	
	Certifications	CE	CE; FCC
Technical	Detection Mode	PIR	
	Sensitivity	3 levels adjustable	
	Detection Range	12 m (39.37 ft) (86°) with installation height of 2.2 m (7.22 ft)	
	Detection Speed	0.3 m/s-3 m/s (0.98 ft/s-9.84 ft/s)	
	Pet Immunity Level	≤18 kg (39.68 lb)	
	White Light Resistance Level	2000 lux	

Type	Parameter	Description
	Two-way Digital Temperature Compensation	Yes
	Scenario	Indoor
	Operating Current	65 μ A
	Alarm Current	Day: 170 mA (Avg); 800 mA (Max) Night: 230 mA (Avg); 2.8 A (Max)

2 Checklist

Figure 2-1 Checklist




Table 2-1 Checklist

No.	Item Name	Quantity	No.	Item Name	Quantity
1	PIR-Camera	1	5	Quick start guide	1
2	Double-sided adhesive tape	1	6	Legal and regulatory information	1
3	Screw package	2	7	Battery	3
4	QR code	1	-	-	-

3 Design

3.1 Appearance

Figure 3-1 Appearance





Table 3-1 Structure

No.	Name	Description
1	IR light	Provides IR light for dark environments.
2	Camera	Captures images when an intrusion alarm is triggered.
3	Indicator	- Flashes green quickly: Pairing mode or reduced sensitivity mode. - Solid green: An alarm event was triggered. - Solid green for 2 seconds: Pairing successful. - Slowly flashes green for 3 seconds: Pairing failed.
4	Tamper switch	When the tamper switch is released, the tamper alarm will be triggered
5	Bracket tamper switch	(Optional) If the bracket is removed, the tamper alarm will be triggered.
6	Battery	Insert batteries to power on the PIR-Camera.
7	On/off switch	Turn on or turn off the PIR-Camera.
8	Back cover	If the back cover is opened, the tamper alarm will be triggered.

3.2 Dimensions

Figure 3-2 Dimensions (mm [inch])



4 Power On

Step 1 Loosen the screw to open the PIR-Camera.

Figure 4-1 Loosen the screw




Figure 4-2 Open the PIR-Camera




Step 2 Insert batteries into the PIR-Camera.




- When inserting the batteries, make sure that they are all charged to the same level.
- When inserting the batteries, align the "+" symbols on the battery to those on the PIR-Camera.

Figure 4-3 Insert batteries



Step 3 Turn on the PIR-Camera.

Figure 4-4 Turn on the PIR-Camera



5 Adding the PIR-Camera to the Hub

Before you connect it to the hub, install the DMSS app to your phone. This manual uses iOS as an example.



- Make sure that the version of the DMSS app is 1.99 or later, and the hub is V1.001.0000000.8.R.220528 or later.
- Make sure that the hub has a stable internet connection.
- Make sure that the hub is disarmed.

Step 1 Go to the hub screen, and then tap  to add the PIR-Camera.

Step 2 Tap  to scan the QR code at the bottom of the PIR-Camera, and then tap **Next**.

Step 3 Tap **Next** after the PIR-Camera has been found.

Step 4 Follow the on-screen instructions and switch the PIR-Camera to on, and then tap **Next**.

Step 5 Wait for the pairing.

Step 6 Customize the name of the PIR-Camera, and select the area, and then tap **Completed**.

6 Installation


6.1 Field of View

Field of view of the PIR-Camera are shown below.




When installing and using the PIR-Camera, make sure there are no objects partially or fully obscuring the detector's field of view.


Figure 6-1 Field of View



a



b




c

6.2 Installing the PIR-Camera

Before installation, add the PIR-Camera to the hub and test the signal strength and RF-HD. We recommend installing the PIR-Camera in a place with a signal strength of at least 2 bars.


Step 1 Drill 4 holes in the wall according to the hole positions of the PIR-Camera, and then put the expansion bolts into the holes.

Figure 6-2 Drill holes




Step 2 Close the PIR-Camera.

Figure 6-3 Close the PIR-Camera



Step 3 Secure the PIR-Camera with a screw.

Figure 6-4 Secure the PIR-Camera



 : Installation height cannot be higher than 2m.

7 Configuration

You can view and edit general information of the PIR-Camera.

7.1 Viewing Status

On the hub screen, select a PIR-Camera from the accessory list, and then you can view the status of the PIR-Camera.

Table 7-1 Status

Parameter	Value
Temporary Deactivate	The status for whether the functions of the PIR-Camera are enabled or disabled. •  : Enable. •  : Only disable tamper alarm. •  : Disable.
Temperature	The temperature of the environment.
Signal Strength	The signal strength between the hub and the PIR-Camera. •  : Low. •  : Weak. •  : Good. •  : Excellent. •  : No.
Battery Level	The battery level of the PIR-Camera. •  : Fully charged. •  : Sufficient. •  : Moderate. •  : Insufficient. •  : Low.
Anti-tampering Status	The tamper status of the PIR-Camera, which reacts to the detachment of the body.
Online Status	Online and offline status of the PIR-Camera. •  : Online. •  : Offline.
Entrance Delay Time	Entrance and exit delay time.
Exit Delay Time	

Parameter	Value
24 H Protection Zone Status	Active status of the 24 h protection zone. : Enable. : Disable.
Sensitivity	Sensitivity level during a shock alarm.
Transmit through Repeater	The status of whether the PIR-Camera forwards its messages to the hub through the repeater.
Program Version	The program version of the PIR-Camera.

7.2 Configuring the PIR-Camera

On the hub screen, select a PIR-Camera from the accessory list, and then tap  to configure the parameters of the PIR-Camera.

Table 7-2 Keypad parameter description

Parameter	Description
Snapshot Test	Tap Snapshot Test on the PIR-Camera screen, and then the PIR-Camera will take some snapshots. You can view a notification message in the message list afterwards.  We recommend you to use snapshot test function when you install the PIR-Camera for the first time. This will help you to find the most suitable locations and angles.
Device Configuration	- View PIR-Camera name, type, SN and device model. - Edit PIR-Camera name, and then tap Save to save configuration.
Area	Select the area to which the PIR-Camera is assigned.
Temporary Deactivate	Whether send commands to the alarm hub. - Tap Enable, and then the PIR-Camera will send commands to the hub. Enable is set by default. - Tap Only Disable Tamper Alarm, and then the system will only ignore tamper alarm messages. - Tap Disable, and then the PIR-Camera will not send commands to the hub.

Parameter	Description
Snapshot Config	Configure the number of snapshots that can be taken at a time, the interval and the parameters of the image. - Tap Times to Take Snapshots, and then select times from 1 to 10. - Tap Trigger Interval, and then you can select 10, 30, 60, or 120 seconds. - Tap Image resolution and Quantity, and then for the image resolution, you can select 1600 × 1200, 1280 × 960, 640 × 480, or 320 × 240. For the image quantity, you can select between 1 and 20.  For image resolution 1600 × 1200, you can only select between 1 and 10 for the image quantity.
LED Indicator	LED Indicator is enabled by default. For details on indicator behavior, see "3.1 Appearance".  If LED Indicator is disabled, the LED indicator will remain off regardless of whether the PIR-Camera is functioning normally or not.
Over-temperature Alarm	Enable the Over-temperature Alarm function, and then the alarm will be triggered when the temperature of the area where the PIR-Camera is installed is higher or lower than the defined one.
24 H Protection Zone	Enable the 24 H Protection Zone function, and then the accessory located in the 24 h protection zone is always active whether the security system is configured in the armed mode or not.
Home Mode	Enable the Home Mode, and then the selected accessories under the hub will be armed.
Delay Mode under Home Mode	Enable the Delay Mode under Home Mode, the selected accessory under the hub will be armed and the alarm will not be triggered until the end of customized delay time.  Only enable Home Mode first can Delay Mode under Home Mode take effect.

Parameter	Description
Delay Time	The system provides you with time to leave or enter the protection zone without alarm. • Delay Time for Entering Arming Mode: When you enter the zone, if you do not disarm the system before the delay ends, an alarm will be triggered.  Make sure that the delay time for entering arming mode is no longer than 45 seconds in order to comply with EN50131-1. • Delay Time for Exiting Arming Mode: When you are in the zone and arm the system, if you do not leave the zone before the delay ends, an alarm will be triggered. You can select from 0 s to 120 s.  The arming mode will be effective after the delay time.
Sensitivity	• Sensitivity level during a shock alarm. • Select from low, medium and high.
Siren Linkage	When an alarm is triggered, the accessories will report the alarm events to the hub and alert with siren.
Signal Strength Detection	Test the current signal strength.
Detector Test	Tap Start Detection to test the status of the PIR-Camera.
RF-HD Test	Tap Start Detection to test the signal strength for transmitting images between the PIR-Camera and the hub.
Transmit Power	Select from high, low, and automatic. The higher transmission power levels are, the further transmissions can travel, but power consumption increases.  If you select Low, the PIR-Camera will enter into reduced sensitivity mode.
Cloud Update	Update online.
Delete	Delete the PIR-Camera.  Go to the hub screen, select the PIR-Camera from the accessory list, and then swipe left to delete it.

Appendix 1 Cybersecurity Recommendations

Cybersecurity is more than just a buzzword: it's something that pertains to every device that is connected to the internet. IP video surveillance is not immune to cyber risks, but taking basic steps toward protecting and strengthening networks and networked appliances will make them less susceptible to attacks. Below are some tips and recommendations from Dahua on how to create a more secured security system.

Mandatory actions to be taken for basic device network security:

1. Use Strong Passwords

Please refer to the following suggestions to set passwords:

- The length should not be less than 8 characters.
- Include at least two types of characters; character types include upper and lower case letters, numbers and symbols.
- Do not contain the account name or the account name in reverse order.
- Do not use continuous characters, such as 123, abc, etc.
- Do not use overlapped characters, such as 111, aaa, etc.

2. Update Firmware and Client Software in Time

- According to the standard procedure in Tech-industry, we recommend to keep your device (such as NVR, DVR, IP camera, etc.) firmware up-to-date to ensure the system is equipped with the latest security patches and fixes. When the device is connected to the public network, it is recommended to enable the "auto-check for updates" function to obtain timely information of firmware updates released by the manufacturer.
- We suggest that you download and use the latest version of client software.

"Nice to have" recommendations to improve your device network security:

1. Physical Protection

We suggest that you perform physical protection to device, especially storage devices. For example, place the device in a special computer room and cabinet, and implement well-done access control permission and key management to prevent unauthorized personnel from carrying out physical contacts such as damaging hardware, unauthorized connection of removable device (such as USB flash disk, serial port), etc.

2. Change Passwords Regularly

We suggest that you change passwords regularly to reduce the risk of being guessed or cracked.

3. Set and Update Passwords Reset Information Timely

The device supports password reset function. Please set up related information for password reset in time, including the end user's mailbox and password protection questions. If the information changes, please modify it in time. When setting password protection questions, it is suggested not to use those that can be easily guessed.

4. Enable Account Lock

The account lock feature is enabled by default, and we recommend you to keep it on to guarantee the account security. If an attacker attempts to log in with the wrong password several times, the corresponding account and the source IP address will be locked.

5. **Change Default HTTP and Other Service Ports**

We suggest you to change default HTTP and other service ports into any set of numbers between 1024-65535, reducing the risk of outsiders being able to guess which ports you are using.

6. **Enable HTTPS**

We suggest you to enable HTTPS, so that you visit Web service through a secure communication channel.

7. **MAC Address Binding**

We recommend you to bind the IP and MAC address of the gateway to the device, thus reducing the risk of ARP spoofing.

8. **Assign Accounts and Privileges Reasonably**

According to business and management requirements, reasonably add users and assign a minimum set of permissions to them.

9. **Disable Unnecessary Services and Choose Secure Modes**

If not needed, it is recommended to turn off some services such as SNMP, SMTP, UPnP, etc., to reduce risks.

If necessary, it is highly recommended that you use safe modes, including but not limited to the following services:

- SNMP: Choose SNMP v3, and set up strong encryption passwords and authentication passwords.
- SMTP: Choose TLS to access mailbox server.
- FTP: Choose SFTP, and set up strong passwords.
- AP hotspot: Choose WPA2-PSK encryption mode, and set up strong passwords.

10. **Audio and Video Encrypted Transmission**

If your audio and video data contents are very important or sensitive, we recommend that you use encrypted transmission function, to reduce the risk of audio and video data being stolen during transmission.

Reminder: encrypted transmission will cause some loss in transmission efficiency.

11. **Secure Auditing**

- Check online users: we suggest that you check online users regularly to see if the device is logged in without authorization.
- Check device log: By viewing the logs, you can know the IP addresses that were used to log in to your devices and their key operations.

12. **Network Log**

Due to the limited storage capacity of the device, the stored log is limited. If you need to save the log for a long time, it is recommended that you enable the network log function to ensure that the critical logs are synchronized to the network log server for tracing.

13. **Construct a Safe Network Environment**

In order to better ensure the safety of device and reduce potential cyber risks, we recommend:

- Disable the port mapping function of the router to avoid direct access to the intranet devices from external network.
- The network should be partitioned and isolated according to the actual network needs. If there are no communication requirements between two sub networks, it is suggested to use VLAN, network GAP and other technologies to partition the network, so as to achieve the network isolation effect.
- Establish the 802.1x access authentication system to reduce the risk of unauthorized access to private networks.
- Enable IP/MAC address filtering function to limit the range of hosts allowed to access the device.

More information

Please visit Dahua official website security emergency response center for security announcements and the latest security recommendations.

ENABLING A SAFER SOCIETY AND SMARTER LIVING

Legal and Regulatory Information

Legal Considerations

Video surveillance can be regulated by laws that vary from country to country. Check the laws in your local region before using this product for surveillance purposes.

Disclaimer

Every care has been taken in the preparation of this document. Please inform your nearest Dahua office of any inaccuracies or omissions. Dahua Technology shall not be held responsible for any technical or typographical errors and reserves the right to make changes to the product and manuals without prior notice. Dahua Technology makes no warranty of any kind with regard to the material contained within this document, including, but not limited to, the implied warranty of merchantability and fitness for a particular purpose. Dahua Technology shall not be liable or responsible for incidental or consequential damages in connection with the furnishing, performance or use of this material. This product is only to be used for its intended purpose.

Intellectual Property Rights

Dahua Technology retains all intellectual property rights relating to technology embodied in the product described in this document.

Equipment Modifications

This equipment must be installed and used in strict accordance with the instructions given in the user documentation. This equipment contains no user-serviceable components. Unauthorized equipment changes or modifications will invalidate all applicable regulatory certifications and approvals.

Trademark Acknowledgments

  are registered trademarks or trademark applications of Dahua Technology in various jurisdictions. All other company names and products are trademarks or registered trademarks of their respective companies.

Regulatory Information

European Directives Compliance

-  This product complies with the applicable CE marking directives and standards:
- Low Voltage (LVD) Directive 2014/35/EU.
 - Electromagnetic Compatibility (EMC) Directive 2014/30/EU.

01

Privacy Protection Notice

As the device user or data controller, you might collect personal data of others such as face, fingerprints, car plate number, Email address, phone number, GPS and so on. You need to be in compliance with the local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures, including but not limited to: providing clear and visible identification to inform data subject the existence of surveillance area and providing related contact.

About the Manual

- The manual is for reference only. If there is inconsistency between the manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the manual.
- The manual would be updated according to the latest laws and regulations of related jurisdictions. For detailed information, refer to the paper manual, CD-ROM, QR code or our official website. If there is inconsistency between paper manual and the electronic version, the electronic version shall prevail.
- All the designs and software are subject to change without prior written notice.
- The product updates might cause some differences between the actual product and the manual. Please contact the customer service for the latest program and supplementary documentation.
- There still might be deviation in technical data, functions and operations description, or errors in print. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the manual are for the respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurring when using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Support

Should you require any technical assistance, please contact your Dahua distributor. If your questions cannot be answered immediately, your distributor will forward your queries through the appropriate channels to ensure a rapid response. If you are connected to the Internet, you can:

- Download user documentation and software updates.
- Search by product, category, or phrase.
- Report problems to Dahua support staff by logging in to your private support area.
- Chat with Dahua support staff.
- Visit Dahua Support at www.dahuasecurity.com/support/.

Contact Information

ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD.
Address: No.1199, Bin'an Road, Binjiang District, Hangzhou, P.R. China

05

Signalor	Beskrivelse
	Angiver høj risiko, som, hvis den ikke undgås, kan medføre død eller alvorlig personskade.
	Angiver middel eller lav risiko, som, hvis den ikke undgås, kan medføre lettere til moderat personskade.
	Angiver mulig risiko, som hvis den ikke undgås, kan resultere i skade på ejendom, tab af data, reduceret ydelse eller uforudsigelige resultater.
	Indeholder forslag, som hjælper dig med at løse et problem eller spare tid.
	Indeholder yderligere oplysninger, som understreger og supplerer teksten.

Sikkerhedskrav

- Følg lokale standarder for sikkerhed for at sikre, at spændingen er stabil og i overensstemmelse med produktets krav til strømforsyning.
- Transportér, brug og opbevar produktet i henhold til de tilladte klimatiske forhold (temperatur og luftfugtighed). Se produktets tekniske specifikationer for specifik temperatur og luftfugtighed ved drift.
- Placer ikke produktet et sted med fugt, støv, stærk varme eller kulde, stærk elektronisk udstråling eller ustabile lysforhold.
- Installer ikke produktet i nærheden af en varmekilde, såsom en radiator, et varmeapparat, et centralfyr eller andre varmeafgivende enheder, for at undgå ildbrand.
- Undgå, at væske løber ind i produktet og dermed forårsager skade på de elektriske komponenter.
- Installer produktet vandret, eller installer det et stabilt sted for at undgå, at det falder ned.
- Installer produktet et sted med god udluftning og bloker ikke produktets ventilationsåbninger.
- Adskil ikke produktet.
- Undgå stærkt tryk, kraftige vibrationer og gennemblending under transport, opbevaring og installation. Produktet skal være fuldt emballeret under transport.
- Brug fabriksemballagen eller tilsvarende til transporten.

Batteri

Lav batterispendning påvirker driften af ledelsesuret og får uret til at nulstille, hver gang produktet tændes. Der vises en logbesked i produktets serverapparat, når batteriet skal udskiftes. Se konfigurationsiderne til produktet, eller kontakt Dahuas supportteam for at få flere oplysninger om serverapparatet.

ADVARSEL

- Der er risiko for eksplosion, hvis batteriet udskiftes forkert.
- Ikke tænd kun med et tilsvarende batteri eller et batteri, der anbefales af Dahua.
- Bortskaf brugte batterier i overensstemmelse med lokale bestemmelser eller batteriproducentens anvisninger.

09

- Spazвайте местните стандарти за електрическа безопасност, за да осигурите стабилно напрежение, отговарящо на изискването за захранване на устройството.
- Транспортирайте и използвайте и съхранявайте устройството при указаните условия на влажност и температура. Направете проверка в съответните технически спецификации на устройството за конкретната работна температура и влажност.
- Не поставяйте устройството на място, изложено на влага, прах, много висока или ниска температура, със силно електронно излъчване или на място с променливо осветление.
- Не поставяйте устройството близо до източник на топлина, като радиатор, нагрявател, печ, или друго устройство за генериране на топлина, за да избегнете пожар.
- Не допускате в устройството да попадне течност, за да не се повредят външните компоненти.
- Монтирайте устройството хоризонтално или го поставете на стабилно място, за да не падне.
- Монтирайте устройството на добре проветриво място и не блокирайте вентилационния на устройството.
- Не разглобявайте устройството произволно.
- Избягвайте силно натовавяне, вибрации и намокряне по време на транспортиране, съхранение и монтаж. При транспортиране следва да се опакова напълно.
- Използвайте за транспортиране фабричната опаковка или подобна.

Батерия

Ниската мощност на батерията влияе на работата на часовника в реално време (RTC), което води до нулиране при усъщно включване. Часовът батерията трябва да бъде сменена, в отчета на съдържана на продукта ще се покаже съобщение. За повече информация относно отчета на съдържана вижте страниците за настройка на продукта или се свържете с екипа на Dahua.

ΠΡΟΕΙΔΕΥΣΗ

- Ακό батерията е неправилно подменена, има риск от експлозия.
- Сменяйте само със същата или батерия, препоръчана от Dahua.
- Избягвайте използването батерии в съответствие с местните разпоредби или инструкциите на производителя на батерията.

Românesc

Masuri de siguranta si Attentionari

Acest capitol descrie indicațiile de utilizare corectă a Dispozitivului , prevenirea pericolului și prevenirea distrugerii proprietății.Citiți aceste rânduri înainte folosii dispozitivului.

Instrucțiuni de siguranta

Urmatoarele semne categorizate pot aparea in Ghid.

Signal Words	Meaning
	Indică un risc potențial ridicat care, dacă nu este evitat, va duce la deces sau vătărnări grave.

13

- Restrictions of Hazardous Substances (RoHS) Directive 2011/65/EU and its amendment Directive (EU) 2015/863

A copy of the original declaration of conformity may be obtained from Dahua Technology.

The most up to date copy of the signed EU Declaration of Conformity (DoC) can be downloaded from: www.dahuasecurity.com/support/notice/

CE-Electromagnetic Compatibility (EMC)

This digital equipment is compliant with Class B according to EN 55032.

CE-Safety

This product complies with IEC/EN/UL 60950-1 or IEC/EN/UL 62368-1, Safety of Information Technology Equipment.

Declaration of Conformity CE

(Only for the product has RF function)

Hereby, Dahua Technology declares that the radio equipment is compliant with Radio Equipment Directive (RED) 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.dahuasecurity.com/support/notice/

USA Regulatory Compliance

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC SDOC Statement can be downloaded from: <https://us.dahuasecurity.com/support/notices/>

02

Postcode: 310053

Tel: +86-571-87688883

Fax: +86-571-87688815

Email: overseas@dahuatech.com

Website: www.dahuasecurity.com

English

Important Safeguards and Warnings

This Chapter describes the contents covering proper handling of the device, hazard prevention, and prevention of property damage. Read these contents carefully before using the device, comply with them when using, and keep it well for future reference.

Safety Instructions

The following categorized signal words with defined meaning might appear in the manual

Signal Words	Meaning
	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
	Indicates a potential risk which, if not avoided, could result in property damage, data loss, lower performance, or unpredictable result.
	Provides methods to help you solve a problem or save you time.
	Provides additional information as the emphasis and supplement to the text.

Safety Requirement

- Abide by local electrical safety standards to ensure that the voltage is stable and complies with the power supply requirement of the device.
- Transport, use, and store the device under the allowed humidity and temperature conditions. Refer to the corresponding technical specifications of device for specific working temperature and humidity.
- Do not place the device in a location exposed to dampness, dust, extreme hot or cold, strong electronic radiation, or unstable lighting conditions.
- Do not install the device in a place near the heat source, such as radiator, heater, furnace, or other heat generating device to avoid fire.
- Prevent liquid from flowing into the device to avoid damage to internal components.
- Install the device horizontally or install on the stable plane to prevent it from falling.
- Install the device in a well-ventilated place, and do not block the ventilation of the device.

06

Suomi

Tärkeitä varotoimenpiteitä ja varoituksia

Tässä luvussa kuvataan laitteen asianmukainen käsittely, vaarojen torjunta ja omaisuusvahinkojen estäminen. Lue tämä sisälu huolellisesti ennen laitteen käyttämistä ja noudata näitä ohjeita, kun käytät laitetta. Säilytä ohjeet tulevia tarpeita varten.

Turvallisuusohje

Suuraavat luokitellut huomoisanat kuvattulla merkityksellä saatavat esiintyä ohjeissa.

Huomusanat	Merkitys
	Ilmaisee suuren potentiaalisen vaaran, joka johtaa kuolemaan tai vakavaan loukkaantumiseen, jos sitä ei vältetä.
	Ilmaisee keskiuuden tai pienen potentiaalisen vaaran, joka saattaa johtaa lievään tai korjaallaiseen loukkaantumiseen, jos sitä ei vältetä.
	Ilmaisee mahdollisen vaarallisen tilanteen, joka saattaa johtaa omaisuusvahinkoon, tietojen menetykseen, suoritusstehon heikkenemiseen tai oodotamattomiin tuloksiin, jos sitä ei vältetä.
	Tarjoavat apua ongelmien ratkaisemiseen tai säästävät aikaa.
	Tarjoaa lisätietoa, joka korostaa tai täydentää tekstiä.

Turvallisuusvaatimus

- Noudata paikallisia sähköturvallisuusstandardeja varmistaksesi, että jännite on vakaa ja vastaa laitteen virtajännitteen asetuksia vaatimuksi.
- Kuljeta, käytä ja säilytä laitetta sallituissa kosteus- ja lämpötilaolosuhteissa. Käsitä laitteen erityinen käyttölämpötilaja -kosteus laitteen vastaavista oimistustiedoista.
- Älä sijaita laitetta paikkaan, jossa se altistuu kosteudelle, pölylle, erittäin kuivalle tai kylmälle lämpötilalle, voimakkaalle sähköisäilylle tai epävakaille tilaolosuhteille.
- Älä asenna laitetta lähelle lämmönlähdettä, kuten lämpöpatteria, lämmitintä, uunia tai muuta lämpöä tuottavaa laitetta, tulipalon välttämiseksi.
- Vältä nesteen pääsyä laitteen sisälle sisäisten komponenttien vahingoittumisen estämiseksi.
- Asenna laite vaakasoraan tai asenna se vaakaaseen paikkaan estääksesi sen kaatumisen.
- Asenna laite hyvin ilmastoituihin paikkaiin äläkä peitä laitteen tuuletusaukkoja.
- Älä pura laitetta omavaltaisesti.
- Vältä kovaa rasitusta, voimakasta tärinää ja kosteusta kuljetuksen, säilytyksen ja asennuksen aikana. Kuljetus vaatii täydellisen pakkaamisen.
- Käytä tehtaan pakkausta tai vastaavaa kuljetuksen aikana.

Paristo

Ahlainen pariston varausasto vaikuttaa tosiaikakellon (RTC:n) toimintaan nolaten sen jokaisella käynnistyskerralla. Luvioviesi ilmeisty tuotteen palvelinraportissa, kun paristo on vaihdettava. Lisätietoa palvelinraportista saat tuotteen

10

Signal Words	Meaning
	Indică un pericol potențial mediu sau scăzut care, dacă nu este evitat, poate duce la răni ușoare sau moderate.
	Indică un risc potențial care, dacă nu este evitat, ar putea duce la daune materiale, pierderi de date, performanțe mai scăzute sau rezultate imprevizibile.
	Offeră metode care să vă ajute să rezolvați o problemă sau să economisiți timp.
	Offeră informații suplimentare ca accent și supliment la text.

Cerinte de siguranta

- Respectați standardele locale de siguranță electrică pentru a vă asigura că tensiunea este stabilă și respectă cerințele de alimentare ale dispozitivului.
- Transportați, utilizați și depozitați dispozitivul sub condițiile de umiditate și temperatură admise. Consultați specificațiile tehnice corespunzătoare ale dispozitivului pentru temperatură și umiditate specifice de lucru.
- Nu așezați dispozitivul într-o locație expusă la umezeală, praf, extrem de caldă sau rece, de radiații electronice puternice sau de condiții de iluminare instabile.
- Nu instalați dispozitivul într-un loc în apropierea sursei de căldură, cum ar fi radiatorul, încălzitorul, cuptorul sau alt dispozitiv generator de căldură, pentru a evita incendii.
- Impedicați curgerea lichidului în dispozitiv pentru a evita deteriorarea componentelor interne.
- Instalați dispozitivul în poziție orizontală sau instalați-l pe un loc stabil pentru a preveni căderea acestuia.
- Instalați aparatul într-un loc bine ventilat și nu blocați ventilația aparatului.
- Nu dezasamblați dispozitivul voi.
- Evitați loviturile puternice, vibrațiile violente și umiditatea în timpul transportului, depozitării și instalării. Este necesar un pachet complet în timpul transportului.
- Utilizați pachetul de fabrica sau echivalent în timpul transportului.

Baterie

Puterea redusă a bateriei afectează funcționarea RTC, determinând resetarea la ficare pornire. Când bateria are nevoie de înlocuire, în raportul serverului produsului va apărea un mesaj de jurnal. Pentru mai multe informații despre raportul serverului, consultați paginile de configurare ale produsului sau contactați asistentul Dahua.

AVERTIZARE

- Risc de explozie dacă bateria este înlocuită incorect.
- Înlocuiți numai cu o baterie identică sau cu o baterie recomandată de Dahua.
- Annulați bateria în conformitate cu reglementările locale sau cu instrucțiunile producătorului bateriei.

RF exposure warning

(Only for the product has RF communication function)

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

Canada Regulatory Compliance

ICES-003

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- This device may not cause interference, and
- This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- l'appareil ne doit pas produire de brouillage, et
- l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF exposure warning

(Only for the product has RF communication function)

This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'attention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

03

- Do not disassemble the device arbitrarily.
- Avoid heavy stress, violent vibration, and soaking during transportation, storage, and installation. Complete package is necessary during the transportation.
- Use the factory package or the equivalent for transportation.

Battery

Low battery power affects the operation of the RTC, causing it to reset at every power-up. When the battery needs replacing, a log message will appear in the product's server report. For more information about the server report, see the product's setup pages or contact Dahua support.

-  **WARNING**
- Risk of explosion if the battery is incorrectly replaced.
 - Replace only with an identical battery or a battery which is recommended by Dahua.
 - Dispose of used batteries according to local regulations or the battery manufacturer's instructions.

Polski

Ważne środki ostrożności i ostrzeżenia

Niniejszy rozdział opisuje właściwe sposoby korzystania z urządzenia, sposoby zapobiegania zagrożeniom, a także sposoby zapobiegania uszkodzeniu mienia. Przed rozpoczęciem korzystania z urządzenia zapoznaj się dokładnie z tymi informacjami i zachowaj je na przyszłość do celów referencyjnych.

Instrukcje dot. bezpieczeństwa

W podręczniku mogą pojawić się następujące symbole. Ich znaczenie wyjaśnia poniższa tabela.

Symbol	Znaczenie
	Oznacza potencjalne zagrożenie wysokiego stopnia, którego nieuniknienie może skutkować poważnymi urazami lub śmiercią.
	Oznacza potencjalne zagrożenie średniego lub niskiego stopnia, którego nieuniknienie może skutkować pomniejszonymi lub średnimi urazami.
	Oznacza potencjalne zagrożenie, którego nieuniknienie może skutkować zniszczeniem mienia, utratą danych, spadkiem wydajności lub mied innymi nieprzewidzianymi skutki.
	Oznacza wskazówki pozwalające na rozwiązanie problemu lub oszczędność czasu.
	Oznacza informacje uzupełniające tekst główny.

Japan Regulatory Compliance

VCCI

These products comply with the requirements of VCCI Class B Information Technology Equipment.

Batteries

Correct disposal of batteries in this product

 This marking on the battery indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in Directive 2006/66/EC and its amending Directive 2013/56/EU. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

CAUTION

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Safety

The product complies with IEC/EN/UL 60950-1, Information Technology Equipment – Safety – Part 1: General Requirements; or complies with IEC/EN/UL 62368-1, Audio/video, information and communication technology equipment – Part 1: Safety requirements.

If the power supply to the product is from external power adaptor without connecting to AC Mains, and the product is not shipped with power adaptor, customers are required to use the external power adaptor that must fulfill the requirements for Safety Extra Low Voltage (SELV) and Limited Power Source (LPS).

Waste Electrical and Electronic Equipment (WEEE) statements

Disposal and Recycling

When this product has reached the end of its useful life, dispose of it according to local laws and regulations. For information about your nearest designated collection point, contact your local authority responsible for waste disposal. In accordance with local legislation, penalties may be applicable for incorrect disposal of this waste.

 This symbol means that the product shall not be disposed of together with household or commercial waste. Directive 2012/19/EU on waste electrical and electronic equipment (WEEE) is applicable in the European Union member states. To prevent potential harm to human health and the environment, the product must be disposed of in an approved and environmentally safe recycling process. For information about your nearest designated collection point, contact your local authority responsible for waste disposal. Businesses should contact the product supplier for information about how to dispose of this product correctly.

Wymogi dot. Bezpieczeństwa

- Przeznaczaj lokalnych standardów bezpieczeństwa elektrycznego celem uwzględnienia, że źródło napięcia jest stabilne i zgodnie z Wymogami określonymi dla urządzeń.
- Urządzenie należy transportować, używać i przechowywać w warunkach o dozwolonym poziomie wilgotności i temperatury. Szczegółowe informacje na temat wilgotności i temperatury roboczej znaleźć można w odpowiedniej specyfikacji technicznej urządzenia.
<