




Overview



Power on: Long press the power key until the device screen lights up.
Off Screen: When screen on, press power key, screen will be turned off.
Resume: Press the power key while system is in sleep mode.
Force restart: Long press the power key for more than 8 seconds, the device will be forced to restart.
Contactless card indicator: Show contactless card reading status.
Notice: If not use device for long time, please power off the device.


How to install printing paper

1. Open printer cover.
2. Install printing paper with printing side up, printing side should contact the printer metal plate.
3. Close the printer cover, heard a "click" sound when well closed.



How to use magnetic card reader


Magnetic card reader located at the top side of the device.
Please keep hands steady when holding the terminal and swiping card.
When swiping card, please make the magnetic strip of the card contact to magnetic block and quickly pass through the slot.
Do not change swipe direction or move card up before finish reading, Bi-direction card swiping is supported.



How to use IC card reader


IC card reader located at right side of the device. Please let metal IC side up when insert IC card into slot. Keep inserting the IC card until feel the card inserted to the end. Do not use strong force to plug the card.

Caution: Do not pull out the card when the transaction is not completed yet.



How to read contactless card

The reading area of the contactless card is located at the top. When reading card, just let the contactless card close to the reading area.
Recommended reading rage is 0-3cm
Please let the card in parallel with reading area for better reading performance.




Package includes

- Device x 1
- Battery x 1
- Power adapter x 1
- USB cable x 1
- Quick Start Guide x 1

SIM Card and TF Card installation instructions

SIM/SAM card installation:
Open the back cover, remove the battery, gently insert the SIM card into the correct card slot according to the instruction.


SIM1 installation:
Push the SIM1 card holder to the end according to "open" direction. then pull up the holder 90°degrees and place the SIM1 card into slot with correct direction , close the holder and shift it toward the direction of"LOCK".



How to install battery

Before use, open the battery cover and install the battery properly.
Install battery: Align the bottom of the battery with the battery compartment, and gently press back cover until locked.

Note: Overexertion should be avoided when installing or removing the battery.



Charging instructions

Plug the charging cable into the Type-C port of the device.

The power indicator will turn red when charging. The red light goes out when fully charged.

Battery tips

1. After receiving the device (including batteries), we recommend customer immediately start to use, if couldn't, store period should not exceed 3 months.
2. Please always charge battery in time after drain. Do not store battery with drain or full condition. We suggest keep battery capacity at around 50% when store.
3. Please use authorized charger to charge. Do not use 3rd party's cradle or adapter.
4. If not use the device for long period of time please keep the battery and the device separately.
5. The battery stored in warehouse, must charge/discharge once every 3 months, keep 60% to 70% capacity.
6. Lithium-ion battery should be stored in a cool, dry, ventilated environment, recommend to store between 0 to 28 °C.
7. Do not use metal to contact or short circuit between two electrodes. Do not put device into overheating, excessive tide or decay environment. Do not squeeze or collision.

Transportation Notice

1. It's forbidden for transport when temperature is higher than 65 °C.
2. The battery needs to be individual packed, do not directly stack without protection. Avoid battery electrodes contact to short circuit.
3. Suggest isolate each battery by bags, paper, foam or other isolation materials before pack in the carton.
4. Fill the room of carton by cushioning material before packing to avoid shaking.

Precautions

1. Read all information in this guide before using the device to ensure safe and proper operation.
2. Please use the accessories that have been approved by this manufacturer and corresponds to this model. Use of any power source, charger, battery, etc. that has not been approved by this manufacturer may cause fire, explosion, or other hazards.
3. Please use device and accessories within the specified temperature range. Equipment failure may occur when the ambient temperature is too high or too low.
4. Do not disassemble the product and its accessories. If the equipment or any of its components are not working properly.
5. The battery is made from a flammable and explosive material. Do not disassemble, squeeze, drop and make any other destructive operations on the battery. Do not place the battery in high temperatures.
6. Disposal of used batteries is subject to local relevant documents or policies regarding disposal of used batteries.

Warranty Policy

Thank you for using Urovo smart terminal series products. In the situation of quality problems, which arise from raw materials or production processes, during normal use of purchased products, UROVO TECHNOLOGY LTD. will be responsible for free maintenance within one year from the date of purchase. The company may provide repairs due to the user's failure to use the product according to the provided instructions of the product. However, corresponding service fee and component fee will be charged.

Warranty Terms:

1. Under normal circumstances, the warranty period of the device is 12 months (3 months for accessories), subject to the sales agreement.
2. During the product warranty period, under the normal use conditions (determined by our technical staff), the user will be entitled to a free warranty for damaged or faulty warranty parts.
3. During the warranty period, faults caused by repair, disassembly or modification of the product by a personnel other than our company, improper installation, improper use by the user (failure to follow instructions), serial number damage, accident or natural disaster, will not be covered under the warranty.
4. The warranty will expire immediately if any alterations are made to the warranty card.
5. Please show the equipment SN and purchase certificate for repair. The company reserves the right to interpret the above contents.

Place of Origin: Zhu hai Quality Inspector: 02

UROVO TECHNOLOGY LTD.
Website: en.urovo.com

UROVO

Note: The contents of the manual are subject to change without prior notice.

FCC regulatory conformance :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user ' s authority to operate the equipment.

NOTE: Unauthorized modifications could void the user ' s authority to operate the equipment.

RF exposure information:

The SAR limit of FCC is 1.6W/kg(Body-worn, Hotspot), 4.0W/kg(Extremity) averaged over one gram of tissue. Device has also been tested with 10mm(Body-worn), 10mm(Hotspot), 0mm(Extremity) against this SAR limit.