



UniFi[®] | SECURITY GATEWAY XG-8

Enterprise 10G Gateway
Router with DPI

Model: USG-XG-8

QUICK START GUIDE

Introduction

Thank you for purchasing the Ubiquiti Networks® UniFi® Security Gateway XG. This Quick Start Guide is designed to guide you through installation and also includes warranty terms.

Package Contents



UniFi Security Gateway XG



Mounting
Brackets (Qty. 2)



Bracket Screws
(Qty. 8)



Mounting
Screws (Qty. 4)



Cage Nuts
(Qty. 4)



Rubber Feet (Qty. 4)



Power Cord



Quick Start Guide

UniFi Controller System Requirements


- Linux, Mac OS X, or Microsoft Windows 7/8/10
- Java Runtime Environment 7 (or above)
- Web Browser: Google Chrome (Other browsers may have limited functionality)
- UniFi Controller software v5.6 or higher (available at: www.ubnt.com/download/unifi)

! **IMPORTANT:** We strongly recommend using UPS backup and power regulation to prevent equipment damage due to stability issues with local AC power.

TERMS OF USE: All Ethernet cabling runs must use CAT5 (or above). It is the professional installer's responsibility to follow local country regulations and indoor cabling requirements.

Network Requirement


A UniFi Cloud Key or management station running the UniFi Controller software, located either on-site and connected to the same Layer-2 network, or off-site in the cloud or NOC



All UniFi devices support off-site management controllers. For setup details, see the User Guide on our website at: www.ubnt.com/download/unifi

Hardware Overview

Front Panel Ports



Interface	Description
microSD	Reserved for future use.
USB	Reserved for future use.
Console	RJ45 serial console port for Command Line Interface (CLI) management. Use an RJ45-to-DB9 serial console cable, also known as a rollover cable, to connect the <i>Console</i> port to your computer. Then configure the following settings as needed: • <i>Baud rate</i> 115200 • <i>Data bits</i> 8 • <i>Parity</i> NONE • <i>Stop bits</i> 1 • <i>Flow control</i> NONE
SFP+ (Ports 1-8)	SFP+ ports are hot-swappable and support 10 Gbps fiber SFP modules.
RJ45 (Port 0)	RJ45 port supports 10/100/1000 Ethernet connections.

Front Panel System LED



System


State	Status
White	Factory defaults, waiting for integration.
Blue	Successfully integrated into a network and working properly.
Flashing White	Bootup in progress.
Flashing Blue	Firmware upgrade is taking place.

Front Panel LCD Display

LCD Display




Port Screen



Section of LCD	Information Displayed
Ports 1-4, Ports 5-8	Information on each SFP+ port: • Port Speed 1G or 10G  Note: There are two groups of ports: ports 1-4 and ports 5-8. All ports in each group operate at the same speed. For example, if port 1 is set to 1G, then ports 2-4 will also operate at 1G. • Port Number 1 to 8 • Interface Type  - Primary WAN;  - Other WAN; No icon - LAN port • Throughput Upload (blue) and download (green) throughput speeds • / Port is disconnected • X Port is disabled A white outline indicates the currently selected port.
System and SFP+	Information on the selected SFP+ port: • # <port><interface> Port: 1 to 8; Interface: WAN or LAN followed by the WAN/LAN number • IP address(es) assigned to the port • Uptime if port is up; or <i>Disabled</i> or <i>Disconnected</i> if port is down • Number of clients (active connections)
Port 0	Information on RJ45 port 0: • Interface Type  - Primary WAN;  - Other WAN; No icon - LAN port • Throughput Upload (blue) and download (green) throughput speeds • IP address of the Primary WAN

Statistics Screen



Section of LCD	Information Displayed
Statistics	Statistics on uploaded (blue) and downloaded (green) data: • Throughput Total throughput speed in bps/kbps/Mbps/Gbps • Bytes Total bytes (B)* • Packets Total packets* • Bar Graphs Plots of data uploaded and downloaded
System Details	Information on the system: • Host name • IP address of the primary WAN port • Latency in ms for the Primary WAN or selected port • Number of clients (active connections) for the Primary WAN or selected port • CPU and RAM usage percentage (red indicates usage of 90% or greater) • Temperature of CPU in °C (red indicates temperature of 85 °C or greater)

* Units:

k = $2^{10} = 1024$


M = $2^{20} = 1,000,000$

G = $2^{30} = 1,000,000,000$

T = $2^{40} = 1,000,000,000,000$

P = $2^{50} = 1,000,000,000,000,000$

Front Panel Button



Button	Description
Reset	Resets to factory defaults. The UniFi Security Gateway XG should be running after bootup is complete. Press and hold the Reset button for about 10 seconds until the <i>System</i> LED starts flashing and then becomes solidly lit. After a few seconds, the LED will turn off, and the UniFi Security Gateway XG will automatically reboot.

Back Panel



The USG-XG-8 includes one hot-swappable AC/DC PSU module. An optional AC/DC PSU module can be installed in the *PSU 2 Module Bay*.

You also have the option to use a DC/DC PowerModule™, model RPS-DC-100W (sold separately).

 **Note:** There are ventilation holes on the sides of the UniFi Security Gateway XG.

Installation Requirements

- Phillips screwdriver
- Standard-sized, 19" wide rack with a minimum of 1U height available
- For indoor applications, use Category 5 (or above) UTP cabling approved for indoor use.
- For outdoor applications, shielded Category 5 (or above) cabling should be used for all wired Ethernet connections and should be grounded through the AC ground of the power supply.

We recommend that you protect your networks from harmful outdoor environments and destructive ESD events with industrial-grade, shielded Ethernet cable from Ubiquiti Networks. For more details, visit: **www.ubnt.com/toughcable**



WARNING: To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.




Note: Although the cabling can be located outdoors, the UniFi Security Gateway XG itself should be housed inside a protective enclosure.

Hardware Installation

The UniFi Security Gateway XG can be placed on a horizontal surface, mounted on a wall, or mounted on a rack.

! WARNING: FAILURE TO PROVIDE PROPER VENTILATION MAY CAUSE FIRE HAZARD. KEEP AT LEAST 20 MM OF CLEARANCE NEXT TO THE VENTILATION HOLES FOR ADEQUATE AIRFLOW.

1. Attach the *Mounting Brackets* to the UniFi Security Gateway XG.




2. Attach the UniFi Security Gateway XG to the rack using the four *Mounting Screws*. (If the rack has square slots, then use the *Cage Nuts* with the *Mounting Screws*.)



3. Connect the *Power Cord* to the *AC/DC PSU Module*.



4. Connect the other end of the *Power Cord* to a power outlet.



Connecting Ethernet to LAN

Connect a UFiber 10 Gbps SFP+ optical module and fiber optic patch cable to SFP+ port 1.



For detailed instructions on using SFP+ ports, refer to *Using SFP+ Ports*.

Using SFP+ Ports




Note: Each SFP+ port requires a UFiber 10 Gbps SFP+ optical module and a fiber optic patch cable.


For information about compatible fiber SFP+ modules, visit: **community.ubnt.com/unifi**

To use an *SFP+* port:

1. Remove the protective plug covering the *SFP+* port.
2. Plug a compatible fiber module into the *SFP+* port.



3. Connect a fiber optic cable to the fiber module. Then connect the other end of the cable to another fiber device.



640-00305-03

Initial Setup via Bluetooth

Use the UniFi Mobile app to configure the UniFi Security Gateway XG.

1. Download the UniFi Mobile app from the App Store (iOS) or Google Play™ (Android).



2. Enable Bluetooth on your mobile device.
3. Launch the app and hold your mobile device within 1.5 m (5') of the UniFi Security Gateway XG.
4. Follow the on-screen instructions to set up the UniFi Security Gateway XG.

Software Installation


Download the latest version of the UniFi Controller software at: **www.ubnt.com/download/unifi**

From a management station connected to the same Layer-2 network, launch the installer and follow the on-screen instructions.



Note: If you already have UniFi Controller v5.6 or higher installed, go to the section, *Adopting the UniFi Security Gateway XG*.

After you have installed the software and run the UniFi Setup Wizard, a login screen will appear for the UniFi Controller management interface. Enter the *Admin Name* and *Password* that you created in the UniFi Setup Wizard. Then click **Login**.



You can manage your network and view network statistics using the UniFi Controller management interface. For information on using the UniFi Controller software, refer to the User Guide located on our website at:
www.ubnt.com/download/unifi

Configuring the WAN and LAN Interfaces Before Adoption

Prior to adopting the UniFi Security Gateway XG, you can access its Configuration Interface via a web browser to configure the WAN and LAN interfaces and the inform URL.

By default, the *WAN* port is set to *DHCP* so it can obtain its network settings from the service provider. The *LAN* port is set to a static IP of 192.168.1.1/24 with *DHCP Server* enabled.


If the UniFi controller is on the local network, access the Configuration Interface and configure the LAN port's *IP Address* to be on the same subnet as your controller.

To change the interface settings, connect a computer (through a switch) to SFP+ port 1 of the UniFi Security Gateway XG.


1. From a web browser, go to: **https://setup.ubnt.com**



2. The UniFi Security Gateway XG *Settings* window will appear. Click **Configuration** to continue.



3. In the *Configuration* window, configure the *WAN Settings*, *LAN Settings*, and *Inform URL* as needed.



4. Click **Apply Changes** to save the changes.

Adopting the UniFi Security Gateway XG

1. From the UniFi Controller dashboard, click **Devices** in the left menu bar.



2. On the *Devices* screen, locate the UniFi Security Gateway XG in the list of devices under the *Model* column. To adopt it, click **Adopt**.

The screenshot shows the 'DEVICES' screen in the UniFi Controller. It displays a table of devices with columns for Name, IP Address, Model, Version, and Actions. The 'Model' column lists various UniFi Security Gateway XG models. The 'Actions' column contains an 'Adopt' button for each device.

Name	IP Address	Model	Version	Actions
UniFi Security Gateway XG	192.168.1.1	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.2	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.3	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.4	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.5	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.6	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.7	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.8	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.9	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.10	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.11	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.12	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.13	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.14	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.15	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.16	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.17	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.18	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.19	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.20	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.21	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.22	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.23	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.24	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.25	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.26	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.27	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.28	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.29	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.30	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.31	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.32	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.33	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.34	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.35	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.36	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.37	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.38	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.39	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.40	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.41	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.42	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.43	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.44	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.45	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.46	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.47	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.48	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.49	UniFi Security Gateway XG	3.1.0.0	Adopt
UniFi Security Gateway XG	192.168.1.50	UniFi Security Gateway XG	3.1.0.0	Adopt

3. The System LED on the UniFi Security Gateway XG will turn blue to confirm that it is successfully adopted.

Specifications

USG- XG-8	
Dimensions	442.4 x 285.6 x 43.7 mm (17.42 x 11.24 x 1.72")
Weight	4.435 kg (9.78 lb)
With Mount Brackets	4.535 kg (9.98 lb)
Max. Power Consumption	AC/DC 100W
Power Supply	(2) Hot-Swappable AC/DC or DC/DC 100W PSU (1 AC/DC PSU Included)
Supported Voltage Range	100 - 240VAC
System LED	Status
LCD	4.7" Wide-Viewing Angle True Color TFT-LCD Touch Screen
Processor	MIPS64 16-Core, 1.8 GHz
System Memory	16 GB DDR4 RAM
On-Board Flash Storage	4 GB
Rackmount	Yes, 1U
ESD/EMP Protection	Air: ± 24 kV, Contact: ± 24 kV
Operating Temperature	-5 to 40° C (23 to 104° F)
Operating Humidity	5 to 95% Noncondensing
Certifications	CE, FCC, IC
Interfaces	
Networking	(8) 10 Gbps SFP+ Ports, (1) 1 Gbps RJ45 Ethernet Port
Management	(1) RJ45 Ethernet In-Band, (1) RJ45 Serial Out-of-Band, (1) Bluetooth 4.0

Safety Notices

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer.

 **WARNING:** Failure to provide proper ventilation may cause fire hazard. Keep at least 20 mm of clearance next to the ventilation holes for adequate airflow.

 **WARNING:** To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

 **WARNING:** Do not use this product in location that can be submerged by water.

 **WARNING:** Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

Electrical Safety Information

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
 - a. Do not substitute the power cord with one that is not the provided approved type. Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
 - b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
 - c. Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
 - d. Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.
 - e. Protective bonding must be installed in accordance with local national wiring rules and regulations.

Limited Warranty

UBIQUITI NETWORKS, Inc (“UBIQUITI NETWORKS”) warrants that the product(s) furnished hereunder (the “Product(s)”) shall be free from defects in material and workmanship for a period of one (1) year from the date of shipment by UBIQUITI NETWORKS under normal use and operation. UBIQUITI NETWORKS’ sole and exclusive obligation and liability under the foregoing warranty shall be for UBIQUITI NETWORKS, at its discretion, to repair or replace any Product that fails to conform to the above warranty during the above warranty period. The expense of removal and reinstallation of any Product is not included in this warranty. The warranty period of any repaired or replaced Product shall not extend beyond its original term.

Warranty Conditions

The above warranty does not apply if the Product:

- (I) has been modified and/or altered, or an addition made thereto, except by Ubiquiti Networks, or Ubiquiti Networks’ authorized representatives, or as approved by Ubiquiti Networks in writing;
- (II) has been painted, rebranded or physically modified in any way;
- (III) has been damaged due to errors or defects in cabling;
- (IV) has been subjected to misuse, abuse, negligence, abnormal physical, electromagnetic or electrical stress, including lightning strikes, or accident;
- (V) has been damaged or impaired as a result of using third party firmware;
- (VI) has no original Ubiquiti MAC label, or is missing any other original Ubiquiti label(s); or
- (VII) has not been received by Ubiquiti within 30 days of issuance of the RMA.

In addition, the above warranty shall apply only if: the product has been properly installed and used at all times in accordance, and in all material respects, with the applicable Product documentation; all Ethernet cabling runs use CAT5 (or above), and for outdoor installations, shielded Ethernet cabling is used, and for indoor installations, indoor cabling requirements are followed.

Returns

No Products will be accepted for replacement or repair without obtaining a Return Materials Authorization (RMA) number from UBIQUITI NETWORKS during the warranty period, and the Products being received at UBIQUITI NETWORKS’ facility freight prepaid in accordance with the RMA process of UBIQUITI NETWORKS. Products returned without an RMA number will not be processed and will be returned freight collect or subject to disposal. Information on the RMA process and obtaining an RMA number can be found at: **www.ubnt.com/support/warranty**

Disclaimer

EXCEPT FOR ANY EXPRESS WARRANTIES PROVIDED HEREIN, UBIQUITI NETWORKS, ITS AFFILIATES, AND ITS AND THEIR THIRD PARTY DATA, SERVICE, SOFTWARE AND HARDWARE PROVIDERS HEREBY DISCLAIM AND MAKE NO OTHER REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, REPRESENTATIONS, GUARANTEES, OR WARRANTIES OF MERCHANTABILITY, ACCURACY, QUALITY OF SERVICE OR RESULTS, AVAILABILITY, SATISFACTORY QUALITY, LACK OF VIRUSES, QUIET ENJOYMENT, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT AND ANY WARRANTIES ARISING FROM ANY COURSE OF DEALING, USAGE OR TRADE PRACTICE IN CONNECTION WITH SUCH PRODUCTS AND SERVICES. BUYER ACKNOWLEDGES THAT NEITHER UBIQUITI NETWORKS NOR ITS THIRD PARTY PROVIDERS CONTROL BUYER'S EQUIPMENT OR THE TRANSFER OF DATA OVER COMMUNICATIONS FACILITIES, INCLUDING THE INTERNET, AND THAT THE PRODUCTS AND SERVICES MAY BE SUBJECT TO LIMITATIONS, INTERRUPTIONS, DELAYS, CANCELLATIONS AND OTHER PROBLEMS INHERENT IN THE USE OF COMMUNICATIONS FACILITIES. UBIQUITI NETWORKS, ITS AFFILIATES AND ITS AND THEIR THIRD PARTY PROVIDERS ARE NOT RESPONSIBLE FOR ANY INTERRUPTIONS, DELAYS, CANCELLATIONS, DELIVERY FAILURES, DATA LOSS, CONTENT CORRUPTION, PACKET LOSS, OR OTHER DAMAGE RESULTING FROM ANY OF THE FOREGOING. In addition, UBIQUITI NETWORKS does not warrant that the operation of the Products will be error-free or that operation will be uninterrupted. In no event shall UBIQUITI NETWORKS be responsible for damages or claims of any nature or description relating to system performance, including coverage, buyer's selection of products (including the Products) for buyer's application and/or failure of products (including the Products) to meet government or regulatory requirements.

Limitation of Liability

EXCEPT TO THE EXTENT PROHIBITED BY LOCAL LAW, IN NO EVENT WILL UBIQUITI OR ITS SUBSIDIARIES, AFFILIATES OR SUPPLIERS BE LIABLE FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL OR OTHER DAMAGES (INCLUDING LOST PROFIT, LOST DATA, OR DOWNTIME COSTS), ARISING OUT OF THE USE, INABILITY TO USE, OR THE RESULTS OF USE OF THE PRODUCT, WHETHER BASED IN WARRANTY, CONTRACT, TORT OR OTHER LEGAL THEORY, AND WHETHER OR NOT ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Note

Some countries, states and provinces do not allow exclusions of implied warranties or conditions, so the above exclusion may not apply to you. You may have other rights that vary from country to country, state to state, or province to province. Some countries, states and provinces do not allow the exclusion or limitation of liability for incidental or consequential damages, so the above limitation may not apply to you. EXCEPT TO THE EXTENT ALLOWED BY LOCAL LAW, THESE WARRANTY TERMS DO NOT EXCLUDE, RESTRICT OR MODIFY, AND ARE IN ADDITION TO, THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE LICENSE OF ANY SOFTWARE (EMBEDDED IN THE PRODUCT) TO YOU. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to any transactions regarding the sale of the Products.

Compliance

FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This radio transmitter (FCC: SWX-USGXG) has been approved by FCC.

ISED Canada

CAN ICES-3(A)/NMB-3(A)

This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This radio transmitter (IC: 6545A-USGXX) has been approved by ISED Canada.

CAN ICES-3(A)/NMB-3(A)

Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. l'appareil ne doit pas produire de brouillage;
2. l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le présent émetteur radio (IC : 6545A-USGXX) a été approuvé par ISDE Canada.

RF Exposure Warning

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be located or operating in conjunction with any other antenna or transmitter, except as listed for this product's certification.

Les antennes utilisées pour cet émetteur doit être installé pour fournir une distance de séparation d'au moins 20 cm de toutes les personnes et ne doit pas être situé ou opérant en conjonction avec une autre antenne ou un autre émetteur, sauf dans les cas énumérés à la certification de ce produit.

Australia and New Zealand



Warning: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.



RoHS/WEEE Compliance Statement



English

European Directive 2012/19/EU requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.

Deutsch

Die Europäische Richtlinie 2012/19/EU verlangt, dass technische Ausrüstung, die direkt am Gerät und/oder an der Verpackung mit diesem Symbol versehen ist, nicht zusammen mit unsortiertem Gemeindeabfall entsorgt werden darf. Das Symbol weist darauf hin, dass das Produkt von regulärem Haushaltsmüll getrennt entsorgt werden sollte. Es liegt in Ihrer Verantwortung, dieses Gerät und andere elektrische und elektronische Geräte über die dafür zuständigen und von der Regierung oder örtlichen Behörden dazu bestimmten Sammelstellen zu entsorgen. Ordnungsgemäßes Entsorgen und Recyceln trägt dazu bei, potentielle negative Folgen für Umwelt und die menschliche Gesundheit zu vermeiden. Wenn Sie weitere Informationen zur Entsorgung Ihrer Altgeräte benötigen, wenden Sie sich bitte an die örtlichen Behörden oder städtischen Entsorgungsdienste oder an den Händler, bei dem Sie das Produkt erworben haben.

Español

La Directiva 2012/19/UE exige que los equipos que lleven este símbolo en el propio aparato y/o en su embalaje no deben eliminarse junto con otros residuos urbanos no seleccionados. El símbolo indica que el producto en cuestión debe separarse de los residuos domésticos convencionales con vistas a su eliminación. Es responsabilidad suya desechar este y cualesquiera otros aparatos eléctricos y electrónicos a través de los puntos de recogida que ponen a su disposición el gobierno y las autoridades locales. Al desechar y reciclar correctamente estos aparatos estará contribuyendo a evitar posibles consecuencias negativas para el medio ambiente y la salud de las personas. Si desea obtener información más detallada sobre la eliminación segura de su aparato usado, consulte a las autoridades locales, al servicio de recogida y eliminación de residuos de su zona o pregunte en la tienda donde adquirió el producto.

Français

La directive européenne 2012/19/UE exige que l'équipement sur lequel est apposé ce symbole sur le produit et/ou son emballage ne soit pas jeté avec les autres ordures ménagères. Ce symbole indique que le produit doit être éliminé dans un circuit distinct de celui pour les déchets des ménages. Il est de votre responsabilité de jeter ce matériel ainsi que tout autre matériel électrique ou électronique par les moyens de collecte indiqués par le gouvernement et les pouvoirs publics des collectivités territoriales. L'élimination et le recyclage en bonne et due forme ont pour but de lutter contre l'impact néfaste potentiel de ce type de produits sur l'environnement et la santé publique. Pour plus d'informations sur le mode d'élimination de votre ancien équipement, veuillez prendre contact avec les pouvoirs publics locaux, le service de traitement des déchets, ou l'endroit où vous avez acheté le produit.

Italiano

La direttiva europea 2012/19/UE richiede che le apparecchiature contrassegnate con questo simbolo sul prodotto e/o sull'imballaggio non siano smaltite insieme ai rifiuti urbani non differenziati. Il simbolo indica che questo prodotto non deve essere smaltito insieme ai normali rifiuti domestici. È responsabilità del proprietario smaltire sia questi prodotti sia le altre apparecchiature elettriche ed elettroniche mediante le specifiche strutture di raccolta indicate dal governo o dagli enti pubblici locali. Il corretto smaltimento ed il riciclaggio aiuteranno a prevenire conseguenze potenzialmente negative per l'ambiente e per la salute dell'essere umano. Per ricevere informazioni più dettagliate circa lo smaltimento delle vecchie apparecchiature in Vostro possesso, Vi invitiamo a contattare gli enti pubblici di competenza, il servizio di smaltimento rifiuti o il negozio nel quale avete acquistato il prodotto.

Declaration of Conformity

български [Bulgarian] С настоящото UBIQUITI NETWORKS декларира, че този тип радиосъоръжение USG-XG-8 е в съответствие с Директива 2014/53/ЕС. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: **www.ubnt.com/compliance**

Hrvatski [Croatian] UBIQUITI NETWORKS ovime izjavljuje da je radijska oprema tipa USG-XG-8 u skladu s Direktivom 2014/53/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: **www.ubnt.com/compliance**

Čeština [Czech] Tímto UBIQUITI NETWORKS prohlašuje, že typ rádiového zařízení USG-XG-8 je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese: **www.ubnt.com/compliance**

Dansk [Danish] Hermed erklærer UBIQUITI NETWORKS, at radioudstyrstypen USG-XG-8 er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: **www.ubnt.com/compliance**

Nederlands [Dutch] Hierbij verklaar ik, UBIQUITI NETWORKS, dat het type radioapparatuur USG-XG-8 conform is met Richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: **www.ubnt.com/compliance**

English Hereby, UBIQUITI NETWORKS declares that the radio equipment type USG-XG-8 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: **www.ubnt.com/compliance**

Eesti keel [Estonian] Käesolevaga deklareerib UBIQUITI NETWORKS, et käesolev raadioseadme tüüp USG-XG-8 vastab direktiivi 2014/53/EÜ nõuetele. EÜ vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: **www.ubnt.com/compliance**

Suomi [Finnish] UBIQUITI NETWORKS vakuuttaa, että radiolaitetyypin USG-XG-8 on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksti on saatavilla seuraavassa internetosoitteessa: **www.ubnt.com/compliance**

Français [French] Le soussigné, UBIQUITI NETWORKS, déclare que l'équipement radioélectrique du type USG-XG-8 est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: **www.ubnt.com/compliance**

Deutsch [German] Hiermit erklärt UBIQUITI NETWORKS, dass der Funkanlagentyp USG-XG-8 der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: **www.ubnt.com/compliance**

Ελληνικά [Greek] Με την παρούσα ο/η UBIQUITI NETWORKS, δηλώνει ότι ο ραδιοεξοπλισμός USG-XG-8 πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: **www.ubnt.com/compliance**

Magyar [Hungarian] UBIQUITI NETWORKS igazolja, hogy a USG-XG-8 típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: **www.ubnt.com/compliance**

Íslenska [Icelandic] Hér með lýsir UBIQUITI NETWORKS yfir því að USG-XG-8 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 2014/53/EU. Fullur texti ESB samræmisýfirlýsing er að finna á eftirfarandi netfangi: **www.ubnt.com/compliance**

Italiano [Italian] Il fabbricante, UBIQUITI NETWORKS, dichiara che il tipo di apparecchiatura radio USG-XG-8 è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: **www.ubnt.com/compliance**

Latvīu kalba [Latvian] Ar šo UBIQUITI NETWORKS deklarē, ka radioiekārta USG-XG-8 atbilst Direktīvai 2014/53/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: **www.ubnt.com/compliance**

Lietuvių kalba [Lithuanian] Aš, UBIQUITI NETWORKS, patvirtinu, kad radijo įrenginių tipas USG-XG-8 atitinka Direktivą 2014/53/ES. Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: **www.ubnt.com/compliance**

Malti [Maltese] B'dan, UBIQUITI NETWORKS, niddikja li dan it-tip ta' tagħmir tar-radju USG-XG-8 huwa konformi mad-Direttiva 2014/53/UE. Id-dikjarazzjoni tal-konformità tista' tiġi kkonsultata minn **www.ubnt.com/compliance**

Norsk [Norwegian] UBIQUITI NETWORKS erklærer herved at utstyret USG-XG-8 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 2014/53/EU. Den fulle teksten til EU-samsvarserklæringen er tilgjengelig på følgende internettadresse: **www.ubnt.com/compliance**

Polski [Polish] UBIQUITI NETWORKS niniejszym oświadcza, że typ urządzenia radiowego USG-XG-8 jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: **www.ubnt.com/compliance**

Português [Portuguese] O(a) abaixo assinado(a) UBIQUITI NETWORKS declara que o presente tipo de equipamento de rádio USG-XG-8 está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: **www.ubnt.com/compliance**

Română [Romanian] Prin prezenta, UBIQUITI NETWORKS declară că tipul de echipamente radio USG-XG-8 este în conformitate cu Directiva 2014/53/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: **www.ubnt.com/compliance**

Slovenčina [Slovak] UBIQUITI NETWORKS týmto vyhlasuje, že rádiové zariadenie typu USG-XG-8 je v súlade so smernicou 2014/53/EÚ. Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: **www.ubnt.com/compliance**

Slovenščina [Slovenian] UBIQUITI NETWORKS potrjuje, da je tip radijske opreme USG-XG-8 skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: **www.ubnt.com/compliance**

Español [Spanish] Por la presente, UBIQUITI NETWORKS declara que el tipo de equipo radioeléctrico USG-XG-8 es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: **www.ubnt.com/compliance**

Svenska [Swedish] Härmed försäkrar UBIQUITI NETWORKS att denna typ av radioutrustning USG-XG-8 överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: **www.ubnt.com/compliance**

Online Resources

Website www.ubnt.com

Support help.ubnt.com

Community community.ubnt.com

Downloads downloads.ubnt.com

Ubiquiti Networks, Inc.
685 Third Avenue, 27th Floor
New York, NY 10017
USA



©2016-2017 Ubiquiti Networks, Inc. All rights reserved. Ubiquiti, Ubiquiti Networks, the Ubiquiti U logo, the Ubiquiti beam logo, TOUGHCable, and UniFi are trademarks or registered trademarks of Ubiquiti Networks, Inc. in the United States and in other countries. All other trademarks are the property of their respective owners.

AI091817