

11 CAUTIONS & WARNINGS

Do not recharge the Battery Pack if it is warm to the touch. Allow the Battery Pack to cool before recharging. Recharging a warm Battery Pack will shorten the life of the Pack.

Recharging batteries should be done by an adult.

Do not charge a damaged, leaking, hot or wet Battery Pack.

When not in use, remove Battery from its compartment.

When not in use, Transformer should be unplugged from the electrical outlet.

Under no circumstance should the Battery Pack be disposed of in fire. This may cause injury, leakage or explosion.

Please dispose of Ni-Cd Battery cells properly.

Do not break open or disassemble the Battery Pack.

Do not use the Battery Pack or Charger for any other reason than charging and running a West Coast Choppers RC Vehicle.

Do not stall the motor during use.

WARNING:
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation of the device.

ATTENTION PARENTS: The Battery Charger & Battery Pack need to be periodically examined for potential hazards and any potential hazardous parts be repaired or replaced.

ITEM NO. 3346/3347

CHEVROLET

LICENSED PRODUCT

GM

WEST COAST CHOPPERS

RC VEHICLES

CAUTION-ELECTRICALLY OPERATED PRODUCT:

NOT RECOMMENDED FOR CHILDREN UNDER 8 YEARS OF AGE AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIONS SHOULD BE OBSERVED DURING HANDLING AND USE TO PREVENT ELECTRIC SHOCK. MODEL 3346/3347 75-76A CUDRA 10/02/2004

Full Function 9.6V Ni-Cd Radio Control Vehicle

OPERATING INSTRUCTIONS

*IMPORTANT: IF VEHICLE DOES NOT RESPOND PROPERLY, PLEASE REPLACE THE 9.6V NI-Cd BATTERY PACK. THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

Cudra

SS Truck

PLEASE DO NOT RETURN TO STORE

For more information or questions, please call Consumer Services: 1-877-FUN-TOYS (1-877-366-6997)

Colors and decorations may vary. Keep content details for future reference.

WWW.WESTCOASTCHOPPERS.COM

We are the West Coast Choppers, Inc. All Rights Reserved. Manufactured and used under license from WestCoast Choppers, L.A. West Coast Choppers and CC, and trademarks of WestCoast Choppers, L.A.

Manufactured & Distributed by © 2005 Planet Toys Inc. NY, NY 10010 All Rights Reserved. MADE IN CHINA

www.planettoysltd.com

042005

3 CHARGING THE BATTERY PACK

IMPORTANT: The included 9.6V NiCd Battery is not charged, please charge prior to use.

Standard 110/120V Household electrical outlet

Transformer

Battery Plug

9.6V Ni-Cd Battery Pack

Transformer Plug

1. First, plug the Transformer into a Standard 110/120V Household electrical outlet.

2. Plug the 9.6V Ni-Cd battery into charger.

3. Charge the Battery for about four hours.

NOTE: Leaving the Battery in the Charger will not increase the life of your battery.

4. After charging and during use, the Battery Pack will become warm.

IMPORTANT: Please allow the Battery Pack to cool prior to recharging. Charging before doing so will greatly reduce the life of the Battery.

4 BATTERY PACK INSTALLATION

1. Unscrew the battery cover

2. Plug the 9.6V Ni-Cd battery into battery box.

3. Replace the battery compartment cover and tighten the screw.

7 CONTROLLER ON/OFF SWITCH

Power Switch

1. On back of Controller, locate On/Off switch.

2. Slide switch either to the left or right to turn on and off.

8 OPERATING THE VEHICLE

Forward

LED light

LED light will glow RED when the power is on. LED that is off indicates that the power is off.

Left

Backward

Burn-Out Feature

Right

ON/OFF SWITCH, ALIGNMENT CONTROL

On/Off Switch

Alignment Control Dial

Alignment Control

The Alignment Control Dial is located between the front wheels. If the vehicle begins to pull to the left, adjust the trim control towards the "R" marking. If the vehicle pulls to the right while driving, adjust the trim control towards the "L" markings.

PROPER USE, PRECAUTIONS & CARE

1.The Toy can perform better on a vinyl floor. Thick carpets are not recommended since carpet does not provide suitable traction and lint from the carpet may damage vehicle.

2.Operating multiple vehicles with the same frequency in close proximity will cause interference and poor performance.

FCC CAUTION: The manufacturer is not responsible for the radio interference caused by unauthorized frequency modification to this equipment. Such modifications could void the user's authority to operate the equipment.

3.Works best away from high voltage power lines, large buildings and walls.

4.Hold the controller antenna up for the best performance.

5.When the product does not respond, slows down, or loses range, replace the batteries.

6.This product is not recommended for use on loose dirt or wet surface.

7.Do not immerse in water.

1 TABLE OF CONTENTS

PAGE 1: Table of Contents.
PAGE 2: Chopper Checklist.
PAGE 3: Charging the 9.6V Ni-Cd Battery Pack.
PAGE 4: Battery Pack Installation.
PAGE 5: Controller Battery Installation.
PAGE 6: Setting up the Oil Burnout Feature.
PAGE 7: Controller ON/OFF switch.
PAGE 8: Operating the Vehicle, Proper Use, Precautions & Care.
PAGE 9: CUDRA & SS Features and Functions.
PAGE 10: Please note and troubleshooting.
PAGE 11: Caution, Warning & Attention Parents.

2 CHOPPER CHECKLIST

IMPORTANT: THE INCLUDED 9.6V NI-Cd BATTERY PACK IS NOT CHARGED PRIOR TO SHIPMENT AND MUST BE CHARGED BEFORE USE.

To prevent damage, the contents of the package that are listed below have been packed in the styrofoam tray and may be out of plain sight. Please remove all contents from the tray.

VEHICLE

CUDA

SS TRUCK

CONTROLLER (1 9V Battery Included)

9.6 Ni-Cd BATTERY

1 "9V" BATTERY

NI-Cd BATTERY CHARGER

BURN-OUT OIL

Caution: Don't fill any oil or other liquid other than our provided specific smoke oil

5 CONTROLLER BATTERY INSTALLATION

1. On the back of the Controller, locate the Battery Compartment.

2. Unscrew the Battery Compartment Cover.

3. Insert 1 "9V" size alkaline batteries. Make sure the plus (+) and minus (-) markings on the battery match up with the plus (+) and minus (-) markings inside the Battery Compartment.

4. Replace the Battery Compartment Cover and tighten the screw.

Insert 9V Battery (W/ 22.5-00007) Here

Unscrew the battery cover

Tighten Screw

FOR BEST RESULTS:

1. Do not mix old and new batteries

2. Do not mix alkaline, standard or rechargeable batteries.

3. Use alkaline batteries only.

NOTE: Replace with Alkaline Batteries for longest life and best performance. Remember to take out all the batteries from the vehicle and the controller if the vehicle will not be used for a long time.

6 OIL BURN-OUT FEATURE

TIP: To have a better smoke effect, press and hold the burnout firmly and continuously to have big amount of smoke, if the smoke effect still can't appear, please check the smoke oil level from the bottom of car transparent tank.

CUDA

1. Carefully turn the vehicle upside down and locate the oil compartment found on the bottom of the vehicle chassis.

2. Use the tip of bottle to press down the spring ball and fill the smoke oil into the hole from the bottle

Oil Compartment

SS TRUCK

1. Carefully turn the vehicle upside down and locate the oil compartment found on the bottom of the vehicle chassis.

2. Use the tip of bottle to press down the spring ball and fill the smoke oil into the hole from the bottle

Oil Compartment

9 CUDRA FEATURES

WORKING HEADLIGHTS

Lights will glow while driving forward.

WORKING TAILLIGHTS

Lights will glow while driving backward.

BURN OUT FEATURE

Rear body of car will rise and burn-out when burn-out button is activated.

SS TRUCK FEATURES

WORKING HEADLIGHTS

Lights will glow while driving forward.

WORKING TAILLIGHTS

Lights will glow while driving backward.

BURN OUT FEATURE

Rear body of car will rise and burn-out when burn-out button is activated.

10 PLEASE NOTE & TROUBLESHOOTING

PLEASE NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna

- Increase the separation between the equipment and receiver

- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.

- Consult the dealer or an experienced radio/TV technician for help

TROUBLE SHOOTING

Problems	Reasons	Solution
Running problems	The battery inside the radio control unit is too weak.	Replace with new alkaline batteries inside the control unit.
	There is a weak or low reception for the radio control.	
Operation problems	The rechargeable battery inside the vehicle is too weak.	Recharge the 9.6V Ni-Cd Battery Pack.
	A small object obstructs movement of the tire or axle.	Use tweezers or a paper clip to remove obstruction.
Other	The vehicle was driven on the carpet and has fabric threads caught in the axle.	Playing on the carpet is not recommended.
	The vehicle does not respond to the radio control.	Try playing at another location.
Other	The radio control's frequency is disrupted by something around the environment.	Some other equipment using the same radio wave could disrupt the radio control. Either play in another location or turn off other equipment. If you are planning to race your vehicles with another friend, purchase vehicles with 2 different frequencies (49MHz and 27MHz) to avoid disruption