Yealink

Certified for Microsoft Teams

How-to video

BHD762
Bluetooth Headset



Quick Start Guide V1.3

Please update the headset to the latest version via Yealink USB Connect (PC) or Yealink Connect (APP) before using.


1 Package List



BHD762



USB 2.0 Cable (USB-A to USB-C)



BT51-A Dongle or BT51-C Dongle



Carrying Case



BHC76 Wireless Charging Stand

Power Adapter


Optional



Quick Start Guide


Note: We recommend that you use the included accessories, and other accessories may have compatibility issues that prevent them from working properly.

2 Charging




Note:
We recommend to fully charge the headset when using it for the first time. The BHC76 is compatible with devices that support QI wireless charging, such as wireless charging mobile phones and headsets.


LED Indicator Status



Note: It takes two hours for USB charging and three hours for wireless charging to be fully charged.


3 Power on/off






4 Pairing and Connecting Device

No Built-in Bluetooth Device




Built-in Bluetooth Device


Step1: Enter Pairing Mode



Step2: Select the Headset from Your Bluetooth Device




5 Call Controls and Busylight




Note: Only the Teams edition can connect to Teams.


6 Music Controls



7 Customers Button



8 Sound Control




Note:
- You can set the level of noise cancellation on Yealink USB Connect (desktop client) or Yealink Connect (mobile app).
- If you are in Noise Canceling mode, you might not hear the ambient sound. It depends on ambient conditions and the type or volume of audio playback Do not use the headset in places where the inability to hear ambient sounds would be dangerous.

9 Replace Ear Cushions



10 Software Management


Yealink USB Connect (PC)



Download it from the Yealink website https://www.yealink.com/product/yuc.

Note: It needs to be used with Yealink USB Connect of version 0.34.x.x or higher.

Yealink Connect App (Mobile)



Apple and the Apple logo are trademarks of Apple Inc.

Download the Yealink Connect App from IOS App Store or Android App Store.

Notes for BHC76 (optional)

1. Please use the power adapter provided by Yealink to get a more efficient charging experience.
2. Please do not place any metal and magnetic cards on the charging board to avoid abnormalities and damage to the charger.
3. Please do not charge too far away from the charging sign to get a more efficient charging experience.
4. During use, if you find the charging board or the charged device is overheated and the charging stops (the indicator light keeps flashing), you need to remove the charged device until it cools down, and then try charging again.
5. The indicator light of the charging stand keeps flashing, and it may be the following three situations:
   - The location of the charged device is not placed correctly. You need to replace the it. After calibrating the charging position, you can charge the device normally until the indicator light is always on.
   - The charging stand has an overheating alarm. After the mobile phone or the charging stand cools down, it will stop flashing automatically and enter the normal charging state.
   - Metal or magnetic cards may be placed on the charging board, and please remove them.

Safety Guide for BHC76 (optional)

1. Do not disassemble the product by yourself or bring it near fire and water to avoid short circuit leakage or damage to the product.
2. Do not use the product in high temperature, humidity, and corrosive environment to avoid damaging the circuit and causing failure to charge or other failures.
3. Do not expose the product to corrosive liquids. Otherwise, it will cause severe damage.
4. Do not disassemble or re-equip the product for any reason to avoid secondary failure and burnout.
5. Do not place the product below -10°C or above 60°C.
6. Do not knock, throw or shake the product because rough methods will damage the internal circuit board structure.

If you need to know the product warranty information, please visit https://ams.yealink.com.

About Yealink

Yealink (Stock Code: 300628) is a global brand that specializes in video conferencing, voice communications and collaboration solutions with best-in-class quality, innovative technology and user-friendly experience. As one of the best providers in more than 140 countries and regions, Yealink ranks No.1 in the global market share of SIP phone shipments (Global IP Desktop Phone Growth Excellence Leadership Award Report, Frost & Sullivan, 2019).

Copyright

Copyright © 2023 YEALINK(XIAMEN) NETWORK TECHNOLOGY CO., LTD.

All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of Yealink(Xiamen) Network Technology CO., LTD.

Technical Support

Visit Yealink WIKI (http://support.yealink.com/) for firmware downloads, product documents, FAQ, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (https://ticket.yealink.com) to submit all your technical issues.

430104002245

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.
Web: www.yealink.com
Addr: No.666 Hu'an Rd,Huli District Xiamen City, Fujian, P.R. China
Copyright©2023 Yealink Inc. All rights reserved.

Yealink

Certified for Microsoft Teams

BHD762
蓝牙耳机



快速使用指南 V1.3

首次使用前，建议通过 Yealink USB Connect（电脑端）或 Yealink Connect（手机端）将设备升级到最新版本。

1 包装清单



BHD762



USB 2.0 线
(USB-A 转 USB-C)



或

BT51-A 或 BT51-C
蓝牙适配器



BHC76 无线
充电底座



电源适配器

可选




便携包




快速入门指南

说明：我们建议您使用自带的配件，其他配件可能存在兼容性问题，无法正常工作。

2 充电



USB 充电




对准可充电区域

无线充电（可选）


说明：
首次使用时建议将耳机充满电。
BHC76 兼容支持 Qi 无线充电的设备，如无线充电手机、耳机。

LED 状态指示灯



说明：USB 充满电需要两个小时，无线充电需要三个小时才能充满。


3 开 / 关机






4 配对与设备连接

无蓝牙设备




内置蓝牙设备


第一步：进入配对模式




第二步：从蓝牙设备列表中选择耳机




5 通话控制与忙碌指示灯






说明：只有 Teams 版本支持与 Teams 建立连接。


6 音乐控制



7 客户键



8 声音控制




说明：
- 降噪模式级别可以在 Yealink USB Connect（电脑端）或者 Yealink Connect（移动端）设置。
- 在开启降噪模式可能听不到环境声音，具体取决于环境状况和音频播放的类型 / 音量。请勿在因无法听到环境声音就会造成危险的地方使用耳机。

9 更换耳罩



10 软件管理

Yealink USB Connect（电脑端）



从亿联网站 https://www.yealink.com/product/yuc 下载。

说明：需要搭配 0.34.x.x 或更高版本的 Yealink USB Connect 使用。

Yealink Connect App（移动端）



Apple 和 Apple 标志是 Apple Inc. 的商标。

从 iOS 系统 或 Android 系统的应用商店下载 Yealink Connect App。

BHC76 说明

1. 为了让您得到更高效的充电体验，请使用提供的电源适配器。
2. 请勿在充电板上放金属杂物或磁卡，避免充电底座异常或损坏。
3. 为了让您得到更高效的充电体验，充电设备请勿离充电闪电标志太远。
4. 使用过程中如遇到充电板或充电设备过热导致停止充电（指示灯一直闪烁），请取下充电设备，待冷却后，重新尝试充电。
5. 指示灯一直闪烁，可能下面三种情况：
   - 位置没放置好，重新放置充电设备校准位置后直到指示灯常亮，正常充电。
   - 为保证一定的安全，充电底座具有过热报警，待手机或充电设备自身冷却后，会自动消除闪烁情况，进入正常充电状态。
   - 充电板上放金属杂物或磁卡，需取下金属物或磁卡。

BHC76 安全须知

1. 请勿将本产品自行拆卸或投入火中、水中，避免造成短路漏电或损坏产品。
2. 请勿在高温、潮湿或腐蚀性环境下使用本产品，避免损坏电路导致不能充电或其它故障。
3. 请勿将产品接触腐蚀性液体，否则会造成严重损坏。
4. 请勿以任何理由拆卸或改装本产品，避免造成二级故障及烧毁。
5. 请勿将产品置于小于 -10°C或者大于 60°C。
6. 请勿敲打、扔掷或强烈震动本产品，粗暴方式会损坏内部电路板结构。

如需了解产品保修信息，请访问 https://ams.yealink.com。

