


Yealink

Certified for
Microsoft Teams

Smart Business Phone MP55 E2

—Teams® Edition




English | Chinese

Quick Start Guide (V1.0)

Package Contents


The following items are included in your package. If you find anything missing, contact your system administrator.



⚠ **Note:** We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in reduced performance.


Assembling the Phone

1. Attach the stand, as shown below:




⚠ **Note:** You can also mount the phone to a wall. For more information on how to attach the wall mount bracket, refer to Yealink Wall Mount Quick Installation Guide for Yealink IP Phones.

2. Connect the handset and optional headset, as shown below:




3. Connect the USB flash drive, as shown below:



⚠ **Note:** The USB port can also be used to connect other USB devices, such as EXP55, USB headset, EHS40 and so on.


4. Connect the network and power, as shown below:

You have two options for network and power connections. Your system administrator will advise you which one to use.



⚠ **Note:**The IP phone should be used with Yealink original power adapter (5V/2A) only. The use of the third-party power adapter may cause the damage to the phone. If you are connecting a PC to your phone, we recommend that you use the Ethernet cable provided by Yealink.If inline power (PoE) is provided, you don't need to connect the power adapter. Make sure the hub/switch is PoE-compliant.

Hardware Component Instructions




	Item
1	Reversible Handset Hook
2	Speaker
3	Navigation Keys and OK Key
4	Cancel Key
5	Volume Key
6	Power LED Indicator
7	Line Keys
8	Soft Keys
9	Touch function keys (Teams Button/Headset Key/Mute Key/Pagination Key)
10	Keypad
11	Hold Key
12	Transfer Key
13	Redial Key
14	Speakerphone Key
15	USB 2.0 Type-A port (DC 5V/0.5A)
16	PC Port/Internet Port/Power Port
17	Security Slot
18	RJ9 Handset Port/RJ9 Headset Port

Adjusting the handset hook

The IP phone is packaged with the handset hook from desk mount position. Before mounting the IP phone to a wall, you must set the handset hook to wall mount position.

To adjust the handset hook:


1. Pull the handset hook in the handset cradle.
2. Rotate the handset hook 180 degrees.
3. Reinsert the handset hook.



The handset hook has a lip which allows the handset to stay on-hook when the IP phone is mounted vertically.

包装清单


包装箱包含以下配件。如果发现遗失任何配件，请联系你的系统管理员。



❗ 说明：我们推荐使用由亿联提供或经亿联认可的配件。使用未经认可的第三方配件可能会导致性能的下降。


安装话机

1. 安装底座：




❗ 说明：你也可以将话机安装在墙上。想要了解更多关于挂墙式的安装信息，请参阅 Yealink Wall Mount Quick Installation Guide for Yealink IP Phones。

2. 连接手柄和耳麦(可选):




3. 连接 U 盘, 如下图:



❗ 说明: USB 端口还可用于连接其他 USB 设备, 如 EXP55、USB 耳机、EHS40 等。


4. 连接网络和电源(可选):

对于网络和电源连接,你有两种选择。你的系统管理员将建议你使用哪一个。



⚠ 说明：我们要求使用亿联原装电源(5V/2A)，使用第三方电源可能会导致话机损坏。如果你的话机需要与 PC 机相连，建议使用 Yealink 标配的网线。如果使用 PoE 供电方式，话机不需要连接电源适配器，确保交换机 / 集线器支持 PoE 供电。

硬件介绍




名称	
1	手柄挂钩
2	扬声器
3	导航键和确定键
4	取消键
5	音量调节键
6	电源指示灯
7	线路键
8	软按键
9	触摸功能键 (Teams 键 / 耳机键 / 静音键 / 翻页键)
10	键盘
11	保持键
12	通话转接键
13	重拨键
14	免提键
15	USB 2.0 A 型端口 (直流 5V/0.5A)
16	PC 端口 / 互联网端口 / 电源端口
17	安全锁孔
18	RJ9 听筒端口 / RJ9 耳机端口

调整手柄挂钩

出厂时，话机的手柄挂钩默认设置为适合桌面安装的位置。在将话机安装到墙上之前，必须将手柄挂钩设置为壁挂位置。

调整手柄挂钩：

1. 将话机的手柄挂钩拉出。
2. 将话机的手柄挂钩旋转 180 度。
3. 重新插入话机的手柄挂钩。



话机的手柄挂钩有一个凸边，使得当话机垂直安装时，听筒能够保持挂断状态。

Regulatory Notices

Operating Ambient Temperatures

- Operating temperature: +32 to 104°F (0 to 40°C)
- Relative humidity: 5% to 90%, noncondensing
- Storage temperature: -22 to +158°F (-30 to +70°C)

Warranty

Our product warranty is limited only to the unit itself, when used normally in accordance with the operating instructions and the system environment. We are not liable for damage or loss resulting from the use of this product, or for any claim from a third party. We are not liable for problems with Yealink device arising from the use of this product; we are not liable for financial damages, lost profits, claims from third parties, etc., arising from the use of this product.

Explanation of the symbols

- DC symbol (Apply for DC powered products)
- is the DC voltage symbol.
- WEEE Warning symbol



To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, and users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol.

Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Restriction of Hazardous Substances Directive (RoHS)

This device complies with the requirements of the EU RoHS Directive. Statements of compliance can be obtained by contacting support@yealink.com.

Safety Instructions

Save these instructions. Read these safety instructions before use!



General Requirements

- Before you install and use the device, read the safety instructions carefully and observe the situation during operation.
- During the process of storage, transportation, and operation, please always keep the device dry and clean, avoid collision and crash.
- Please attempt not to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair.
- Please refer to the relevant laws and statutes while using the device. Legal rights of others should be respected as well.



Environmental Requirements

- Do not cover ventilation openings, this equipment is not intended to be used on soft support.
- The marking information is located at the exterior of the bottom.
- Place the device at a well-ventilated place. Do not expose the device under direct sunlight.
- Keep the device dry and free of dusts.
- Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials.
- Keep the device away from any heat source or bare fire, such as a candle or an electric heater.



Operating Requirements

- Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accidental swallowing.
- Please use the accessories provided or authorized by the manufacturer only.
- The power supply of the device shall meet the requirements of the input voltage of the device. Please use the provided surge protection power socket only.
- Before plugging or unplugging any cable, make sure that your hands are completely dry.
- Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbasin, kitchen sink, wet basement or near a swimming pool.
- During a thunderstorm, stop using the device and disconnect it from the power supply. Unplug the power plug and the Asymmetric Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike.
- If the device is left unused for a rather long time, disconnect it from the power supply and unplug the power plug.
- When there is smoke emitted from the device, or some abnormal noise or smell, disconnect the device from the power supply, and unplug the power plug immediately.
- Contact the specified maintenance center for repair.
- Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- Before connecting a cable, connect the grounding cable of the device first. Do not disconnect the grounding cable until you disconnect all other cables.



Cleaning Requirements

- Before cleaning the device, disconnect it from the power supply.
- Use a piece of soft, dry and anti-static cloth to clean the device.
- Keep the power plug clean and dry.



Battery Precautions (Apply for lithium battery products)

- Do not immerse the battery into water, which could short-circuit and damage the battery.
- Do not expose the battery to an open flame or leave the battery where it could be subjected to extremely high temperatures, which could cause the battery to explode.
- Do power the handset off before removing the battery.
- Do not try to use the battery for the power supply of any device other than this device.
- Do not open or mutilate the battery, released electrolyte is corrosive and may cause damage to the your eyes or skin.
- Use only the rechargeable battery pack delivered with the device or those rechargeable battery packs expressly recommended by Yealink.
- Defective or exhausted battery should never be disposed of as municipal waste. Return old battery to the battery supplier, a licensed battery dealer or a designated collection facility.

Troubleshooting

The unit cannot supply power to Yealink device.

There is a bad connection with the plug.

1. Clean the plug with a dry cloth.
 2. Connect it to another wall outlet.
- The usage environment is out of operating temperature range.

1. Use in the operating temperature range.

The cable between the unit and the Yealink device is connected incorrectly.

1. Connect the cable correctly.
- You cannot connect the cable properly.
1. You may have connected a wrong Yealink device.
2. Use the correct power supply.

Some dust, etc., may be in the port.

1. Clean the port.

Contact your dealer or authorized service facility for any further questions.

Contact Information

YEALINK NETWORK TECHNOLOGY CO.,LTD.

No.666 Hu'an Rd,Huli District Xiamen City, Fujian, P.R. China

support@yealink.com

Made in China

Yealink (Europe) Network Technology GmbH

Georg-Mueller-Straße 5, 80807 Munich

EUROPE@yealink.com

YEALINK (USA) NETWORK TECHNOLOGY CO., LTD.

Suite 160, 5445 legacy drive, Plano, Texas, 75024, United States

Made in China



YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.

Web: www.yealink.com

Copyright©2025 YEALINK(XIAMEN) NETWORK

TECHNOLOGY CO.,LTD. All rights reserved.