

## Label location of BT-1800

The FCC ID label will stick on the bottom side of main unit.



FCC ID label (for model BT-1800) stick on the bottom side of main unit

40 mm

Model : BT-1800  
FCC ID : T4PBT180020061010

32mm

