

○
RESET

netis

Model: **DL4480V1**

SuperVector VDSL2 AC1200 Dual Band Gigabit IAD

USB3.0

Default setting IP Address: 192.168.1.1

User Name: guest

Password: guest@XXXX

SSID: netis_2.4G_XXXXXX

netis_5G_XXXXXX

(XXXX/XXXXXX: last 4/6 digits of MAC address)

Wireless password: password

FCC ID: T58DL4480V1R

SN:



This device complies with Part 15 of the FCC Rules.


Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received,
including interference that may cause undesired operation.

MAC:


Input: 12V=1.5A



PWR



FXS2



FXS1




LAN1

LAN2

LAN3

LAN4

WAN



DSL

