TRANSFORMING ROBOT

RADIO CONTROLLED CAR

MUTATES FROM ROBOT TO RACE CAR IN JUST SECONDS!

TWO FREQUENCIES FOR COMPETITIVE PLAY

BLUE HAT TOY COMPANY

DX2016D

Toy RC Robot Jr

AGES 6+

BOX CONTAINS THE FOLLOWING FREQUENCY:

☐ 27 MHz
☐ 49 MHz

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ WARNING! CHOKING HAZARD - Small parts. Not suitable for children under 3 years.

MUTATES FROM ROBOT TO RACE CAR IN JUST SECONDS!

TWO FREQUENCIES FOR COMPETITIVE PLAY

BLUE HAT TOY COMPANY

TRANSFORMING ROBOT

RADIO CONTROLLED CAR

- Automatically converts from Robot to Race Car at the Touch of a Button
- Wireless Radio Control
- Super-Grip Tires for Smooth Surfaces
- Available in Two Frequencies for Competitive Play

WIRELESS RC ACTION!

2905101 (35343)

6 94202 31772 3

Made in China

©2015 MerchSource, LLC. Blue Hat Toy Company, Robot Car and all associated logos are trademarks of MerchSource, LLC. All rights reserved.

Distributed by MerchSource, LLC, Irvine, CA 92618.

US Pat. Nos. D617,851, D631,923; China Pat. No. ZL200830049165.3.

For technical support, please visit www.mscustomercare.com or call 1-800-374-2744.

The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notices from this package.

Car requires 3 "AA" (1.5V) batteries (not included) and one 9V battery (included). See bottom panel for complete operating instructions. Colors and styles may vary.

Car requires 3 "AA" 1.5V alkaline batteries (not included) and one 9V battery (included). See bottom panel for additional battery information. Colors and styles may vary.

SAFETY PRECAUTIONS

CAUTION: Always keep clear of car during transformation to avoid potential pinch points.

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating your car.
- Do not submerge car or controller in water.
- Adult supervision is recommended when operating this car.
- Never operate your car on the street or highway.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate your car in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON"
- Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave car or transmitter outside overnight. Dampness is harmful to interior components.

BATTERY INFORMATION

Operation requires 3 "AA" batteries (not included) for car and one 9V battery for radio controller (included) .

- Carefully remove items from packaging.
- Refer to the diagram for battery installation. Unscrew with a Phillips screw driver and rotate lever (A) to unlock the battery door (B). Open the battery door (B), insert 3 "AA" size batteries in the correct polarity shown (C). Close and screw back to close the battery door.
- Slide open the battery compartment door on the back of the controller. Insert one 9V battery following the correct polarity. Replace the battery compartment door.
- **NOTE: All turning is preformed by back wheels.**

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

KEEP THIS PACKAGING FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Insert batteries using the correct polarity. Do not short circuit the supply terminal.
- Remove batteries when not in use. Dispose of exhausted batteries properly by local regulations.
- Only use manufacturer specified batteries (charged) and/or adapter, of acceptable, specified quality.
- Always use, replace, and recharge of specified batteries under adult supervision.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.