

Remote features



Push-to-talk voice

Use your voice to quickly search across channels, turn captions on, and more.



TV controls

Power up your TV, adjust the volume, and mute.



Simple setup

Easily pair it to your compatible Roku device.



Pre-set channel shortcuts

Launch popular streaming channels in just a press.

What type of voice commands can I use with this remote?

“Turn captions on”

“Launch The Roku Channel”

“Skip 30 seconds”

“Show me action movies”


© 2022 Roku, Inc. All rights reserved.
Roku, Roku TV, Happy Streaming and the Roku logo are the trademarks or registered trademarks of Roku, Inc.




4100000873_01

Roku Voice Remote

Quick Start Guide



Details



Pairing your remote

Step 1:

Use your current Roku remote or the free mobile app to press and hold  for 5 seconds to open the setup menu.

Step 2:

Select **Remote** and follow the on-screen instructions to pair your new remote.

For help pairing your remote, visit go.roku.com/remotepair

Setting up TV controls

Own a Roku TV™? You can skip this section.

- Press the  button on your new remote.
- Go into the Settings menu and select **Remotes & Devices**.
- Find your new remote under **Remotes**.
- Select **Set up remote for TV control** and follow the instructions.

Happy Streaming™

Roku Voice Remote - Important Product Information

The Roku Voice Remote which accompanies this Important Product Information ("Remote") is compatible with all Roku TV models, Roku® Streambar® and select players.

Safety Precautions/Use & Handling

To help ensure safe and enjoyable operation of the Remote, and headphones (if applicable) please follow these guidelines:

- Observe all warnings, precautions and instructions.
- Keep the Remote out of the reach of small children.
- Do not allow liquid, small particles or other foreign objects to get into the Remote or headphones.
- Do not expose the Remote and headphones to liquid, smoke or steam.
- Do not expose the Remote or headphones to high temperatures, high humidity or direct sunlight.
- Do not place the Remote on the floor or in a place where they may cause someone to trip or stumble.
- Permanent hearing loss may occur if the Remote headphones are used at high volume. To prevent possible hearing loss, limit the amount of time you use the headphones at high volume.
- For more information on product safety and troubleshooting, please go to **support.roku.com**



Important Tips About Battery Handling

Replacing batteries: Always replace dead batteries with two brand-new batteries from the same manufacturer. Never use damaged batteries.

Disposal of batteries: Always dispose of batteries following federal guidelines or local ordinances. Do not dispose of used batteries in an open fire.

Warning Signs: If your Remote gets warm/hot during use, discontinue use and contact Roku Customer Support immediately at **support.roku.com**. There is a risk of explosion if a battery is replaced by an incorrect type.

Limited Warranty & Warranty Service Process

For any Remote purchased and delivered to end users in the US, go to **support.roku.com** for the warranty terms and conditions. You may also request a copy of such terms by mail by contacting us at 1155 Coleman Ave, San Jose, CA 95110.

Additional Legal Notices - US ONLY

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

2.4 GHz band operation of this product in the US is firmware-limited to channels 1 through 11.

IMPORTANT NOTE: FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

support.roku.com

Copyright © 2022 Roku, Inc. All rights reserved.



4100000874_01

Roku Voice Remote - Important Product Information

The Roku Voice Remote which accompanies this Important Product Information ("Remote") is compatible with all Roku TV models, Roku® Streambar® and select players.

Safety Precautions/Use & Handling

To help ensure safe and enjoyable operation of the Remote, and headphones (if applicable) please follow these guidelines:

- Observe all warnings, precautions and instructions.
- Keep the Remote out of the reach of small children.
- Do not allow liquid, small particles or other foreign objects to get into the Remote or headphones.
- Do not expose the Remote and headphones to liquid, smoke or steam.
- Do not expose the Remote or headphones to high temperatures, high humidity or direct sunlight.
- Do not place the Remote on the floor or in a place where they may cause someone to trip or stumble.
- Permanent hearing loss may occur if the Remote headphones are used at high volume. To prevent possible hearing loss, limit the amount of time you use the headphones at high volume.
- For more information on product safety and troubleshooting, please go to **support.roku.com**



Important Tips About Battery Handling

Replacing batteries: Always replace dead batteries with two brand-new batteries from the same manufacturer. Never use damaged batteries.

Disposal of batteries: Always dispose of batteries following federal guidelines or local ordinances. Do not dispose of used batteries in an open fire.

Warning Signs: If your Remote gets warm/hot during use, discontinue use and contact Roku Customer Support immediately at **support.roku.com**. There is a risk of explosion if a battery is replaced by an incorrect type.

Limited Warranty & Warranty Service Process

For any Remote purchased and delivered to end users in the US, go to **support.roku.com** for the warranty terms and conditions. You may also request a copy of such terms by mail by contacting us at 1155 Coleman Ave, San Jose, CA 95110.

Additional Legal Notices - US ONLY

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

2.4 GHz band operation of this product in the US is firmware-limited to channels 1 through 11.

IMPORTANT NOTE: FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

support.roku.com

Copyright © 2022 Roku, Inc. All rights reserved.



4100000874_01