

GENERAL INSTRUCTION FOR AQUA REMOTE CONTROL PRODUCT

CAUTION : TO PREVENT BATTERY LEAKAGE :

- (1) BE SURE TO INSERT BATTERIES CORRECTLY AND ALWAYS FOLLOW THE TOY AND BATTERY MANUFACTURER'S INSTRUCTIONS.
- NEVER MIX OLD AND NEW BATTERIES (REPLACE ALL BATTERIES AT THE SAME TIME)
- (2) NEVER MIX OLD AND NEW BATTERIES.
- (3) NEVER MIX ALKALINE, STANDARD OR RECHARGEABLE BATTERIES.
- (4) ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.
- (5) DO NOT USE RECHARGEABLE BATTERIES, UNLESS SPECIFIED.
- (6) NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED.
- (7) RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED.
- (8) RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION.
- (9) ALWAYS REMOVE EXHAUSTED OR DEAD BATTERIES FROM THE PRODUCT.
- (10) REMOVE BATTERIES FROM PRODUCT BEFORE EXTENDED STORAGE.
- (11) TO SUPPLY TERMINALS ARE NOT TO BE SHORT CIRCUITED. BATTERIES MAY EXPLODE OR LEAK IF MISUSED. BATTERIES SHOULD BE INSTALLED BY ADULT ONLY.
- (12) REMOVE THE BATTERIES AFTER USE.
- (13) IF THE PRODUCT IS DAMAGED, DON'T TRY TO REPAIR IT BY YOURSELF.

WARNING : Changes or Modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

HOW TO INSTALL BATTERY

- (1) USING A SMALL PHILLIPS HEAD SCREWDRIVER TO UNSCREW BATTERY COMPARTMENT LID.
- (2) INSERT THE BATTERY INSIDE THE BATTERY BOX.
- (3) REATTACH LID WITH SCREWS (DO NOT OVER-TIGHTEN).

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.
OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS :
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED,
INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE
OPERATION.

AQUA LEISURE INDUSTRIES, INC.
INGO BUSINESS CENTRE WESSEX HOUSE OXFORD ROAD
NEWBURY BERKSHIRE RG141PA UNITED KINGDOM
MADE IN CHINA

Aqua
LEISURE