



User Guide

AC1300 Whole Home Mesh Wi-Fi System Deco M5

Contents

About This Guide	1	Blacklist	19
Appearance	2	Online Upgrade	20
Set Up Your Deco	3	WPS	21
Add More Decos	6	Parental Controls	22
Dashboard	7	Antivirus	23
Check Deco Status	8	QoS	24
Manage Connected Devices	9	Monthly Report	25
Create New Networks	10	Managers	26
Remove/Reboot Deco	12	Advanced Features	27
Shortcut	13	Authentication	32
Automation	14		
Wi-Fi Settings	16		
Internet Speed Test	17		
Network Optimization	18		

About This Guide

This guide provides a brief introduction to Deco Whole Home Mesh Wi-Fi System and the Deco app, as well as regulatory information.

Features available in Deco may vary by model and software version. Deco availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual Deco experience.

Conventions

In this guide, the following conventions are used:

Convention	Description
Deco	Stands for Deco Whole Home Mesh Wi-Fi System/Unit.
<u>Underline</u>	Hyperlinks are in teal and underlined. You can click to redirect to a website or a specific section.
Teal	Key information appears in teal, including management page text such as menus, items, buttons and so on.
 Note:	Ignoring this type of note might result in a malfunction or damage to the device.
 Tips:	Indicates important information that helps you make better use of your device.

More Info

- Specific product information can be found on the product page at <https://www.tp-link.com>.
- A community is provided for you to discuss our products at <https://community.tp-link.com>.
- Our Technical Support contact information can be found at the [Help](#) center of the Deco app and the [Contact Technical Support](#) page at <https://www.tp-link.com/support/>.

Speed/Coverage/Device Quantity Disclaimer

Maximum wireless transmission rates are the physical rates derived from IEEE Standard 802.11 specifications. Range, coverage, and maximum quantity of connected devices are based on test results under normal usage conditions. Actual wireless data throughput, wireless coverage, and quantity of connected devices are not guaranteed and will vary as a result of 1) environmental factors, including building materials, physical objects, and obstacles, 2) network conditions, including local interference, volume and density of traffic, product location, network complexity, and network overhead, and 3) client limitations, including rated performance, location, connection quality, and client condition.

HomeCare Disclaimer

A basic TP-Link HomeCare™, powered by Trend Micro™, package is included for 3 years from date of activation at no additional cost. It includes Parental Controls, Quality of Service, and Antivirus. Deactivation of HomeCare™ will disable certain controls and protections. For a complete list of HomeCare™ functions, go to <https://www.tp-link.com>.

IoT Compatibility Disclaimer

IoT compatibility refers only to smart devices that can be controlled via the Deco app. Other wireless devices can still connect to Deco for normal Wi-Fi use.


Seamless Roaming Disclaimer

Clients need to support 802.11k/v/r and may require additional set up. Performance may vary depending on the client device.

Appearance

Each Deco has an LED that changes color according to its status, two RJ-45 Ethernet ports, a power slot, and a Reset button. See the explanation below:

💡 Tip: The product label can be found at the bottom of the product.



Set Up Your Deco

The intuitive Deco app guides you through an easy setup process that gets each unit up and running and all your devices connected and online. Follow the steps below to set up your Deco Whole Home Mesh Wi-Fi System.

1. Download and install the Deco app

Scan the QR code below or go to Google Play or the Apple App Store to download the Deco app. Install the app on your Android or iOS smartphone or tablet.




or



2. Log in or sign up with TP-Link ID

Open the app. Use your TP-Link ID to log in. If you don't have a TP-Link ID, sign up first.

Note: If you forgot your login password, tap [Forgot password?](#). The Deco app will guide you through the rest.



3. Identify your Deco


Choose your Deco model.



4. Connect your modem to Deco


Power off your modem. Connect your Deco to the modem and power them both on.

If you don't have a modem, connect the Ethernet outlet directly to your Deco.




5. Select a location

Select a location for this Deco. If its location is not listed, you can create a new one by choosing [Custom](#).




6. Set up internet connection

Select the internet connection type and enter the information. If you are not sure, contact your internet service provider.



7. Create your Wi-Fi network


Set a network name and a password. These will be the name and password you use to connect your devices to Wi-Fi.



The screenshot shows a mobile app interface for creating a Wi-Fi network. At the top, the status bar shows 'No SIM', signal strength, and the time '11:08 AM'. Below the status bar is a blue 'X' icon. The main heading is 'Create your Wi-Fi Network'. Below this, a paragraph explains that the network name and password will be used to access the network, and that the password must be at least 8 characters. There are two input fields: 'Network Name' and 'Password'. Below the 'Password' field, a note recommends using a combination of letters, numbers, and symbols. At the bottom, there is a grey button labeled 'NEXT'.

8. Setup complete

Your Deco network is now up. Add more Decos or complete the setup and connect all devices to the Deco network.




Add More Decos

After created a Deco network, you can add more Deco units into the network to expand the Wi-Fi coverage, and manage them conveniently on your Deco app.

On the Overview page, Tap 

Select the Deco model you want to add, and follow app instructions to complete the setup


After the setup, you can find the added Decos by tapping 




Dashboard

After you successfully set up your Deco network, you will see the dashboard of the Deco app. Here you can get an overview of the network status, create shortcut and automation, and set up various advanced features.


Tap  to get an overview of the network status




Tap  > [Shortcut](#) to create or execute shortcut



Tap  > [Automation](#) to set interactions between your smart devices




Tap  for more features




Check Deco Status

In the Overview page, you can check the working status of all the Decos, check the Deco details, change or customize the location, and more.



Tap  to check all Decos' status



Tap a Deco unit to check the details



Tap the Deco unit to change or customize the location




Manage Connected Devices

In the Overview page, you can check the working status of all the connected devices, view the device details, or change the device settings.

Tap a client on the [Network Devices](#) list to check the details

Tap  to manage the device settings

Tap [Belongs to](#) to add a unique profile for the device and manage its online activities





Create New Networks

On the Deco app, you can create different Deco networks bound to your TP-Link ID, and manage them conveniently from the Deco app with one account. You can also help family or friends by managing their network on your Deco app. Two methods are provided as below to create a new network:

Method 1. Create a new network from the Overview page

Tap  > [Create New Network](#)

Then follow the app instructions to complete the setup




Create New Networks


On the Deco app, you can create different Deco networks bound to your TP-Link ID, and manage them conveniently from the Deco app with one account. You can also help family or friends by managing their network on your Deco app. Two methods are provided as below to create a new network:

Method 2. Create a new network from the Menu page


Tap  to open the Menu



Tap  > [CREATE NEW NETWORK](#)



Follow app instructions to complete the setup



Remove/Reboot Deco





You can remove or reboot your Deco easily on the Deco app. Follow the steps below.

Tap  to check all Decos' status

Tap a Deco unit to enter the details

Tap  to remove or reboot the Deco


 Note: If the LED light of Deco does not turn pulsing blue after tapping Remove, refer to [Appearance](#) to use the reset button to reset it.




Shortcut

Shortcut lets you achieve an action with a simple tap.


Tap  > [Shortcut](#) > [CREATE](#)




Add actions



Create shortcuts




Tap the icon to execute the shortcut
Tap the name to edit the shortcut




Automation

Automation allows you to set interactions between your smart devices by adding triggers and actions. For example, if the bedroom light turns on (which is a trigger), and then the air conditioner in the bedroom will start running (which is an action).


Tap  > Automation > CREATE




Set effective time




Add triggers




Add actions



Set a name for the automation



Automation setup complete



Wi-Fi Settings





You can change the network name and password of your main network, create a separate network for guests to guarantee the security and privacy of your main network, and shake your device to share the network details easily with family and friends.

Tap  > Wi-Fi

Manage your main network (e.g. change your Wi-Fi network name and password)

Enable guest network


Shake to share your network




Internet Speed Test

Test your internet speed to see what you can do on your network. You will get an internet speed rating report after the test.


Tap  > Test Internet Speed




Tap **TEST** to start testing



Get speed test report



Tap  to check speed test history



Network Optimization




Network Optimization lets your Deco intelligently scan for a clearer channel and switch your devices to it, ensuring optimal Wi-Fi performance.

Tap  > [Network Optimization](#)

The app will scan the network automatically

Optimize your network for optimal Wi-Fi performance


Enjoy your time if your network status is perfect




Blacklist

Compile a blacklist to avoid devices added on the blacklist to access to your network, ensuring the safety of your personal information shared in the network.


Tap  > [Blacklist](#)




Add clients to blacklist



Add other devices to blacklist



Manage blacklist





Online Upgrade

TP-Link is dedicated to improving product features and providing a better customer experience. An up-to-date firmware provides better and more stable network performance. Always update your Deco to the latest firmware version when prompted in the Deco app.

Tap  > [Update Deco](#)

Follow app instructions to update your Deco to the latest version


 Tip: If the firmware update fails, please reboot the main Deco, move the Satellite Deco closer to the main Deco, then try to update again.




WPS

WPS (Wi-Fi Protected Setup) helps you to quickly and securely connect a client to a network with a tap without entering any password.

Tap  > WPS



Tap the **WPS** icon on Deco app and then on your client



Your device connects to the network successfully if shown as below

