


## PROPER USE

### Precautions and Care



## SUPPORT

### Trouble Shooting

#### Problem - Vehicle does not move or moves slowly.

- Make certain there are fresh alkaline batteries in the transmitter and that they have been installed in the correct position. You may need to re-sync the transmitter and vehicle. Refer to sync instructions in Transmitter Functions section.
- Are the (+) and (-) markings on the alkaline batteries in the same position as the (+) and (-) markings in the Transmitter Battery Compartment?
- Are the metal contact tabs touching, rusty or dirty in the transmitter?
- Has the vehicle been fully charged?
- Make certain that the vehicle ON/OFF switch is in the "ON" position.

#### Problem - Vehicle moves by itself or exhibits reduced range from the transmitter.

- Make certain there are no outside radio interference in your area. The best way to test this is to take the vehicle as far away from radio towers, electrical lines or tall buildings as possible to ensure no further radio interference will occur.

Always remove Batteries from transmitter when not in use.

Do not dispose batteries in fire. Leakage, explosion and personal injury may occur.

Do not attempt jumps or tricks with this vehicle.

Do not attempt to remove internal battery.

Do not use included USB cord for anything other than its intended purpose.

Always keep USB cord stored when not in use.

Adult supervision recommended.

#### F.C.C. CAUTION:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### USA & Canada 90-Day Limited Warranty

Motor Dayz warrants to the original purchaser that this product will be free of defects in materials and workmanship for ninety (90) days from the date of purchase. If a defect arises within the warranty period, Motor Dayz will, at its sole discretion, provide replacement parts, replace the product, or offer a coupon for our website for a new product of at least equal value. This Warranty does not cover damage resulting from unauthorized modifications, accidents, misuse, or abuse. A dated sales receipt is required for coverage under this Warranty. Purchases from unauthorized retailers, resellers, or distributors are not covered under this Warranty.

Should your item have a defect covered under this Warranty, either call the Consumer Service team by phone or email using the contact details listed below. Most issues can be resolved through troubleshooting in this manner. If necessary, you will be issued a Case Number and be provided instructions on how to obtain replacement parts, a replacement product, or a coupon. Please allow 2 to 4 weeks for processing and delivery, depending on your location. Motor Dayz covers the cost of shipping for valid claims within the USA and Canada. DO NOT send any product to Motor Dayz. Any unsolicited product returns will be refused delivery and returned at the sender's expense.

Motor Dayz's liability for defects in materials and workmanship under this warranty is limited to providing replacement parts, a replacement product, or a coupon at Motor Dayz's sole discretion. In no event shall Motor Dayz be responsible for any incidental, consequential or contingent damages.

#### Valid only in the USA & Canada.

For full Warranty details, visit,

USA: <https://www.motordayz.com/customer-support/warranty/>  
Canada: <https://www.motordayz.ca/customer-support/warranty/>

For more information regarding our product line, please visit,  
USA: [www.motordayz.com](http://www.motordayz.com). For Canada, please visit: [www.motordayz.ca](http://www.motordayz.ca)

#### For Service in the USA

Email: [cservice@motordayz.com](mailto:cservice@motordayz.com)  
Call: 248-863-3110  
Monday- Friday,  
8:30am- 7:00pm Eastern Time

#### For Service in Canada

Email: [cservice@motordayz.ca](mailto:cservice@motordayz.ca)  
Call: 888-225-7375  
Monday- Friday,  
8:30am- 5:00pm Eastern Time


Motor Dayz Customer Service  
3000 N. Pontiac Trail  
Commerce Township, MI 48390  
<http://www.motordayz.com/>

REF R5-10C91U-GD

JN023-26

## WHAT'S INCLUDED

### Component Checklist



(1) R/C Vehicle



(1) Transmitter




(1) USB Charging Cord



(2) "AA" Batteries

## VEHICLE

### Features & Functions



#### Note:


1. Vehicle has working lights.
2. The front and rear of the car can be raised or lowered.
3. The front wheels are capable of bouncing.

\* If vehicle pulls to the left or right during forward driving the Wheel Alignment may need to be adjusted. The Wheel Alignment Dial is located on bottom of chassis between the front wheels.

## VEHICLE

### Charging the Vehicle

This vehicle is equipped with an internal Lithium-Ion battery that is recharged via USB. **ON/OFF Switch must be in the OFF position prior to charging.**



1. Locate the ON/OFF switch and Type-C Charging Port on the under-side of the vehicle.
2. Turn the ON/OFF switch to the "OFF" position.
3. The charging port is Type-C, and the cable can be plugged into any 5V DC computer or 5V DC USB outlet adapter (not included).




4. While charging, the LED Charge Status Light under the vehicle will be on. Once fully charged the LED will turn off. Charging is completed in approximately 1.5 hours. Return cord before operating the vehicle.

## TRANSMITTER


### Battery Installation

1. Remove the screw to open the Battery Compartment Cover.
2. Insert 2 "AA" size batteries. Make sure the positive (+) and negative (-) markings on the batteries match up to the ones inside the Battery Compartment.
3. Replace the Battery Compartment Cover and replace the screw.



**Note:** When replacing Transmitter batteries:  
Use alkaline batteries only.  
Do not mix old and new batteries.  
Do not mix alkaline, standard or rechargeable batteries.

### Functions



### Syncing

This transmitter is equipped with 2.4GHz technology which allows up to 6 vehicles to be raced at the same time. Before first use and after any time the batteries are replaced, the transmitter must be paired to the vehicle.

To sync transmitter and vehicle, follow the steps below:

1. Correctly install batteries in the transmitter.
2. Place vehicle upside down, and turn Vehicle ON/OFF switch to the ON position. The vehicle is only in sync mode for 30 seconds.
3. Immediately press and hold the Forward/Reverse joystick on the transmitter. Keep holding until wheels move (up to 30 sec).