



Netorage100 Schematic-6 MIC


- 1. Content
- 2. CPU
- 3. DRAM
- 4. Flash
- 5. Ethernet Switch
- 6. IDE Interface
- 7. LED_RJ45
- 8. Power & Reset



2. CPU




3. DRAM



Heinesys Inc.			
Title			
Netorage100			
Size	Document Number	DRAM	Rev
B			1.5
Date:	Friday, May 21, 2004	Sheet	3 of 8

4. Flash




=== AM29LV641DH 장착 ===
Not Mount: R59
Mount : R61, R61


=== AM29DL323DT 장착 ===
Not Mount: R61, R57
Mount : R59

Heinesys Inc.			
Title			
Netorage100			
Size	Document Number	FLASH	Rev
B			1.5
Date:	Friday, May 21, 2004	Sheet	4 of 8



5. Ethernet Switch



6. IDE Interface



7. LED_RJ45




Heineys Inc.		
Netorage100		
Size C	Document Number	Rev 1.5
LED_RJ45		
Date: Friday, May 21, 2004	Sheet 7	of 8

8. POWER & RESET

Power Connector

Use 12V, 3.5A Power
Cube
Mfg X/ Part Number X



Heinesys Inc.			
Title Netorage100			
Size C	Document Number	Power & reset	Rev 1.5
Date: Wednesday, June 02, 2004	Sheet	8	of 8