


# Chromebook

## Quick Guide

---

## Package contents


Carefully unpack your box and take out the items listed below. If any of the items are missing or damaged, please contact your dealer immediately:

|                                                                                    |                                                                                    |
|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"><li>• One Chromebook</li></ul>                   | <ul style="list-style-type: none"><li>• One AC adapter</li></ul>                   |
|   |   |
| <ul style="list-style-type: none"><li>• One warranty card</li></ul>                | <ul style="list-style-type: none"><li>• This quick guide</li></ul>                 |
|  |  |

# Layout




| No. | Name             | No. | Name               |
|-----|------------------|-----|--------------------|
| 1   | Microphone       | 5   | USB 2.0 port       |
| 2   | Webcam           | 6   | Micro SD card slot |
| 3   | LCD monitor      | 7   | Touchpad           |
| 4   | Audio combo jack |     |                    |



| No. | Name          | No. | Name      |
|-----|---------------|-----|-----------|
| 1   | DC input jack | 3   | HDMI port |
| 2   | USB 2.0 port  | 4   | Speaker   |


## Function keys



| Icon                                                                                | Description                | Icon                                                                               | Description                |
|-------------------------------------------------------------------------------------|----------------------------|------------------------------------------------------------------------------------|----------------------------|
|    | Previous page              |   | Increase screen brightness |
|    | Next page                  |   | Mute                       |
|    | Reload current page        |   | Decrease audio volume      |
|    | Full-screen mode           |   | Increase the volume        |
|   | Switch to next window      |  | Search                     |
|  | Decrease screen brightness |                                                                                    |                            |

## Before powering on for the first time

- Charge the battery with the adapter coming with your Chromebook until the charging indicator turns from red to green.



- Make sure there is a wireless network available for you to connect your Chromebook.

**Note:** If the only available network is a wired one, you need to acquire separately a USB internet adapter that supports Linux systems.)

# Getting started


## Step1: Turn on your Chromebook for the first time



Press the power button.

For the first time you power on your Chromebook, a

dialog will appear as shown below.



## Step.2: Select your language settings

If there is more than one way to type in your language,

you may be prompted to select a keyboard input method as well.

### **Step3: Connect to a network**

Select a wireless network from the "Select a network" list to connect to the Internet.



If your selected network is a protected one, you will be prompted to enter your password to connect to it.


### **Step 4: Accept the Terms of Service**

Once connected to a network, accept the Terms of Service. Your Chromebook will then automatically download any available system updates to get the latest Chrome OS features.

## Step 5: Create your Google Account

**Note:** The first account signed in here will be set as the owner account and is the only account that will be allowed to change Chrome settings.

When you reach this step, the dialog shown below will appear on your screen.

A screenshot of a Chromium sign-in dialog box. The dialog has a light gray background and a thin black border. In the top left corner, there is a Chromium logo (a colorful wheel) followed by the word "chromium" in a sans-serif font. The main content area is divided into two sections by a vertical line. On the left side, there is a "Sign in" section. It includes the text "Sign in" in a small font, followed by the word "Email" above a text input field. Below the email field is the label "Password" above another text input field. At the bottom of this section is a blue button with the text "Sign in" in white. On the right side of the dialog, there is a section for new users. It starts with the text "If you don't have a Google Account you can [Create a Google Account](#) now." where "Create a Google Account" is a blue link. Below this, it says "You may also skip signing in and [browse as guest](#)." where "browse as guest" is a blue link.

If you already have a Google Account, enter your username and password in the sign-in box and click on the Sign-in button.

If you don't have one, click "[Create a Google Account](#)" on the right to set up a new account.

### **Step 6: Set your account picture**

You can use the Chromebook's built-in webcam to take a photo of yourself, or just choose an icon instead and change it later.

The desktop will be open as shown below, and you can start using your Chromebook.



## Specifications

|                  |                                                                                                                                  |
|------------------|----------------------------------------------------------------------------------------------------------------------------------|
| <b>Processor</b> | <ul style="list-style-type: none"> <li>● Rockchip RK3288 Cortex-A17 Quad Core</li> </ul>                                         |
| <b>Memory</b>    | <ul style="list-style-type: none"> <li>● DDR3L SDRAM</li> <li>● 2G/1600MHz</li> </ul>                                            |
| <b>Storage</b>   | <ul style="list-style-type: none"> <li>● eMMC for V5.0</li> <li>● 16G</li> </ul>                                                 |
| <b>Wireless</b>  | <ul style="list-style-type: none"> <li>● IEEE 802.11 2 X 2 MIMO a/b/g/n/ac Wireless LAN + Bluetooth + NFC NGFF Module</li> </ul> |
| <b>Display</b>   | <ul style="list-style-type: none"> <li>● EDP 1366x768 TN</li> <li>● 11.6" for EDP interface</li> </ul>                           |
| <b>Webcam</b>    | <ul style="list-style-type: none"> <li>● 720p HDTV and 1.3M</li> </ul>                                                           |
| <b>Battery</b>   | <ul style="list-style-type: none"> <li>● Polymer Battery</li> <li>● 2S1P, 7.4V/3400mAh</li> <li>● &gt;25Wh</li> </ul>            |

|                          |                                                                                                                                                                                          |
|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Input/Output</b>      | <ul style="list-style-type: none"> <li>● 1 x 12V DC IN</li> <li>● 1 x 3.6mm combo Jack</li> <li>● 1 x HDMI (A-TYPE)</li> <li>● 2x USB2.0 port</li> <li>● 1xTF slot (Micro SD)</li> </ul> |
| <b>Speaker &amp; Mic</b> | <ul style="list-style-type: none"> <li>● 2 x Build-in speakers (Stereo)</li> <li>● 1 x Internal MIC</li> </ul>                                                                           |
| <b>AC-Adapter</b>        | <ul style="list-style-type: none"> <li>● DC Output: 12V/2A</li> <li>● Input Voltage: 100 - 240VAC</li> <li>● Input Frequency: 50 - 60Hz</li> </ul>                                       |
| <b>Dimension (mm)</b>    | <ul style="list-style-type: none"> <li>● 204 (W) x 290 (D) x 19.3 (H)</li> </ul>                                                                                                         |
| <b>Weight</b>            | <ul style="list-style-type: none"> <li>● &lt; 1,150g (w/o adapter)</li> </ul>                                                                                                            |