

The differences between 4ch model, 5ch model and 6ch model is:

4ch model without channel 5 and channel 6 switch .

5ch model with channel 5 switch

6ch model with channel 5 and channel 6 switch both.