

USER GUIDE

1. Turn on your FMT-100 power switch.

2. Turn your car's FM radio to 88.1.

This is the default broadcast frequency for the FMT-100. If 88.1 is not an empty frequency. Please change your car radio and FMT-100 to 88.5 or 88.9.

3. Plug 3.5mm stereo headphone plug into your MP3 audio output jack.

4. Turn on your MP3 machine.

5. Click play and carefully adjust the volume on your MP3 and car radio.

DISCLAIMER

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE. AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.