

FOB-4F19 Fob Smart Key

User Manual

OUTLINE

1. How to use FOB-4F19

- FOB-4F19 is Remote Keyless System.
- This unit controls door lock/door unlock/tailgate open wirelessly.

2. Introduction of Transmitter (FOB-4F19)

- Transmitter has 4 buttons.
- Transmitter use the battery (CR2032)
- Frequency is 433.92MHz

GENERAL DESCRIPTION

PRIMARY FUNCTION

- Remote door lock/unlock/tailgate/panic open – Operation

Manual

1. LOCK Button
 - If the LOCK button is pushed, then TRANSMITTER sends the LOCK Data.
2. UNLOCK Button
 - If the UNLOCK button is pushed, then TRANSMITTER sends the UNLOCK Data.
3. TAILGATE Button
 - If the TAILGATE button is pushed, then TRANSMITTER sends the TAILGATE OPEN Data.
4. Panic Button
 - If the TAILGATE button is pushed, then Horn of vehicle will be activated.