

Auluxe 



Auluxe 

BP3020

X5a

**Portable
Bluetooth Speaker**

This manual may not be reproduced, distributed, modified or posted to websites without the express written permission of Auluxe Corporation.



Designed and Engineered by Auluxe Corporation.
© 2014 Auluxe Corporation. All Rights Reserved. Printed in China.

使用說明書/ 使用说明书/ 取扱説明書
Instruction Manual/ Benutzerhandbuch

WHAT'S IN THE BOX


Features



①



②




③

- ① X5 Speaker x1
- ② Micro USB Cable x1
- ③ Instruction Manual x1
warranty card x1


Battery Type	3.7V 3000mAh
System Type	2.0 Channels
Rated output	Total 16 Watts
Frequency	180Hz -20KHz
Temperature	0 - 45 °C
Net weight	566 g
Dimensions	Ø80x H210 mm



Power Switch




Press this button to switch ON the X5. Press again to power off. System **will** power off after 10mins when no signal inputs.


Bluetooth/
Handsfree

Press and hold the button for 3secs to activate Bluetooth Pairing mode, and meantime the blue light is flashing. The user then activates the X5 device of the cell phone for pairing with a Bluetooth device. The X5 is connected successfully when blue light turns steady.

LED Indicators



Left Panel




Right Panel

Color	Power	Mode	Indicators Status
Blue	ON	Bluetooth Pairing	Fast flashing
Blue	ON	Bluetooth Ready	Solid
Green	Standby	After 5mins without audio input	Breathing lights
Green	ON	Aux in	Solid

Color	Power	Mode	Indicators Status
Red	ON	Low Power	Flashing twice every 20seconds
Red	ON / OFF	Charging	Breathing lights
Red	ON / OFF	Full Charging	Solid



Charging



To Charge X5, connect X5 with computer through a Micro USB cable. The Power LED will flash red light when charging and turn solid light after full charging.




Battery life is rated at 6~8 hours of use.

*Please note "Actual battery life may vary with use".




Aux In



Connect an external audio device such as Mobile Phone through a 3.5mm cable to play music.



Volume



Rotate the Left Panel to increase or decrease volume while playing music or in Hands-Free mode.