





3 Modes Connection Gaming MMO 12 Side buttons
Gaming Mouse Operating Instructions

US UK

Dear user

Thank you for you choosing REDRAGON Brand, to protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.

2. Consumable parts (such as foot stick) and spare parts replacement are no included in our warranty.

Button Instructions

1. Left button

2. Right button

3. Scroll wheel
(Click as middle button)

4. DPI+ button

5. DPI- button


6. Fire button

7. BT pair button

8. Profile switch button

9. BT/OFF/2.4G switch

10. Programmable button



Wired Connection

[BT/OFF/2.4G] switch on "OFF", connect the mouse to computer with USB cable. The computer will recognize and configure the mouse automatically, the mouse battery will be charging at same time.

2.4G Wireless Connection

1. [BT/OFF/2.4G] switch on "2.4G".

2. Plug the USB receiver into the USB port on your computer, the computer will recognize and configure the mouse automatically,press arbitrary key and you can use your mouse in 2.4G wireless mode.

BT Connection

1. 2.4G/OFF/BT switch on "BT".

2. Press ⑦ button for 3s, the mouse entered pairing status(blue LED flash quickly).Turn on the PC(over WIN7) BT function and search for available device, it will find "BT5.1 Mouse" device. Select the device to pair, after paired you can start use the mouse.

Auto sleep and power save function

The mouse will enter sleep mode when it is out of operation in 3 minutes, move or click any button to wake it up, if you needn't use it for a long time, please turn off it to save the power.(Auto sleep time can be changed in driver).

How to recharge the battery

1. Low battery warning---the scroll wheel LED will twinkling in red when the battery is low.

2. Use the USB cable to connect to PC USB port to charge the battery, the scroll wheel LED will steady on in red, after battery fully charged the LED turns to green color.

Warning:Charging current: 5V = 2A max.

DPI adjustment and indication

Click the DPI+ button or DPI- button to switch it.

Default DPI indicator color (LED on the bottom), the mouse supports max 26000 DPI(adjust through software).

1. RED ----- 400 DPI

2. BLUE ----- 800 DPI

3. GREEN ----- 1600 DPI

4. YELLOW --- 2400 DPI

5. CYAN----- 3200 DPI

Programmable buttons

There are 12 buttons in total: 1/2/3/4/5/6/7/8/9/10/11/12. Please set them to specified functions in the supporting driver(mouse software)(the initial values correspond to the numbers on the keyboard; additionally, 10 corresponds to "0", 11 corresponds to "+", and 12 corresponds to "-")

For more adjustable functions & macro recording, please download& install mouse software to enable more possibility.

FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.

2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Part 15 of the FCC Rules and contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.

DO NOT touch the battery fi material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.

DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.

DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.

DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

CAUTION

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

型号	红龙M913-MAX 2875		备注： 尺寸： L100*W100mm 材质： 80g书写纸， 风琴折页， 正反印 印刷： 单色							
名称	说明书(英)									
日期	2025-8-29									
页码	1 OF 1		文件编号							
绘图	吴九香	审核	香敏琪	核准		版本	A.0			