



BS-7634 2.4G WIRELESS KEYBOARD & MOUSE BUNDLE



ANATEL
02981-24-16556
02980-24-16556



USER MANUAL

US UK

Dear user

Thank you for choosing the **REDRAGON** products. In order to protect your right and get better service, please pay attention to the following warranty rules:

1. Within warranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pads) and spare parts replacement are not included in the warranty.



Function Overview

1. Left button
2. Right button
3. Scroll wheel & Middle button
4. DPI button
5. Battery slot
6. Indicator LED

O.S. Support: Win XP/Win 7/Win 8/Win 10/Win 11/ MAC O.S.

Connection

2.4GHz wireless connection, install 1*AA battery into mouse battery slot, install 1*AA battery into keyboard battery slot, plug USB receiver into computer USB port, the computer will connect mouse and keyboard automatically.

Tip: If the computer didn't connect successfully, plug out USB receiver from computer USB port, take out batteries from mouse and keyboard, take out batteries from mouse and keyboard and reload batteries, plug USB receiver to computer USB port, then-- mouse: press ①+②+③ buttons to re-connect, indicator lighting Red, after mouse connected the indicator turn OFF; keyboard: press [Esc]+[K], the battery indicator flash, after keyboard connected the battery indicator will turn off.

Product Features

Mouse

DPI switching: Press [DPI] button to cyclic switch DPI in 800/1200/1600/2400/4000 DPI, when switch the DPI, LED indicator will flash to show current DPI as below:

800 ----- 1 time
1200 ----- 2 times
1600 ----- 3 times
2400 ----- 4 times
4000 ----- 5 times

Power save mode: The mouse will enter power save mode when it is out of operation over 3 minutes, move or click any button to wake it up, when the mouse is out of operation over 10 minutes, the mouse will enter deep power save mode, click any button to wake it up.

Low battery warning: when mouse battery is low, the LED below the scroll wheel will twinkle, to remind change the battery.

Keyboard Shortcut keys:

FN + F1: Screen Brightness -	FN + F7: Pre-track
FN + F2: Screen Brightness +	FN + F8: Play/Pause
FN + F3: Multiple task	FN + F9: Next Track
FN + F4: Show desktop	FN + F10: Mute
FN + F5: Backward	FN + F11: Volume -
FN + F6: Search	FN + F12: Volume +

Power save mode: The mouse will enter power save mode when it is out of operation over 10 seconds, press any button to wake it up.

Low battery warning: when keyboard battery is low, the ()LED will twinkle, to remind you to change the battery.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.
3. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.
4. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.

DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.

DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.

DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.

DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.



Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

型号	HL-BS-BS-7634(7634+2661)		备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷				
名称	说明书						
日期	2025-7-11						
页码	1 OF 1		文件编号				
绘图	邓子松	审核	香敏琪	核准		版本	A.0