


   Please scan here to download operating instructions 2. 4G/BT Wireless Mouse Operating Instructions	US UK Dear user Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules. 1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty. 1	Button Instructions 1. Left button 2. Right button 3. Scroll wheel(Click as middle button) 4. Side button, defaulted forward 5. Side button, defaulted backward 6. DPI button 7. Pair button 8. Mode/Power switch: BT mode/OFF (power off)/2.4G mode  2	2.4G Wireless Connection [BT/OFF/2.4G] switch on"2.4G", plug USB receiver into computer USB port, click any button, the computer will recognize and configure the mouse automatically. BT Connection [BT/OFF/2.4G] switch on"BT", press ⑦ button for 3s to select BT pair mode. Turn on the computer BT and search for available device, and select device name " BT 5.0 Mouse", the computer will recognize and configure the mouse automatically. DPI adjustment and indication Press DPI button to cyclic adjust DPI in 800 DPI/1200 DPI/ 1600 DPI/2400 DPI/4000 DPI, when adjusting DPI, the DPI indicator flashes Red as below: 800 DPI----1 time 1200 DPI---2 times 1600 DPI---3 times 2400 DPI---4 times 4000 DPI---5 times Auto sleep and power save function The mouse will enter standby mode when it is out of operation in 10s, move or click any button to wake it up, when the mouse is out of operation in 10 minutes, the mouse will enter sleep mode, click ①/②/③ button to wake it up. 3	FAQ 1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports. 2. If the mouse is moving slowly, jumping or with delay, please try another surfaceDark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mousepad strongly recommended.  4
--	---	--	---	---

FCC STATEMENT 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the	reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. 1. Cleaning Instructions: Before cleaning, always unplug the device from the computer's USB port. Clean the surfaces with a soft, dry cloth. For stubborn dirt, use a cloth that is slightly dampened with water. Do not use chemical agents or solvents. Ensure the devices are completely dry before reconnecting them. 2. Ergonomic Health and Safety Guide: Incorrect or prolonged use of computer equipment can lead to discomfort, fatigue, headaches and serious long-term injuries known as musculoskeletal disorders (MSDs). Please take relaxation breaks every 30-60 minutes. 3. WARNING: The product is not a toy. Please keep it out of reach of small children. The product contains small components that may pose a choking hazard.	ISED WARNING This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licenceexempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. L'émetteur/récepteurexempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation. Sciences et Développementéconomique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si e brouillage est susceptible d'en compromettre le fonctionnement 'appareil numérique du ciem conforme.	RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. BATTERY SAFETY GUIDELINES DO NOT replace the battery with a different model. DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material. DO NOT touch the battery fi material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes. DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition. DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations. DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful. CAUTION Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.	 
--	---	---	--	--

型号	红龙BM-4219 4219		备注： 尺寸： L60*W80mm 材质： 80g书写纸， 风琴折页， 双面印 印刷： 单色				EasternTimes Tech 	
名称	说明书(英)							
日期	2026-4-22							
页码	1 OF 1		文件编号					
绘图	吴九香	审核	香敏琪		核准		版本	A.1