WARRANTY

1. Warranty Period: 12 months from purchase.
2. If the products have any qualified problems, Please Contact Us, We Will Solve the Problem for you ASAP.

PACKAGE CONTENT

Mechanical Keyboard x1
User Manual x1

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.
--Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Made in China

USER MANUAL

E-YOOSO®

Z-99

Wired+2.4G+BT three-modes RGB Mechanical Keyboard

PRODUCTS FEATURE

Ergonomic design.
High quality button switches.

LED LIGHTING MODES

Fn + Ins Support 15 backlit modes switching.

Fn + ↑ ↓ Adjust the backlight brightness. When it is adjusted to the extreme position, 1、A indicators will flash 3 times and are adjustable in 5 levels.

Fn + ← → Adjust the backlight streamer speed. When it is adjusted to the extreme position, 1、A indicators will flash 3 times and are adjustable in 5 levels.

Fn + Del Light swicthing: Red, Green, Blue, Yellow, Pink, Cyan, White, RGB (supporting for 11 types);

LIGHT EFFECT ADJUSTMENT ON BOTH SIDES

Fn + PgDn Cycle switching of side lamp effect: Flow; Neon; Static; Pulse; Off.

Fn + PgUp Switch side lamp speed.

Fn + PrtSc Switch the color of side lamp (Available for Pulse and Static).

WHITE LIGHT TEST FUNCTION

Use Fn + Tab to test full-key white light and press again to restore the original light effect. It is for testing purposes only.

CUSTOM KEY SETTINGS OF LIGHTING MODES

Fn + ← = Light recording

Press FN+Backspace to enter light self-defining mode Light off . Press FN+Backspace again to enter recording state. 1, A indicators will flicker continuously (and it will be off after recording is over). Pressthe same key continuously to the designated color, and go on settingother keys to form the needed backlight pattern. After the setting is completed, press FN+Backspace again to save it. When a light macro is played, press FN+Backspace, the light of the defined key will be normally on for indication (FN key cannot self define the light).

WIRED /2.4 G/ BLUETOOTH SWITCHING

1. Switch through the keyboard front power switch and FN key composite function. When the power switch is OFF, it is in Wired mode (the M indicator light is green). When the power switch is ON, press the FN key along with the 1! /2@/3# key to switch to Bluetooth mode (the M indicator light is blue/cyan/pink). Or press the FN key along with the 4$ key to switch to 2.4G mode (the M indicator light is yellow).

BLUETOOTH/2.4G PAIRING MODE

1. Bluetooth: Press and hold FN + (1!)/(2@)/(3#) for 3 seconds to enter the corresponding channel pairing mode of Bluetooth, the M indicator light will flash in blue/cyan/pink, prompting to enter pairing status; the indicator light is always on after the pairing is successful.
2. 2.4G: Press and hold FN + (4$) for 3 seconds to enter 2.4G pairing mode, the M indicator light will flash yellow, then connect the receiver to the computer, and the M indicator light will be solid yellow after the pairing is successful.

MODE STATUS BT/2.4G SELECTION

Press FN + (1!)/(2@)/(3#)/(4$) to switch the BT1/BT2/BT3/2.4G state of the keyboard respectively.

SUPPORT WIN LOCK FUNCTION

Fn + Win to lock the WIN key, repeak to unlock.

MAC/WIN FUNCTION KEY SWITCH

Switching to the Win system: Press the FN key along with the W key, 1、A indicator lights flash 3 times.
Switching to the MAC system: Press the FN key along with the A key, 1、A indicator lights flash 3 times.

MAC multimedia functions are as follows:

F1	Reduce screen brightness /FN+F1=F1
F2	Increase screen brightness /FN+F2=F2
F3	Multitask window (mission control)/FN+F3=F3
F4	Activate Siri. Release Delay Time: 200MS/FN+F4=F4
F5	App exposé function (Ctrl + Down Arrow)/FN+F5=F5
F6	Search(Command+space) /FN+F6=F6
F7	Prev Track/FN+F7=F7
F8	Stop/FN+F8=F8
F9	Next Track/FN+F9=F9
F10	Mute/FN+F10=F10
F11	Volume -/FN+F11=F11
F12	Volume +/FN+F12=F12

WIN multimedia functions are as follows:

Fn + F1	Computer
Fn + F2	Home
Fn + F3	Calculator
Fn + F4	Media Play
Fn + F5	Prev Track
Fn + F6	Next Track
Fn + F7	Play/Pause
Fn + F8	Stop
Fn + F9	Mute
Fn + F10	Volume -
Fn + F11	Volume +
Fn + F12	E-mail

FN COMPOSITE FUNCTION

Fn + I = HOME   Fn + O = END   Fn + P = ScrLk

LOW VOLTAGE INDICATOR

1. When the battery voltage is lower than 3.3V, the light effect will be turned off, and the red light of the battery indicator will flash slowly when a button is pressed.
2. When the battery voltage is equal to or lower than 3.0V, the keyboard function is turned off.

AUTOMATIC POWER SAVING

The backlight turns off and enters the standby state if the keyboard is not operated for 3 minute, and enters the sleep state if there is no operation in 30 minutes.

CHARGING INDICATOR

If you connect the TYPE-C USB cable to the computer or the charging adapter, the keyboard will be in the charging state, the battery indicator light will be solid red when charging, and will be green when fully charged.

BATTERY LEVEL INDICATOR

Use RGB indicator (red flashing when the battery is lower than 20%, purple when the battery is lower than 40%, blue when the battery is lower than 60%, cyan when the battery is lower than 80%, green when fully charged. The red light is always on when the battery is being charged, and turns green when it is fully charged).

POWER DISPLAY FUNCTION

Fn + Alt To turn off the entire backlight, and the letter area 1!-0) displays the power level. When the battery is low, the button 1!-3# will display in red, the button 1!-0) will display green when the battery is above 3#, and the default light effect will be restored after releasing it.

RECOVER TO THE DEFAULT SETTING

Fn + ESC Long press for 3 seconds to recover to the default setting.

SYSTEM SUPPORT

Windows/Mac.

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model
DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.
DO NOT touch the battery fi material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes
DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.
DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.
DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful

CAUTION:
Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock

---

为满足中国电子电气产品有害物质限制相关的法律和其它要求，对本产品中有害物质，按部件分类，声明如下。

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板组件	X	O	O	O	O	O
外壳及附件	O	O	O	O	O	O

本表格依据SJ/T 11364的规定编制。
O：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。

X：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。
表中标记"X"的部件，皆因全球技术发展水平限制而无法实现有害物质的替代。

印刷电路板组件：包括印刷电路板及其零部件，电子元器件等根据产品型号不同，您所购买的产品可能不会含有以上所有部件。

在中华人民共和国境内销售的电子电气产品必须标识此标志，标志内的数字代表在正常的使用状态下的产品的环保使用期限。

《废弃电器电子产品回收处理管理条例》

倡导环保和低碳的消费体验，建议拥有该产品的用户在不需要此产品时，应遵守国家废弃电器电子产品回收处理相关法律法规，将其交给当地具有国家认可的回收处理资质的厂商进行回收处理，降低资源浪费，保护地球自然环境。

使用手册

元素®

Z-99

有线+2.4G+蓝牙三模RGB机械键盘

产品特色

人体工程学原理的外形设计理念。
高品质按键开关，手感舒适。

LED灯光模式

Fn + Ins 对15种灯光模式进行切换。

Fn + ↑ ↓ 调节背光亮度,调至极限档位时,1、A指示灯烁3次，5级可调。

Fn + ← → 调节背光流光速度，调至极限档位时,1、A指示灯闪烁3次，5级可调。

Fn + Del 背光颜色调节: 红, 绿, 蓝, 黄, 粉, 青, 白, RGB (支持11种灯光模式进行切换)。

两边侧灯光效调节

Fn + PgDn 循环切换侧灯灯效:流光，霓虹，常亮，呼吸，灭。

Fn + PgUp 切换侧灯速度。

Fn + PrtSc 切换侧灯颜色(呼吸、常亮有效)。

白光测试功能

使用 Fn + Tab 测试全键白光，再按一次恢复原有灯效，仅供测试时使用。

灯光录制

Fn + ← = 灯光录制

按FN+退格键(BACKSPACE)进入灯光自定义模式，键位灯全灭。再按一次FN+退格键进入录制状态。1、A指示灯持续闪烁 (录制结束熄灭)。连续按同一按键至指定颜色，再继续设置其他按键，组成所需要的背光图形，完成设定后，再按FN+退格键进行存储即可。播放灯光宏时，按FN+退格键，已定义按键灯会常亮指示(FN键不能自定义灯光)。

有线/2.4G/蓝牙切换

1. 通过键盘前端电源开关及FN键复合功能进行切换。电源开关在OFF档时为有线模式 (M指示灯为绿色)，电源开关在ON档时，FN+ 1! / 2@ / 3# 为蓝牙模式(M指示灯为相应的蓝色/青色/粉红色)。FN+ 4$ 为2.4G模式 (M指示灯为黄色)。

蓝牙/2.4G配对

1. 蓝牙: FN+ 1! / 2@ / 3# 长按3秒进入蓝牙的相应通道配对模式，M指示灯相应的蓝色/青色/粉红色会闪亮，提示进入配对状态，配对成功后指示灯常亮。
2. 2.4G: FN+ 4$ 长按3秒进入2.4G对码模式，M指示灯黄色闪亮，然后再将接收器连接到电脑，对码成功后M指示灯黄色常亮。

BT/2.4G选择

1. 短按 FN+ 1! / 2@ / 3# / 4$ 分别切换键盘的BT1 / BT2 / BT3 / 2.4G状态。

支持锁WIN功能

Fn + Win 键可以锁定WIN键的功能，重复解锁 (注意MAC系统下面无锁Win键功能)。

系统支持

支持Windows/Mac等。

MAC/WIN功能按键对调

默认 WIN 系统，按 FN+W 键按一下切换到 WIN 系统，1、A 指示灯闪烁 3 下，FN+A 切换到 MAC，1、A 指示灯闪烁 3 下。

MAC 多媒体功能如下：

F1	屏幕亮度减/FN+F1=F1
F2	屏幕亮度加/FN+F2=F2
F3	多任务窗口(mission control) /FN+F3=F3
F4	呼出Siri, 延时200MS释放 /FN+F4=F4
F5	app exposé功能 (control+下箭头)/FN+F5=F5
F6	搜索(Command+space) /FN+F6=F6)
F7	上一曲/FN+F7=F7
F8	暂停/FN+F8=F8
F9	下一曲/FN+F9=F9
F10	静音/FN+F10=F10
F11	音量减/FN+F11=F11
F12	音量加/FN+F12=F12

WIN 多媒体功能如下：

Fn + F1	我的电脑
Fn + F2	主页
Fn + F3	计算器
Fn + F4	播放器
Fn + F5	上一曲
Fn + F6	下一曲
Fn + F7	播放/暂停
Fn + F8	停止播放
Fn + F9	静音
Fn + F10	音量减
Fn + F11	音量加
Fn + F12	邮件

FN复合键

Fn + I = HOME   Fn + O = END   Fn + P = ScrLk

低电压指示

1. 电池电压低于3.3V，关闭灯效，在有按键动作时灯带红灯慢闪。
2. 电池电压等于或低于3.0V，键盘功能关闭，在有按键动作时灯带红灯慢闪。

自动省电

键盘未操作3分钟后背光灯熄灭进入待机状态，键盘未操作30分钟键盘进入休眠状态。

充电指示

如果将TYPE-C USB线连接到电脑或充电适配器，键盘将处于充电状态，充电时电池指示灯红色常亮，充满时显示绿色。

电池指示灯指示电量功能

使用RGB指示 (电量低于20%为红色闪烁，电量低于40%为紫色，电量低于60%为蓝色，电量低于80%为青色，满电绿色。充电状态下指示红灯常亮，满电绿色)。

电量显示功能

Fn + Alt 整个背光灭掉,字母区 1! - 0) 显示电量。电量低时按键 1! - 3# 显示红色，3# 以上的电量，1! - 0) 都显示绿色，松开后恢复默认灯效。

恢复出厂设置

Fn + ESC 长按三秒恢复出厂设置并清除所有宏设定。

⚠ 注意

如果电池更换不当会有爆炸危险只能用同样类型或等效类型的电池来更换

--用错误型号的电池组替换，可能会使安全防护失效(例如，对某些类型的锂电池组)；
--将电池组投入火中或加热炉中，或对电池组进行机械挤压或切割的处理可能导致爆炸；
--将电池组放置在极高温度环境中，可能导致爆炸或泄漏可燃液体或气体；和
--电池组承受极低气压，可能导致爆炸或泄漏可燃液体或气体；
--非专业人员请勿拆解或维修此产品，否则有可能造成产品进一步的损坏或人身伤害!

型号	7188	备注：	尺寸：L100*W100mm 材质：100g 双胶纸 印刷：单黑双面印刷				
名称	说明书						
日期	2024 -4-19						
页码	1 OF 5	文件编号	(BYK916+BK3632)				
绘图	何周平	审核		核准		版本	A.0

元素®