

US UK

Dear user

Thank you for choosing the REDRAGON products. In order to protect your right and get better service, please pay attention to the following warranty rules:

1. Within warranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.

2. Consumable parts (such as foot pads) and spare parts replacement are not included in the warranty.

1

2

3

Keyboard functions and installation

1. Plug & Play, no need driver.

2. USB interface.

3. Support Win XP / Vista / Win7 / Win8 / Win10 / Win11.

4. Pairing :
Press and hold 【ESC】 + 【+/-】 button for 3 seconds,LED indicator ON ,plug the USB dongle in 10 seconds, LED indicator OFF, pairing successful.
If the pairing is failed, LED indicator will turn OFF in 10 seconds, Keyboard quit into pairing mode.

5. Multi-media keys

My Computer

Search

Homepage

Email

Calculator

Media player

Stop

Previous

Play/Pause

Next

6. Combination functions

FN + F1= Media player	FN + F7= Play/Pause
FN + F2= Volume-	FN + F8= Stop
FN + F3= Volume+	FN + F9= Homepage
FN + F4= Mute	FN + F10=Email
FN + F5=Previous	FN + F11= My computer
FN + F6= Next	FN + F12=Favorites

4

7. Low power indicator: Any keybaord activities will trigger indicator flash slowly when baterry less than 1V.

Warning: Charging Input: 5V==2A

5

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

6

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.

DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.

DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.

DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.

DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

CAUTION:

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

7

PT

Prezado usuário

Obrigado por escolher os produtos REDRAGON Para proteger seus direitos e oferecer um melhor atendimento, leia com atenção as regras da garantia, abaixo.

1. Dentro do período da garantia, os reparos são garantidos nos casos de falha devido a problemas no circuito elétrico. Danos causados pela desmontagem, por impactos violentos, imersão em água, ligação em correntes ou voltagens incorretas e danos causados por desastres naturais, como incêndios, inundações ou terremotos, não estão incluídos.

2. Peças que sofrem desgaste (como pés) e a substituição de peças avulsas não estão incluídas em nossa garantia.

8

9

10

Funções e instalação do teclado

1. Plug & play, sem necessidade de driver.

2. Interface USB.

3. Compatível com Win XP / Vista / Win7 / Win8 / Win10 / Win11.

4. Pareamento:
Pressione e segure a tecla 【ESC】 + 【+/-】 por 3 segundos e o LED indicador se acenderá. Conecte o dongle USB em 10 segundos e o LED indicador se apagará, indicando que o pareamento foi bem-sucedido.
Se o pareamento falhar, o LED indicador se apagará em 10 segundos e o teclado sairá do modo de pareamento.

5. Teclas multimídia

Meu Computador

Pesquisa Página

principal

Email

Calculadora

Reprodutor de mídia

Parar

Anterior

Tocar/Pausar

Próximo

6. Funções de combinação

FN + F1= Reprodutor de mídia	FN + F7= Tocar/Pausar
FN + F2= Volume+	FN + F8= Parar
FN + F3= Volume+	FN + F9= Página inicial
FN + F4= Mudo	FN + F10=Email
FN + F5=Anterior	FN + F11= Meu computador
FN + F6= Próximo	FN + F12= Favoritos

11

7. Indicador de baixa energia: qualquer atividade no teclado fará o indicador piscar lentamente quando a bateria estiver abaixo de 1V.

Warning: Charging Input: 5V==2A

12

REDRAGON

BK-7367 2.4G WIRELESS MEMBRANE KEYBOARD

USER MANUAL

封底

封面

型号	BK-7367/7367	备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷		文件编号		版本		A.1
名称	说明书							
日期	2025-2-28							
页码	1 OF 1							
绘图	邓子松	审核	香敏琪	核准				