

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.




- 2.4G wireless connection, operating range 10 meters.
- power-saving chip KA8G2, low power consumption,
- 5 switchable DPI 800/1200/1600/2400/4000 settings.
- Supports power-saving mode and low battery reminder function.
- Plug & play Nano receiving adapter. (you can put the receiver inside the mouse for storage. Easy to carry outside and avoid missing).
- Compatibility with Windows/Mac operating system,

1. At first, please insert the accompanied USB receiver into the valid USB port of the computer correctly. The computer will automatically recognize and connect to this receiver.
2. If the keyboard needs to be re-paired, after powering on, please press and hold ESC + K key, the indicator light will enter a flashing state, and the keyboard will enter the pairing mode. The insert the receiver, and the pairing can be completed. (When this keyboard is used for the first time, Windows 2000 and Windows XP systems will be automatically recognize and install the driver program; older versions of the operating system may be require installing Microsoft's standard USB driver program).
3. The keyboard and mouse can be used normally after inserting the battery into the battery compartment of the keyboard and mouse with the polarity marked correctly.

Switchable among five DPI levels. Press the DPI switch button on the mouse. In the switching process, Scroll wheel led: the red LED the light will flash once for 800 DPI, twice for 1,200 DPI, three times for 1,600DPI, four times for 2,400DPI and five times for 4,000DPI.

Media Play Volume - Volume + Mute Prev Track
Play/Pause Next Track Desktop Multitask window Search
Calculator Home E-mail Computer

1. Left button
2. Right button
3. Middle button
4. Forward
5. Backward
6. DPI switch



The wireless mouse may disconnect with the receiver due to high temperature and high magnetic field. In this case, you have to reconnect them.

1. Disconnect the receiver and insert it again.
2. Simultaneously press and hold the left, middle and right buttons for about 3 seconds, the Scroll wheel led will flash in red; indicating the pairing is successful. Remove the battery and then install it in line with the right steps (keep the distance between the mouse and the receiver within about 30 CM).

1. In wireless mode, the data transmit by 2.4GHz radio waves, the linear using distance is up to 10 meters, which could be reduced if there are large obstacles or environmental interference
2. The performance of the mouse may also affected by uneven, reflective desktop.

DO NOT replace the battery with a different model
DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material
DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes
DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.
DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.
DO NOT impact, bend, alter, disassemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful

CAUTION:
Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock



产品质量实行“三包”服务，产品质量期以购机日起保修1年。在质保期内，如因产品本身质量问题我司可视情况提供免费维修、更换或退货服务。

*销售人员承诺的产品之外的服务及附加的配置、赠品，不在本保修服务范围内。

*如无法提供购买时间凭证，产品统一按照序列号标签的时间进行质保时间计算。

Number of children	Number of families
0	1
1	2
2	3
3	2
4	1
5	1
6	1
7	1
8	1

部件名称		印刷电路板组件	外壳及附件
有 害 物 质	铅 (Pb)	X	○
	汞 (Hg)	○	○
	镉 (Cd)	○	○
	六价铬 (Cr(VI))	○	○
	多溴联苯 (PBB)	○	○
	多溴二苯醚 (PBDE)	○	○
质	邻苯二甲酸二 (2-乙基己基) 己酯 (DEHP)	○	○
	邻苯二甲酸丁基苯酯 (BBP)	○	○
	邻苯二甲酸二正丁酯 (DBP)	○	○
	邻苯二甲酸二异丁酯 (DIBP)	○	○

注 1:
○: 表示该有害物质在该部件所有均质材料中的含量均满足电器电子产品有害物质限制使用国家标准要求。
△: 表示该有害物质在该部件所有均质材料中的含量不满足电器电子产品有害物质限制使用国家标准要求。

注 2: 以上列出的部件, 标注其有害物质含量均满足电器电子产品有害物质限制使用国家标准要求。
表中标记“*”的部件, 皆因安全技术要求或水平限制而无须标注有害物质限制使用。

注 3: 电子产品电气系统含有某些有害物质, 在环保使用期限内可以放心使用, 超过环保使用期限之后则应进入回收循环系统。




- 2.4G工作模式。通用性强，无遮挡传输距离近达10米。
- 使用低功耗芯片KA8G2，使信号的功耗更低，电池续航更久。
- 800/1200/1600/2400/4000五档DP切换功能并具DP档位指示，随意切换喜欢的速度。
- 支持省电模式支持省电模式和低电量提醒功能。
- 接收器，即插即用。（可置于鼠标底部接收插口，便于携带外出以免遗忘）。
- 支持Windows/Mac等操作系统。

1. 将随机附带的USB 接收器正确插入计算机的有效USB 接口。计算机将自动识别并连接此接收器。
2. 若键盘需要重新配对，上电后按下ESC+K，指示灯进入闪烁状态，及键盘进入配对模式，这时再插入接收器，即可完成配对。(该键盘初次使用时，WIN2000和WIN XP系统会自动识别并安装驱动程序，较早版本的操作系统可能需要安装微软的标准USB驱动程序)。
3. 将电池正确装入在键盘电池仓内极性标识正确后，键盘即可正常使用。

点按DPI按钮, 800/1200/1600/2400/4000 五档CPI循环切换, 切换过程中, 鼠标滚轮下的红色LED指示灯: 800 DPI时闪烁1次, 1200 DPI时闪烁2次, 1600 DPI时闪烁3次, 2400 DPI时闪烁4次, 4000 DPI时闪烁5次。

多媒体功能 音量减 音量加 静音 上一曲
暂停/继续 下一曲 一键桌面 显示多任务窗口 搜索
计算器 主页 邮件 我的电脑

1. 鼠标左键
2. 鼠标右键
3. 鼠标滚轮和中键
4. 前进键
5. 后退键
6. DPI键



无线键盘和接受器由于某些特殊原因，例如高温，高磁场等，有可能失去正常连接，需要重新连接才可以使用。

① 按下接收器然后重新插上。

② 键盘和接受器之间距离保持在30CM，鼠标同时按下左中右三键，滚轮下的红色LED闪烁，配对等待时间约20S，配对成功后滚轮下的红色LED熄灭，您又可以使用无线鼠标了。

键鼠使用红外线作为移动寻光源，符合相关的安全规定。
键鼠使用2.4GHz无线电波传送数据，视线使用距离为10米。如果有较大的障碍物，环境干扰等，使用距离将会有所减少！
在凹凸不平，反光等桌面上可能影响鼠标的使用。

无线键盘 x1 无线鼠标 x1 接收器 x1 用户手册x1

备注:
此设备必须符合FCC第15条的规定。在以下两个条件下可以运转:1.此设备不会造成任何不必要的干扰。2.此设备可接受/兼容一定的干扰(包括一些非正常的干扰)。
用户未经负责当局明确批准的更改或修正有权禁止使用者操作此设备。

注意

如果电池更换不当会有爆炸危险! 只能用同样类型或等效类型的电池来更换

- 用错误型号的电池替换, 可能会使安全防护失效(例如, 对某些类型的锂电池);
- 将电池组放入高温加热炉中, 或对电池组进行机械损伤或过切割的处理可能导致爆炸;
- 电池组放置在极高温度环境中, 可能导致电池组内短路或液体溢出; 和
- 电池组承受过低气压, 可能导致爆炸或造成泄漏可燃液体或气体;

除非专业人士可能构造拆解或维修此产品, 否则有可能造成产品进一步的损坏或人身伤害!



型号	Z-747 (7369+2967)		备注: 尺寸: L100*W100mm		新 版 
名称	(HTS9206+KA8G2)说明书		材质: 80g书写纸		
日期	2025-7-3		印刷: 单黑双面印刷		
页码	1 OF 3		文件编号		
绘图	何周平	审核	核准		
			版本		A.0