

REDRAGON BS-8531 DeskSet Pro Wireless Keyboard and Mouse Wireless Keyboard and Mouse User manual	US UK Dear user Thank you for you choosing REDRAGON Brand, to protect your rights and for better customer service, we ask that you note our warranty rules. - Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. - Consumable parts (such as foot stick) and spare parts replacement are no included in our warranty. CAUTION: Important Safety Note: For transportation and storage safety, the battery of this product is shipped at a reduced charge level. If you encounter insufficient battery upon first use, please fully charge the device before operation.		KEYBOARD How to connect the keyboard with multiple devices 2.4G Wireless Connection [2.4G/OFF/BT] switch on "2.4G"; the ⬢ slowly flashes in Green, plug the USB receiver into your computer USB port, the keyboard will connect with computer automatically. The ⬢ M on the keyboard will be steady on Green for about 3s then turn off. - If auto-connection unsuccessfully, or you want to connect to new device, plug out the USB receiver, press and hold [FN]+[K5] for more than 3s, the ⬢ M quickly flashes in Green, plug the USB receiver into computer USB port, after paired the indicator will be steady on for 3s and then turn off. BT Connection [2.4G/OFF/BT] switch on "BT". - Press & hold [FN]+[1]/[2]/[3]/[4] for 3s to select corresponding BT channels. The ⬢ M flashes in blue/[1]/cyan/[2]/pink/[3], turn on BT function and searching for available devices, you will find "BT5.0 Keyboard" device names. Select the BT name to pair, after pairing the indicator will be steady on for 3s and then turn off. - To switch the BT connections between BT1/BT2/BT3, press [FN]+[1]/[2]/[3].	Product Features Backlight - Press [FN] + [INS] to cyclic through the default lighting effects. (On, Constant-On, Breathing, Off). - Press [FN] + [1] / [2] / [3] to adjust backlight brightness, total 6 levels. - Press [FN] + [4] / [5] to adjust light rotating speed, total 5 levels. Windows/MAC switching Press FN+W=WIN / FN+A=MAC to switch (WIN/MAC). During the system switch, the ⬢ 1 indicator lights will flash three times. Commands of key combinations with [FN] key <table border="1"> <thead> <tr> <th>MAC O.S.</th> <th>WINDOWS O.S.</th> </tr> </thead> <tbody> <tr> <td>F1: Screen brightness - / FN+F1=F1</td> <td>FN+F1: Screen brightness - (O.S.Win8 or later)</td> </tr> <tr> <td>F2: Screen brightness + / FN+F2=F2</td> <td>FN+F2: Screen brightness + (O.S.Win8 or later)</td> </tr> <tr> <td>F3: Multiple task / FN+F3=F3</td> <td>FN+F4: Multiple windows (Alt+tab)</td> </tr> <tr> <td>F4: Siri / FN+F4=F4</td> <td>FN+F4: Speech recognition (win+h)</td> </tr> <tr> <td>F5: app expose function / FN+F5=F5</td> <td>(O.S.Win10 or later)</td> </tr> <tr> <td>F6: Search (Command+space) / FN+F6=F6</td> <td>FN+F5: Back</td> </tr> <tr> <td>F7: Pre track / FN+F7=F7</td> <td>FN+F6: Search</td> </tr> <tr> <td>F8: Play/Pause / FN+F8=F8</td> <td>FN+F7: Pre track</td> </tr> <tr> <td>F9: Next track / FN+F9=F9</td> <td>FN+F8: Play/Pause</td> </tr> <tr> <td>F10: Mute / FN+F10=F10</td> <td>FN+F9: Next track</td> </tr> <tr> <td>F11: Volume - / FN+F11=F11</td> <td>FN+F10: Mute</td> </tr> <tr> <td>F12: Volume + / FN+F12=F12</td> <td>FN+F11: Volume +</td> </tr> <tr> <td></td> <td>FN+F12: Volume +</td> </tr> </tbody> </table>	MAC O.S.	WINDOWS O.S.	F1: Screen brightness - / FN+F1=F1	FN+F1: Screen brightness - (O.S.Win8 or later)	F2: Screen brightness + / FN+F2=F2	FN+F2: Screen brightness + (O.S.Win8 or later)	F3: Multiple task / FN+F3=F3	FN+F4: Multiple windows (Alt+tab)	F4: Siri / FN+F4=F4	FN+F4: Speech recognition (win+h)	F5: app expose function / FN+F5=F5	(O.S.Win10 or later)	F6: Search (Command+space) / FN+F6=F6	FN+F5: Back	F7: Pre track / FN+F7=F7	FN+F6: Search	F8: Play/Pause / FN+F8=F8	FN+F7: Pre track	F9: Next track / FN+F9=F9	FN+F8: Play/Pause	F10: Mute / FN+F10=F10	FN+F9: Next track	F11: Volume - / FN+F11=F11	FN+F10: Mute	F12: Volume + / FN+F12=F12	FN+F11: Volume +		FN+F12: Volume +
MAC O.S.	WINDOWS O.S.																															
F1: Screen brightness - / FN+F1=F1	FN+F1: Screen brightness - (O.S.Win8 or later)																															
F2: Screen brightness + / FN+F2=F2	FN+F2: Screen brightness + (O.S.Win8 or later)																															
F3: Multiple task / FN+F3=F3	FN+F4: Multiple windows (Alt+tab)																															
F4: Siri / FN+F4=F4	FN+F4: Speech recognition (win+h)																															
F5: app expose function / FN+F5=F5	(O.S.Win10 or later)																															
F6: Search (Command+space) / FN+F6=F6	FN+F5: Back																															
F7: Pre track / FN+F7=F7	FN+F6: Search																															
F8: Play/Pause / FN+F8=F8	FN+F7: Pre track																															
F9: Next track / FN+F9=F9	FN+F8: Play/Pause																															
F10: Mute / FN+F10=F10	FN+F9: Next track																															
F11: Volume - / FN+F11=F11	FN+F10: Mute																															
F12: Volume + / FN+F12=F12	FN+F11: Volume +																															
	FN+F12: Volume +																															
Power save mode & How to recharge On wireless/BT connection mode, when keyboard without any operation over 3 minutes, the keyboard backlight will turn off to enter standby mode, when keyboard without any operation over 10 minutes, the keyboard will enter sleep mode, press any key to wake up. Connect the keyboard to computer with Type-C USB cable, the keyboard will be in the charging state. The ⬢ will be steady on red while charging and will return to the current lighting effect when fully charged. (The keyboard's Type-C port is for charging only.) ⚠ Warning: Charging current: 5V=1A Built-in Li-ion battery 1 unit DO NOT use fast-charging adapter to recharge your keyboard! FAQ - If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer. - If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.	MOUSE Button Instructions - Left button - Right button - Scroll wheel - Click as middle button - Side button, defaulted forward - Side button, defaulted backward - DPI button - Pair button (BT) - Mode/Power Switch: BT/Off (Power Off)/2.4G 2.4G Wireless Connection [BT/OFF/2.4G] switch on "2.4G"; plug USB receiver into computer USB port, click any button, the computer will recognize and configure the mouse automatically. BT Connection [BT/OFF/2.4G] switch on "BT"; the LED indicator light flashes blue, press ⑦ button for about 3s to select BT pair mode. Turn on the computer BT and search for available device, and select device name "BT 5.0 Mouse"; the computer will recognize and configure the mouse automatically.	DPI adjustment and indication (LED lights at the bottom) Press DPI button to cyclic adjust DPI in 400DPI/800DPI/1600DPI/2400DPI/4000DPI, when adjusting the LED lights flashes in Green (in 2.4G mode) / Blue (in BT mode) as below: <table border="1"> <thead> <tr> <th>DPI</th> <th>LED twinkle times</th> </tr> </thead> <tbody> <tr> <td>400 DPI</td> <td>1</td> </tr> <tr> <td>800 DPI</td> <td>2</td> </tr> <tr> <td>1600 DPI</td> <td>3</td> </tr> <tr> <td>2400 DPI</td> <td>4</td> </tr> <tr> <td>4000 DPI</td> <td>5</td> </tr> </tbody> </table> Auto sleep and power save function The mouse will enter sleep mode when it is out of operation in 10s, move or click any button to wake it up, when the mouse is out of operation in 30 minutes, the mouse will enter power save mode, click any buttons to wake it up. How to recharge the battery 1. Low battery warning—The LED indicator will flash red light when the battery is low. 2. Use the USB Type-C cable to connect to PC USB port to charge the battery. The LED indicator will be steady on red while charging and will return to the current lighting effect when fully charged. (The mouse's Type-C port is for charging only.) ⚠ Warning: Charging current: 5V=1A Built-in Li-ion battery 1 unit DO NOT use fast-charging adapter to recharge your mouse!	DPI	LED twinkle times	400 DPI	1	800 DPI	2	1600 DPI	3	2400 DPI	4	4000 DPI	5	FAQ - If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports. - If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended. BATTERY SAFETY GUIDELINES DO NOT replace the battery with a different model. DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material. DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes. DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition. DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations. DO NOT impact, bend, alter, disassemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful. ⚠ CAUTION: Failing to follow all safety guidelines may result product damage, explosion, fire,																	
DPI	LED twinkle times																															
400 DPI	1																															
800 DPI	2																															
1600 DPI	3																															
2400 DPI	4																															
4000 DPI	5																															

型号	HL-BS-8531(8531+4004)		备注：尺寸：100x100mm(折页) 材质：80g书写纸 印刷：单黑色双面印刷					
名称	说明书							
日期	2026-3-17							
页码	1 OF 1		文件编号					
绘图	邓子松	审核	香敏琪	核准			版本	A.0