



REDRAGON

GAMING ESSENTIALS

WIRELESS MECHANICAL KEYBOARD & MOUSE COMBO



Mechanical Gaming Keyboard & Mouse Combo User manual

⚠ CAUTION:

Important Safety Note: For transportation and storage safety, the battery of this product is shipped at a reduced charge level. If you encounter insufficient battery upon first use, please fully charge the device before operation.

US UK

Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.


1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.

2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.


KEYBOARD




A: Cap indicator




M: Mode indicator



Battery indicator



2.4G/OFF/BT mode switch



2.4G receiver storage slot

1

2

Wired Connection

[2.4G/OFF/BT] switch on "OFF", connect the keyboard to the computer with USB cable, the computer will recognize and configure the keyboard automatically. the  is constant-on in Green.

2.4G Wireless Connection

1. [2.4G/OFF/BT] switch on "2.4G", the  flash in Yellow, plug the USB receiver into your computer USB port, the keyboard will connect with computer automatically.

2. If auto-connection unsuccessfully, or you want to connect to new device, plug out the USB receiver, press and hold [FN]+[4\$] for 3 seconds, the  flash in Yellow, plug the USB receiver into computer USB port, after paired the indicator will turn to steady on.

BT Connection

1. [2.4G/OFF/BT] switch on "BT".

2. Press [FN]+[1/2@/3#] to select corresponding BT channels. The  flash in blue[1!]/cyan[2@]/pink[3#], press & hold [FN]+[1/2@/3#] for 3s, the  flash quickly, turn on BT function and searching for available devices, It will find "BT 5.0 Keyboard" device names. Select the BT name to pair, after pairing the indicator will turn to steady on.

Product Features

Backlight

1. Press [FN] + [INS] to cyclic switch default 16 backlight patterns.

2. Press [FN] + [ENTER] to cyclic switch 8 backlight color. (Red - Green - Blue - Yellow - Pink - Cyan - White - RGB)

3. Press [FN] + [SPACE] to turn ON/OFF backlight.

4. Press [FN] + [↑ / ↓] to adjust backlight brightness, total 5 levels.

5. Press [FN] + [← / →] to adjust light rotating speed, total 5 levels.

Backlight DIY (Use with AP)

Press [FN] + [BACKSPACE] to enter DIY mode, [ESC] [A] [S] [D] [W] [↑] [↓] [←] [→] lights on, Press [FN] + [BACKSPACE] again to start recording, then press [FN] + [BACKSPACE] again to back to the backlight patterns before.

DIY backlight patterns by AP,  will flash red light till the recording complete, continuously press the key(except [FN]) to select the color you want to set, once key light color setting are completed, press [FN] + [BACKSPACE] to save. (Due to the limited space of chip, DIY backlight cannot be restored to default settings when the keyboard is reset to factory settings.)

Restore factory settings

Press and hold [FN] + [ESC] for 3 seconds.

Commands of key combinations with [FN] key

FN+F1: This PC	FN+F10: Volume -
FN+F2: Browser homepage	FN+F11: Volume +
FN+F3: Calculator	FN+F12: Email
FN+F4: Media player	FN+<[>=Home
FN+F5: Pre track	FN+<[>=End
FN+F6: Next track	FN+<[>=ScrLK
FN+F7: Play/Pause	FN+<[>=PrtSC
FN+F8: Stop play	FN+<[>=Pause
FN+F9: Mute	

3

Knob function

1. Turn the knob to adjust volume by default, pressing the knob button will mute the sound.

2. Press the knob button for 3 seconds to switch to the backlight brightness mode, the backlight flash twice, then you can turn the knob to adjust the brightness of the backlight.

Press the knob button to cyclic switch default 16 backlight patterns. Press the knob button again for 2 seconds to return to the volume adjustment mode.

Power save mode

On wireless/BT connection mode, when keyboard without any operation over 3 minutes, the keyboard backlight will turn off to enter stand by mode, when keyboard without any operation over 30 minutes, the keyboard will enter sleep mode, press any key to wake up.

Battery power indicator: Press and hold the [FN] + [ALT] to show the battery level, the backlight will only light on [1-0] keys to indicating current battery level, battery levels of [1-3] keys are displayed in red, while levels above 3 are displayed in green, release to back to current light mode.

⚠ Warning: Charging Input: 5V ---1A

DO NOT use fast-charging adapter to recharge your keyboard !

Built-in Li-thion battery 1 unit.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.

2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excessliquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.

4

MOUSE

Button Instructions

1. Left button

2. Right button

3. Scroll wheel

(Click as middle button)

4. Side button, defaulted forward


5. Side button, defaulted backward


6. DPI + (default)

7. DPI - (default)

8. BT pairing button

9. BT/OFF/2.4G switch





Pair BT



BT

Off

2.4G

Quick start guide

Wired Connection

[2.4G/OFF/BT] switch on "OFF", connect the mouse to computer with USB cable. The computer will recognize and configure the mouse automatically and charging mouse battery.

2.4G Wireless Connection

1. [2.4G/OFF/BT] switch on "2.4G".

2. Plug the USB receiver into USB port on your computer, the computer will recognize and configure the mouse automatically.

Tip: If auto-connection unsuccessfully, or you want to connect to new device, plug out the USB receiver, press and hold ①+②+③ for 3 seconds, the LED flashes in Green, plug the USB receiver into computer USB port, the mouse will re-connect.

5

BT Connection

1.[2.4G/OFF/BT] switch on "BT".

2. Press  button for 3 seconds, the mouse entered pairing status.

Turn on the PC BT function and searching for available devices, it will find "BT5.1 Mouse" device. Select the device to pair, after paired you can start use the mouse.

Power save function

The mouse will enter power save mode when it is out of operation over 2 minutes, move mouse or click any button to wake it up.

How to recharge the battery

① Low battery warning—the scroll wheel LED will twinkling in red when the battery is low.

② Use the USB cable to connect to PC USB port to charge the battery, the scroll wheel LED will steady on in red, after battery fully charged the LED turns to current DPI color.

⚠ Warning: Charging current: 5V ---1A max

DO NOT use fast-charging adapter to recharge your mouse!

DPI adjustment and indication

Default DPI& indicator color (scroll wheel LED breathing lighting), S157-PRO supports max 12800DPI (adjust through mouse software)

1. RED --- 400 DPI

2. BLUE --- 800 DPI

3. GREEN --- 1600 DPI

4. CYAN --- 2400 DPI

5. PURPLE --- 3200 DPI

6

Report rate adjustment

The mouse support adjust report rate[125Hz-250Hz-500Hz-1000Hz], use mouse software to set the report rate.

For more adjustable function & macro recording, please download& install mouse software to enable more possibility.

Built-in Li-thion battery 1 unit.

FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.

2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.

DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.

DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.

DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.

DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

⚠ CAUTION:

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

7

ISED WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licenceexempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteurexempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation. Sciences et DéveloppementéconomiqueCanada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'appareil doit accepter tout brouillage radioélectrique subi, même si e brouillage est susceptible d'en compromettre le fonctionnement 'appareil numérique du ciem conforme

1. Cleaning Instructions:

Before cleaning, always unplug the device from the computer's USB port. Clean the surfaces with a soft, dry cloth. For stubborn dirt, use a cloth that is slightly dampened with water. Do not use chemical agents or solvents. Ensure the devices are completely dry before reconnecting them.

2. Ergonomic Health and Safety Guide:

Incorrect or prolonged use of computer equipment can lead to discomfort, fatigue, headaches and serious long-term injuries known as musculoskeletal disorders (MSDs). Please take relaxation breaks every 30-60 minutes.

3. WARNING:

The product is not a toy. Please keep it out of reach of small children. The product contains small components that may pose a choking hazard.

8

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

9

型号	HL-S168(8986+2910)		备注：尺寸：100x100mm(折页) 材质：80g书写纸 印刷：单黑色双面印刷									
名称	说明书											
日期	2026-2-5(修改)											
页码	1 OF 1		文件编号									
绘图	邓子松	审核	香敏琪	核准		版本	A.1					