

HD WiFi Camera




Quick Start Guide

Model: T5820HCA

Version No.: 1.0

Before using the product, please read the guide carefully to avoid any damages to the product in virtue of faulty operation or misuse.

1 Appearance



Pilot lamp
Camera Lens
Light sensor
Support
Base

(The front)

After the holder is put in the lampstand, twist downward; twist the holder to the left, then it closes. **close**

After the holder is put in the lampstand, twist downward; twist the holder to the right, then it opens. **open**

-1-



Micro SD card slot
MIC hole
SET(Press 'SET' button by a needle)
DC5V power socket
Silica gel pad (Install it or not is at your option.)

※ Maximally support the cyclic recording of 64GB micro SD card.

-2-

2 Installation

Preparation prior to Installation


1. 2.4G wireless router is required.
2. support Android 4.4 and above, iOS 8.0 and above
3. Download and install the APP:
A. Open the App Store , search "GOSCOM" and install.
B. Open the Google Play Store , search "GOSCOM" and install.
4. Here is an operation example of Android APP, and it can serve as a reference for the IOS APP.
5. power-on Camera and there will be prompt sound indicating power on succeed



-3-

Register/Login

Step 1: Click the "GOSCOM" APP icon to open it (figure 1);
Step 2: Use email address for user ID registration (figure 2-3);
Step 3: After registration, enter the email address and then password to log in (figure 2)




TIP: For user ID registration, please use an effective email address, (example XXXX@qq.com), in order to retrieve the password.


-4-

scan the QR code to add

1.Click "Add Camera" (figure 4) → Click "scan the QR code to add" (figure 5)



2.Configure WiFi, enter WiFi name and password, and Click "Confirm" after that. (figure 6)P.S:Device does not support 5G Wi-Fi network; if this is not your desired network, tap to toggle. (figure 7)




-5-

3.Please press the "SET" key for 1 second, and then you will hear a "Beep" sound(figure 8)




4.Click the QR code icon (Figure 9) , switch to the QR code scanning mode, and scan the ID QR code

- QR Code on the camera sticker (Figure 10) ;
- Or choose the QR code picture from the album for ID scanning (Figure 11)



5.When the APP Switch to the precaution page before scanning, please read the prompts carefully and click "Next step"(Figure 12) When the mobile phone shows a QR code interface, please align the QR code to the camera, with a distance of about 10 ~ 20cm (Figure 13); if scanning succeeds, you will hear "Beep"twice.




-6-



6. After scan the QR Code, and when you hear "Beep" twice Click "I Have Heard It"(Figure 14), and now the camera is connecting to the router WiFi. When you see that the indicator on the device turns from blinking green to be steady on, it indicates that the device is connected and will automatically skip to the device list. (Figure 15)


Click the device to enter the real-time monitoring interface. (Figure 16)



-7-

Add by WiFi

1. Click "Add Camera"(Figure 17) → Click "Add by WiFi" (Figure 18)→ Configure WiFi, enter WiFi name and password, and click "Confirm" after that.(Figure 19)P.S:Device does not support 5G Wi-Fi network; if this is not your desired network, Click to toggle




2. Please press and hold the "SET" key for 1 second, and then you will hear a "Beep" sound(Figure 20)




3. Click the QR code icon (Figure 21) , switch to the QR code scanning mode, and scan the ID QR code

- QR Code on the camera sticker (Figure 22) ;
- Or choose the QR code picture from the album for ID scanning (Figure 23)



-8-


4. After you click "Confirm", when you will hear "Beep"twice, indicates that the camera is connecting to the router. When you see that the indicator on the device turns from blinking green to be steady on, it indicates that the device is connected and will automatically skip to the device list. Click the device to enter the real-time monitoring interface.



-9-

3 View Monitoring and Operate

After the device is connected, you can view real-time monitoring, and take a picture, record a video, speak, set up and make other operations on your mobile phone.




1. Voice button: Click to close/disclose the voice
2. Talkback button: press and hold this button to talk with the camera.
3. Capture button: click to fast capture (save in the settings directory Album Book option).
4. Playback button: Click to enter the playback page, you can view the camera SD card range of Wi-Fi hotspots.
5. Record button: Click to start recording, click the button again (stored in the set the directory of the album option).
6. PTZ button: Click this button, APP pop-up PTZ control interface for Head level, vertical angle to adjust (Figure 28).
7. Sharpness button: Click to adjust the Resolution pixel for real-time video monitoring (HD/SD)
8. Set button: Click this button to set the camera-related functions.

-10-

4 Features

Software Upgrade


1. Click "Settings" icon(Figure 29)-> Click "Device Information" (Figure 30)-> Click "System Firmware"(Figure 31)-> Click "Update Now" (Figure 32)(It can only be upgraded if there is a small red spot on the top right corner of the application firmware)




-11-

Device Unbinding


1. Click "Settings" icon(Figure 33)-> Click "Delete Device" (Figure 34)APP will automatically switch to camera list, delete the camera you want to Unbundled it from the APP



2. Click "setting" icon(Figure 35) → Click "share with friends" (Figure 36) – you can have the QR code(Figure 37)




-12-



35 36 37

If other users want to add the camera, Click "Add Camera" → select "Add Friends to Share" mode(Figure 38)- Click the QR code icon (Figure 39) , switch to the QR code scanning mode- scan the QR code shared by friends- Enter the Device List(Figure 40)



-13-

5 Camera Indicator Instruction

Red indicator remains	Indicates that power failure or network not connected.
Red indicator flashes	Indicates that camera is connecting to network.
Green indicator flashes	Indicates that network connected successfully (no internet).
Green indicator remains	Indicates the camera is connected to server and working well.

-14-

6 Technical Parameters

Video Compression	1920x1080
Imaging sensor	1/2.7"CMOS
Horizontal viewing angle	85±5°
Effective pixel	200W
Night vision range	5m (max)
WiFi Transport protocol	WiFi
Recording media	64GB(max)
Working voltage	DC+5V/1A
Working temperature	-10℃~+40℃
Dimension (HxDxW)	124x82x82mm
Weight:	108g

※ All parameters change without prior notice. The final right of interpretation is reserved by the company.


-15-

7 Function Characteristics

- 24/7 live video streaming.
- High resolution provides excellent picture quality.
- Smart motion alerts on your phone so you know if anything happens.
- Advanced video recording on the micro SD card.
- Night vision up to 5 meters.
- Talk & Listen. See your dog on the couch and tell him to get off.
- Quick, easy setup.
- Compact design fits in the smallest corner of your home.

-16-

8 Package List



※ The picture is only for reference and the real object shall prevail.

-17-

9 Tips

- 1.Suggest using qualified micro-SD card to avoid incompatibility. Format micro-SD card before using.
- 2.In setting page of app (Fig. 11), click "Delete device" to remove the connected camera, can remove the bonding with the account.
- 3.Movement detection: when movement is detected within the scope of camera, the camera will record video and take photos automatically. Videos and photos will be saved in micro-SD card.
- 4.Sharing with Friends: Share two-dimension code of the device with your friends.
- 5.Cancel sharing with friends: Delete the camera and cancel sharing with friends. (You have to re-add the camera to use it again)
- 6.Push message: when movement is detected, alarm message can be sent to server and pushed to your phone.
- 7.Remote monitoring: after the camera is connected to Internet successfully, app can view the monitor via Internet, anytime, anywhere.
- 8.Special characters are accessible only under English mode, and other punctuation mark used in other language inconsistent with that under English mode cannot be input. Available special characters include "@, #, &, *, -, ., /, ?, (,), ", and unavailable special characters include "%", " ", "<", ">".
- 9.When this machine has a crash fault or other abnormal conditions influencing the usage, it is recommended to cut out the power and restart; or press SET key for 5 seconds, which can restore factory settings, and then please reconnect the router.

-18-

10 Troubleshooting

1. Wi-Fi cannot be connected
 - a) Ensure that the antenna of camera is fixed well.
 - b) Ensure that camera is in range of router. Keep the distance less than 40fts between router and indoor camera, less than 65fts for outdoor camera.
 - c) Ensure that SSID and password of Wi-Fi contains no special characters. Modify the SSID and password of Wi-Fi with only English characters, no special characters.
 - d) Ensure that SSID and password are no longer than 16 characters
 - e) Ensure that SSID is broadcasted.
 - f) Ensure that the DHCP is enabled on router.
 - g) Ensure that Wi-Fi encryption method is WPA2-PSK/ WPA-PSK or AES.
 - h) Ensure that Wi-Fi signal is 2.4GHz.
 - i) Ensure that there is no MAC filter on router or add MAC address to router whitelist
 - j) We suggest rebooting the router, and the "security settings, encryption method" of WiFi password should never choose "auto-select".
 - k) Reset the camera to set up connection again. Press and hold SET key for 5 seconds.
2. Red indicator remains, network connection is failed.
 - a) Ensure that the password of Wi-Fi is correct.
 - b) Ensure that the network connects to Internet freely.
 - c) Ensure that the camera is in range of Wi-Fi hotspot.
3. Green indicator flashes, connection to server failed.
 - a) Ensure that Wi-Fi signal is strong enough and bandwidth is enough for connection. Move near to Wi-Fi hotspot or increase the bandwidth.
 - b) Ensure that camera is not under interferon of other 2.4GHz signal.

-19-

The operated frequency is 2.4G~2.4835G with B/G/N20/N40.
The Max output power on 802.11b is 15.96dBm.
The Max output power on 802.11g is 14.98dBm.
The Max output power on 802.11n-20 is 15.12dBm.
The Max output power on 802.11n-40 is 14.67dBm

EU Environmental Provisions

E-waste cannot be mixed with household garbage; corresponding local government sector or recycling stations shall be responsible for circular process.



-20-