



CONTENIDO DEL PAQUETE:

- Manette sans fil Radium
- Récepteur USB de la manette Radium
- Manuel d'utilisation/carte de garantie
- Carte d'inscription

INSTALLATION :

1. Ouvrez le compartiment à piles situé sous la manette sans fil Radium. Insérez 3 piles “AAA”. Remettez en place le couvercle du compartiment à piles.
REMARQUE : les piles “AAA” ne sont pas fournies. Aussi, assurez-vous d'utiliser des piles neuves lors de l'utilisation de la manette sans fil Radium.
2. La manette sans fil Radium dispose d'un commutateur ON/OFF situé au dos de la manette. Positionnez le commutateur sur ON.
3. Lorsque la console PlayStation 3 est en marche, raccordez le récepteur USB de la manette Radium à un des connecteurs USB situés sur le panneau avant de la console PlayStation 3. Les 4 indicateurs de canal situés sur la manette sans fil Radium clignotent lentement.
4. Appuyez sur la touche Connect du récepteur USB de la manette Radium. Le témoin lumineux du récepteur USB clignote rapidement.
5. Appuyez sur la touche Menu située sur la manette sans fil Radium. Les 4 indicateurs de canal clignotent rapidement. Appuyez à nouveau sur la touche Menu, la manette est configurée sur le canal approprié. L'indicateur s'allume de manière fixe pour indiquer le joueur sur lequel la manette est définie : joueur 1, joueur 2, etc.
6. Pour connecter plusieurs manettes sans fil Radium, connectez individuellement chaque manette. Tout d'abord, connectez la manette du joueur 1 puis les manettes des autres joueurs une par une.

REMARQUE : Durant le jeu, vous pouvez accéder au menu de la console PlayStation 3 en maintenant enfoncée la touche Menu pendant 3 secondes. Veuillez vous référer au manuel d'utilisation de la console PlayStation 3 pour de familiariser avec les différentes options du menu disponibles.

FONCTION TURBO :

1. Pour activer la fonction Turbo, appuyez simultanément sur une touche ainsi que sur la touche Turbo (située au dessus des indicateurs de canal) pour activer la fonction Turbo sur cette touche spécifique.
2. Pour annuler la fonction Turbo, répétez l'étape 1.

MODE SOMMEIL :

La manette sans fil Radium dispose d'un mode Sommeil. Le mode Sommeil de la manette sans fil Radium s'active dans les cas suivants:

1. La manette est déconnectée du récepteur pendant une période supérieure à 30 secondes.
 2. Au bout de 5 minutes d'inactivité des sticks analogiques
- Pour activer la manette depuis le mode Sommeil, il vous suffit simplement de déplacer un stick analogique ou d'appuyer sur une touche de la manette.

INDICATEUR DE CHARGE FAIBLE :

Lorsque le niveau de charge des piles de la manette Radium devient faible, les indicateurs des 4 canaux clignotent à raison de 4 fois/seconde. Lorsque cela se produit, retirez les piles usagées puis remplacez-les par des piles neuves.



POUR ASSISTANCE TECHNIQUE
VEUILLEZ CONTACTER : 1-877-999-DREAM
Ou support@dreamgear.net

iSound

dreamGEAR

WARRANTY CARD

All dreamGEAR/i.Sound products come with a limited warranty and have been subjected to a thorough series of tests to ensure the highest level of dependability and compatibility. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, dreamGEAR warrants to the original consumer purchaser that this product will be free from defects in material and workmanship for a period of 120 days from the date of your original purchase. If a defect covered by this warranty occurs, dreamGEAR, at its option, will repair or replace the product purchased at no charge. If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of dreamGEAR.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to products used for any industrial, professional or commercial purposes.

For service on any defective product under the 120-day warranty policy, please contact Consumer Support to obtain a Return Authorization Number.


NOTE: dreamGEAR will not process any defective claims without a Return Authorization Number.

Consumer Support Hotline:
877-999-DREAM (3732) (U.S. and Canada only) or
310-222-1045 (International)

Consumer Support Email: support@dreamgear.net

Websites:
www.dreamgear.net
www.isound.net

RADIUM WIRELESS
USER'S GUIDE



www.dreamgear.net



PACKAGE CONTENTS:

- Radium Wireless Controller
- Radium USB Receiver
- User's Guide/Warranty Card
- Registration Card

SET-UP:

1. Open the battery compartment located on the bottom side of the Radium Wireless Controller. Insert 3 “AAA” batteries. Replace battery compartment cover.
NOTE: “AAA” batteries not included. Also, make sure that you use fresh batteries when playing with the Radium Wireless Controller.
2. The Radium Wireless Controller features an ON/OFF switch located on the bottom side of the controller. Switch the controller to ON.
3. With the PlayStation 3 console powered ON, plug the Radium USB Receiver into one of the USB ports located on the front of the PlayStation 3. The 4 channel indicator lights on the front of the Radium Wireless Controller will flash slowly.
4. Press the Connect button on the Radium USB Receiver. The LED on the receiver will flash rapidly.
5. Press the Menu button located on the front of the Radium Wireless Controller. The 4 channel indicators will flash rapidly. Press the Menu button again and the controller will be set to the appropriate channel. The solid LED will indicate which player position the controller is set to, Player 1, Player 2, etc.
6. To connect multiple Radium Wireless Controllers, connect each controller separately. First, connect Player 1's controller and then connect the remaining controllers, one by one.

NOTE: During gameplay, you can access the PlayStation 3 menu by holding the Menu button for 3 seconds. Please refer to the

PlayStation 3 console User's Guide to see what menu options are available.

TURBO FUNCTION:

1. To activate Turbo, press any button and the Turbo button (located above the 4 channel indicator lights) at the same time to set Turbo to that specific button.
2. To cancel the Turbo function, repeat Step 1.

SLEEP MODE:

The Radium Wireless Controller features a Sleep Mode. The Radium Wireless Controller will enter Sleep Mode if one of the following occurs:

1. If the controller loses contact with the receiver for more 30 seconds.
 2. 5 minutes of analog stick or button inactivity
- To turn the controller on from being on Sleep Mode, simply move the analog stick or press a button on the controller.

LOW BATTERY INDICATOR:

When the batteries in the Radium Controller are lower than the standard amount needed, the LED on the 4 channel indicator lights will flash 4 times/second. If this occurs, please remove the old batteries and replace them with fresh batteries.



FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net



CONTENU DU PACK:

- Controlador Inalámbrico Radium
- Receptor USB Radium
- Guía de usuario/Tarjeta de garantía
- Tarjeta de registro

CONFIGURACIÓN:

1. Abra el compartimiento de baterías que está ubicado en la parte inferior del Controlador Inalámbrico Radium. Inserte 3 baterías „AAA“. Coloque de nuevo la tapa del compartimiento.
NOTA: Las baterías “AAA” no están incluidas Asegúrese de utilizar baterías nuevas cuando juegue con el Controlador Inalámbrico Radium.
2. El Controlador Inalámbrico Radium tiene un interruptor ON/OFF ubicado en su parte inferior. Ponga el interruptor del controlador en la posición ON (encendido).
3. Con la consola PlayStation 3 encendida, conecte el Receptor USB Radium en uno de los puertos USB ubicados en la parte delantera de la PlayStation 3. Las 4 Luces indicadoras de canal que están en la parte frontal del Controlador Inalámbrico Radium parpadearán lentamente.
4. Presione el botón “Connect” del Receptor USB Radium. El LED del receptor parpadeará rápidamente.
5. Presione el botón “Menu” ubicado en la parte delantera del Controlador Inalámbrico Radium. Los 4 indicadores de canal parpadearán rápidamente. Presione de nuevo el botón "Menu" y el controlador se configurará en el canal apropiado. El LED que permanezca encendido de manera permanente indicará en cuál posición de jugador está configurado, jugador 1, jugador 2, etc.
6. Para conectar múltiples Controladores Inalámbricos Radium, conecte cada uno por separado. Primero, conecte el controlador del Jugador 1 y después los controladores restantes, uno por uno.

NOTA: Durante el desarrollo del juego, puede acceder al menú de

la PlayStation 3 manteniendo oprimido durante 3 segundos el botón “Menu”. Consulte la Guía de Usuario de la consola PlayStation 3 para ver las opciones de menú que están disponibles.

FUNCIÓN TURBO:

1. Para activar el Turbo, presione cualquier botón al mismo tiempo que el botón Turbo (ubicado encima de las cuatro luces indicadoras de canal) para ajustar el Turbo en ese botón específico.
2. Para cancelar la function Turbo, repita el Paso 1.

MODO ESPERA:

El Controlador Inalámbrico Radium tiene un Modo de Espera. Entrará en este modo si ocurre uno de los eventos siguientes:

1. Si el controlador pierde contacto con el receptor durante más de 30 segundos.
 2. 5 minutos de inactividad del mando analógico o de los botones
- Para sacar al controlador del Modo de Espera, simplemente mueva el mando analógico o presione un botón del controlador.

INDICADOR DE BATERÍA BAJA.

Cuando las baterías del Controlador Radium están más bajas que la cantidad estándar necesaria, el LED de las 4 Luces indicadoras de canal parpadeará a un ritmo de 4 veces por segundo. Si esto ocurre, retire las baterías viejas y sustitúyalas por baterías nuevas.



PARA SOPORTE TÉCNICO
CONTACTE AL: 1-877-999-DREAM
o support@dreamgear.net

Federal Communications Commission (FCC) Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.